

TESLA

HEAT PUMP AIR TO WATER

USER
MANUAL

ENG

SRB

Ver. 2022

ENG

OPERATING INSTRUCTION

Note: All the pictures in this manual are just schematic diagrams, the actual is the standard. Please read this owner's manual carefully and thoroughly before operating the unit! Take care of this manual for future reference.

SRB

UPUTSTVO ZA UPOTREBU

Napomena: Sve slike u ovom priručniku su samo šematski dijagrami, fizički proizvod je standard. Molimo Vas da pažljivo i temeljno pročitate ovo uputstvo za upotrebu pre korišćenja uređaja! Sačuvajte ovo uputstvo za buduću upotrebu.

Applicable Model:

5KW
8KW
10KW
12KW
14KW
16KW



1. The appliance shall be installed in accordance with national wiring regulations.
2. This appliance is intended to be used by expert or trained users in shops, in light industry and on farms, or for commercial use by lay persons.
3. This appliance is not intended for use by persons (including children) with reduced physical, sensory or mental capabilities, or lack of experience and knowledge, unless they have been given supervision or instruction concerning use of the appliance by a person responsible for their safety.
4. Children should be supervised to ensure that they do not play with the appliance.
5. This appliance can be used by children aged from 8 years or above and persons with reduced physical, sensory or mental capabilities or lack of experience and knowledge if they have been given supervision or instruction concerning use of the appliance in a safe way and understand the hazards involved.
6. Cleaning and user maintenance shall not be made by children without supervision.
7. Disconnect the power source before service or replacing parts.
8. Warning: before obtaining access to terminals, all supply circuits must be disconnected.

Applicable Model:

- 5KW
- 8KW
- 10KW
- 12KW
- 14KW
- 16KW



- 9. Disconnect the power supply before cleaning and maintenance.
- 10. If the supply cord is damaged, it must be replaced by the manufacturer, its service agent or a similarly qualified person in order to avoid a hazard.
- 11. An all-pole disconnection switch having a contact separation of at least 3mm in all poles should be connected in fixed wiring.
- 12. The appliance shall not be installed in the laundry.
- 13. F-gas , The equipment contains fluorinated greenhouse gas R32,Global Warming Potential(GWP):677

Correct Disposal of this product	
	<p>This marking indicates that this product should not be disposed with other household wastes throughout the EU. To prevent possible harm to the environment or human health from uncontrolled waste disposal, recycle it responsibly to promote the sustainable reuse of material resources. To return your used device, please use the return and collection systems or contact the retailer where the product was purchased. They can take this product for environmental safe recycling.</p>

	outdoor temperature	indoor temperature
cooling mode operation	-5~46°C	-25~40°C
heating mode operation	-28~43°C	-25~40°C
DHW mode operation	-28~43°C	-25~40°C

1 Safety Precautions

Warning

* **This air conditioner is a comfortable air conditioner. Please do not use it in special places storing items like computers, precision instruments, food, plants, animals or artware.**

- ⌘ Please entrust a dealer or professional to install. The installer must have relevant professional knowledge. Do not install by yourself, the improper installation will cause fire, electric shock, injury, water leakage and other accidents.
- ⌘ When installing in a small room, take appropriate measures to ensure that the concentration of refrigerant leakage in the room does not exceed a critical level. Please consult your dealer for specific measures.
- ⌘ Observe the regulations of local electric companies when connecting power cables. According to the law, the ground wire must be well connected. If the ground wire is not properly connected, it may cause electric shock.
- ⌘ When the air conditioner needs to be moved or reinstalled, please entrust the dealer or professional to operate. Improper installation will result in fire, electric shock, injury, water leakage and other accidents.
- ⌘ Never modify or repair it yourself. Improper repairing may result in fire, electric shock, injury, water leakage, etc., and must be repaired by a dealer or professional.

Attention

- Confirm that the drainage ditch can drain smoothly.
- Check if the leakage protection switch is installed. The earth leakage protection switch must be installed. If it is not installed, it may cause electric shock.
- Do not install in a place where flammable gases are easily leaked. In the event of a flammable gas leak, it may cause a fire if it is trapped around the indoor unit.
- Confirm that the installation base and hoisting are firm and reliable. If the foundation and hoisting are not strong enough, it may fall and cause an accident.
- Connect the cables correctly. If the cables are not correctly connected, electrical parts may be damaged.
- Exposing the unit to water or other moisture before installation may cause short-circuiting of electrical components. Do not store it in a wet basement or expose it to rain or water.
- If the refrigerant leaks during installation, immediately ventilate the room. If the refrigerant gas leaks out and comes into contact with the fire, it may produce toxic gases.
- After the installation is completed, check and confirm that the refrigerant is not leaked.
- If the refrigerant gas enters the room and comes into contact with a fire source such as a heater, stove or rice cooker, it may produce toxic gases.
- Please install the lightning protection device according to the national laws and regulations, otherwise the machine may be damaged by lightning.

2 Construction Check Points

2.1 Arrival of Goods(AOG) and Out of Box Audit(OOBA)

- 1) After receiving the machine, check for transport damage. If damage is found on the surface or inside, it should be reported to the transportation company immediately in written form.
- 2) After receiving the machine, check whether the model, specification and quantity of the equipment are in accordance with the contract.
- 3) When unpacking, please keep the operating instructions and check the accessories.

2.2 Refrigerant piping

- 1) The refrigerant piping shall use pipeline with specified diameter and wall thickness.
- 2) When the copper tube is welded, it must be filled with nitrogen. Before welding, it is filled with 0.2 kgf/cm² of nitrogen. After the welding is completed, wait until the copper tube is completely cooled and stop the nitrogen supply.
- 3) The refrigerant piping must be insulated.
- 4) After the refrigerant piping is installed, the indoor unit cannot be energized until the airtightness test and vacuuming are performed.

2.3 Air tightness test

After the refrigerant piping is installed, it is necessary to inject nitrogen at a pressure of 40 kgf/cm² (4.0MPa) from the gas side and the liquid side for a 1-hour air tightness test.

2.4 Vacuum treatment

After the air tightness test, vacuum treatment must be carried out simultaneously from both sides of the gas and liquid (vacuum treatment should reach -0.1 MPa).

2.5 Refrigerant adding

- 1) Calculate the amount of refrigerant added based on the pipe diameter and length (solid length) of the liquid side piping between the outdoor unit and the hydronic module.

2.6 Electrical wiring

- 1) Please select the power supply capacity and wire diameter according to the design manual. The power cord of the air conditioner is thicker than the power cord of the general motor.
- 2) To prevent malfunction of the air conditioner, be careful not to make the power cords (220v) to be interleaved and entangled with the communication wire of indoor and outdoor unit (low voltage wiring).
- 3) After performing the airtightness test and vacuum pumping, energize the hydronic module.

2.7 Trial run

Test run can only be performed after at least 3 hours preheating, otherwise the system will be damaged.

3 Installation of Outdoor Unit

Warning

- ⌘ Install the air conditioner in a firm place where the unit can be supported.
- ⌘ If the strength is not enough, the unit may fall and cause personal injury.
- ⌘ Perform specific installation work to prevent strong winds or earthquakes.
- ⌘ Incomplete installation can cause an accident due to the falling of the unit.

3.1 Installation location selection

- 1) Provide sufficient space for installation and maintenance.
- 2) The place shall ensure that the air inlet and outlet are unobstructed and not influenced by the strong wind.
- 3) Dry and ventilated place.
- 4) The supporting surface shall be flat and withstand the weight of the outdoor unit, so that the outdoor unit can be installed horizontally without bringing more noise and vibration.
- 5) Operation noise and exhaust air shall not affect neighbors.
- 6) No flammable gas leaks.
- 7) Easy to install the connecting pipe and electrical connection.

3.2 Dimensions of outdoor unit (unit: mm)

- 1) 5KW、8KW




Figure 3-1 Dimensions of outdoor unit

- 2) 10KW、12KW




Figure 3-2 Dimensions of outdoor unit

3 Installation of Outdoor Unit

3) 14KW、16KW




Figure 3-3 Dimensions of outdoor unit

3 Installation of Outdoor Unit

3.3 Hoisting of outdoor unit

1) A solid and proper foundation has the following effects:

- ① The outdoor unit will not sink.
- ② The outdoor unit does not generate abnormal noise caused by the foundation.

2) Types of foundation

- ① Steel structure foundation.
- ② Concrete foundation (refer to the following figure).




Figure 3-3 Outdoor unit installation and maintenance space Unit:mm

- ⊗ Please entrust a dealer or professional to install. The installer must have relevant professional knowledge. If it is wrongly installed by yourself, it may cause fire, electric shock, injury, water leakage and so on.
- ⊗ When installing in a small room, provide appropriate measures to ensure that the concentration of refrigerant leakage in the room does not exceed a critical level. Please consult your dealer for specific measures.
- ⊗ Observe the regulations of the local electric companies when making power connection. According to the law, the ground wire must be well connected. If the ground wire is not properly connected, it may cause electric shock.
- ⊗ When the air conditioner needs to be moved or reinstalled, please entrust the dealer or professional to operate. Improper installation will result in fire, electric shock, injury, water leakage and other accidents.
- ⊗ Never modify or repair it by yourself. Improper repairing may result in fire, electric shock, injury, water leakage, etc., and must be repaired by a dealer or professional.

4 Installation of Connecting Pipe

4.1 Refrigerant piping

1) Flaring

Cut the pipe with the pipe cutter, and flare with a pipe expander.




Figure 4-1 Cutting of the connecting tube

Table 4-1 Flaring size of connection tube

Outer diameter (mm)	A(mm)	
	MAX	MIN
Φ9.5	12.4	12.0
Φ15.9	19.0	18.6

2) Fastening nut

Align the connecting tube, tighten the nut by hand, and then tighten with a wrench.




Figure 4-2 Tightening

Table 4-2 Tightening torque

Piping size (mm)	Tightening torque (N·m)
Φ9.5	32.7~39.9(333~407 kgf·cm)
Φ15.9	61.8~75.4(630~770 kgf·cm)

Attention

- ⌘ In order to prevent oxidation inside the copper tube during copper pipe welding, nitrogen filling must be taken. Otherwise the scale will block the refrigeration system!
- ⌘ When the nut is tightened, too much force will break the bell mouth, and too little force will cause leakage. Please refer to the tightening torque in the above table to tighten the nut!

4.2 Connection diagram of hydronic module and outdoor unit




Figure 4-3

4 Installation of Connecting Pipe

4.3 Accessory pipe in the pipeline

Because of different mounting positions of the heat pump, the required accessory pipe can be long or short, to avoid too long refrigerant pipe affecting the unit capacity, please select a reasonable pipe length according to table below, try to select the location of the short pipe for the installation.


1. The maximum allowable operating distance away from the pipe

Rated refrigerating capacity Value	<6.5kW	6.5~10.5kW	≥10.5kW
	A Pipeline length (one-way)	Maximum length 15m	Maximum length 20m
B Height difference(one-way)	Maximum length 8m	Maximum length 10m	Maximum length 20m
C Pipeline bends quantity	Up to 10	Up to 10	Up to 15

Note: On condition that 80% of the capacity is guaranteed, in the above parameters, the cooling capacity loss and return oil has been fully considered.

2. The use of oil return elbow

When the height difference between the indoor and outdoor unit is greater than 5 m, in order to facilitate oil return of the compressor, oil return elbow must be used. Upon site operations, the following typical installation methods can be referred to (see Figure below).



Note: Oil return elbow radius $R \leq 100\text{mm}$, oil return elbows must be located per 5m as shown above; when the height difference between indoor and outdoor unit exceeds five meters, oil reserve elbow and backstop elbow should be set according to the relative position of outdoor unit and indoor unit.

4 Installation of Connecting Pipe

4.4 Determination of the main pipe diameter

Table 4-4 Main Pipe Diameter

Model	Main pipe dimensions			
	Pipeline length (one-way) < 30m		Pipeline length (one-way) ≥ 30m	
	Liquid pipe	Gas pipe	Liquid pipe	Gas pipe
5KW 8KW 10KW 12KW	Φ9.52	Φ15.88	Φ9.52	Φ15.88
14KW 16KW	Φ9.52	Φ15.88	Φ9.52	Φ19.05

4.5 Remove the foreign matter inside the pipe


- 1) Before the refrigerant piping is installed, foreign matter inside the pipe must be removed with high pressure nitrogen.
- 2) The hydronic module shall not be connected during cleaning.
- 3) It is not possible to replace nitrogen with flammable and toxic gases such as refrigerant or oxygen.

4.6 Air tightness test

- 1) After the refrigerant piping is installed and connected to the hydronic module, the nitrogen with pressure of 40kgf/cm² (4.00 MPa) should be injected from the gas side and the liquid side before connecting the pipe between the indoor and the outdoor to the outdoor unit valve. Mark the pressure value and perform 8-hour air tightness test.
- 2) If a pressure drop is found, re-examine the leakage of all interfaces and re-pressurize for 8 hours after completion.
- 3) The outdoor unit cannot be connected when holding pressure.

4.7 Vacuum pumping

- 1) A vacuum pump with a vacuum degree of -0.1 μm or less and gas displacement of above 40 L/min shall be used.
- 2) The outdoor unit does not need to be vacuumed. Do not open the shut-off valve on the gas side or liquid side of the outdoor unit.
- 3) Confirm that the vacuum pump can work below - 0.1 MPa after running for more than 1 hour. If it cannot work below - 0.1 MPa after running for more than 2 hours, it indicates that there is moisture or gas leakage inside and needs to be checked.
- 4) The vacuum pump must be equipped with a check valve.



Attention

- ⌘ Do not mix tools and measuring instruments used for different refrigerants and in direct contact with the refrigerant.
- ⌘ Never remove air with refrigerant gas.
- ⌘ When the vacuum degree cannot reach -0.1 MPa, please consider whether there is a possibility of leakage. Please confirm again if there is any leakage. If there is no leak, run the vacuum pump for one or two more hours.

4 Installation of Connecting Pipe

4.8 Adding amount of refrigerant

The calculation method of the adding amount of refrigerant is shown in the following table, based on the pipe diameter and length of connection liquid-side piping between the outdoor unit and the hydronic module.

Table 4-7 Adding amount of refrigerant

Liquid measuring pipe diameter (mm)	Pipe length (m)	Adding amount of refrigerant (Kg)
Φ9.52	≤5	0
Φ9.52	>5	Add 0.03 Kg for each additional 1m

Note: R32 refrigerant must be charged in liquid form with fixed amount measured by electronic scale.

4.9 Instructions for use of the shut-off valve

- 1) It shall be in OFF state when delivery.
- 2) Open or close the valve with a 6 mm hex wrench, counterclockwise turning for opening and clockwise turning for closing.
- 3) The valve cover must be tightened after the operation.
- 4) The operation of vacuuming and refrigerant injection at the service port must be operated with the special tool R32. Inject the refrigerant at the gas side valve service port, and vacuum at the liquid side and the gas side valve service port.




Figure 4-4 Illustration of the shut-off valve

4.10 Pipe insulation treatment

- 1) Insulate the gas side and liquid side pipes separately.
- 2) Use closed-cell insulation material, with B1 flame retardant rating and 120°C high temperature resistance.
- 3) The outer diameter of the copper tube is ϕ 9.52, the thickness of the insulation cotton is not less than 15 mm; the outer diameter of the copper tube is ϕ 15.88, and the thickness of the insulation cotton is not less than 20 mm.
- 4) The nut joint of the hydronic module must also be insulated.

Attention

- ⌘ Please design the dedicated power supply for the hydronic module and the outdoor unit.
- ⌘ The power supply uses a branch circuit and must be equipped with the leakage protector and manual switch.
- ⌘ Please treat the connecting wires of hydronic module and the refrigerant piping as a same system.
- ⌘ For indoor and outdoor communication wires, please use two-core or three-core shielded twisted pair to reduce interference, instead of using ordinary multi-core cables.
- ⌘ Performed in accordance with the relevant national electrical standards.
- ⌘ The wiring of power supply must be performed by a professional electrician.

5 Electrical wiring

5.1 Hydronic module/Outdoor unit wiring

Table 5-1 Hydronic Module/Outdoor Unit Wiring

Model	Power supply		Power cord (mm ²)	Circuit breaker / fuse (a)	Hydronic module/outdoor unit signal line (mm ²) (weak signal line)
5/8/10/12kW	Single phase	220-240V~50Hz	3×4.0	40/30	3-core shielded cable 3×0.75 (2-core shielded cable 2×0.75)
14/16kW	Three phase	380-415V3N~50Hz	5×4.0	63/45	




Figure 5-1 Wiring and Control




Figure 5-2 Electrical connection mode of single-phase/three-phase outdoor unit

Attention

- ⌘ When using the 2-core shielded wire as the signal wire, connect the shielded mesh to "e" of the terminal block. When using the 3-core shielded wire as the signal wire, the shielded mesh must be grounded.
- ⌘ It is absolutely forbidden to connect the power line (strong power) to the signal wire (weak power) terminal block, otherwise the electric control board will be burned out.

5.2 Power cables for hydronic module

Attention


When the power cord is parallel to the signal wire, place the wires in their respective conduits and leave a suitable line spacing (10A or less: 300 mm, 50A or less: 500 mm).

5 Electrical Wiring

5.3 Main control board dial code setting

Table 5-2 Main Control Board Dial Code

Dialing content	Switch number	Dial code	Set value
Start time setting (14、16kW)	SW3		Start time 12 min
			Start time 3 min
Ability setting	Sw6		14KW
			16KW
	0	5KW	
	1	8KW	
	2	10KW	
	3	12KW	
4	Reserved		
...	...		



5 Electrical Wiring

5.4 Outdoor unit check instructions

Table 5-3 Outdoor unit spot check table

SN		Display content	Remarks
0	Normal display	Current frequency / number of indoor unit	Display the number of units being started
1	1-	Capacity of outdoor units	50/80/100/120/140/160
2	2-	Total capacity of indoor units	
3	3-	Total capacity required after correction of outdoor unit	
4	4-	Operation mode	0: Standby; 2: Cooling; 3: Heating; 4: Forced cooling
5	5-	Actual operating capacity of outdoor unit	
6	6-	Fan status	0-8
7	7-	Tw-in water inlet temperature of heat exchanger	
8	8-	Tw-out water outlet temperature of heat exchanger	
9	9-	T1 hydronic module outlet temperature	
10	10-	T3 condenser temperature of outdoor unit	
11	11-	T4 ambient temperature	
12	12-	T5 exhaust temperature	
13	13-	Opening of electronic expansion valve	50/80/100/120:Actual value = Check display value × 4;140/160:Actual value = Check display value × 8
14	14-	High pressure	
15	15-	Primary current	
16	16-	Secondary current	
17	17-	Primary voltage	
18	18-	Secondary voltage	
19	19-	Last failure or protection code	No protection or fault display ---
20	20-	Control parameter	For developers only
21	21-	Control parameter	For developers only
22	22-	---	End of check

5 Electrical Wiring

Table 5-4 Outdoor unit fault codes

Display content	Failure or protection definition	Remarks
E1	Three-phase supply phase-sequence fault	
E2	Communication failure between indoor unit and outdoor unit	Communication interrupted for 2mins or more between ODU and IDU
E4	Ambient temperature sensor failure	
E6	Condenser temperature sensor failure	
E9	AC over voltage / under voltage protection	
E10	EEPROM failure	
H0	Communication failure between the main control chip and the module board	
H1	Communication failure between the main control chip and the communication chip	
H4	Display P6 protection for 3 times within 30 minutes	It can only be restored by repowering on the unit
H5	Display P2 protection for 3 times within 30 minutes	It can only be restored by repowering on the unit
H6	Display P4 protection for 3 times within 100 minutes	It can only be restored by repowering on the unit
H9	Display P9 protection for 2 times within 10 minutes	It can only be restored by repowering on the unit
H8	High pressure sensor failure	Exhaust pressure $P_c < 0.3\text{MPa}$
H10	Display P3 or P14 protection for 3 times within 60 minutes	It can only be restored by repowering on the unit
P1	High pressure protection (high voltage switch)	
P2	Low voltage protection	3 times P2 protection appears within 30 minutes and then reported H5
P3	Primary current overcurrent protection	
P4	Exhaust temperature is too high protection	3 times P4 protection appears within 100 minutes and then reported H6
P5	T3 high temperature protection	
P6	Module protection	3 times P6 protection appears within 30 minutes and then reported H4
P9	DC fan failure	2 times P9 protection appears within 10 minutes and then reported H9
P10	Typhoon protection	
P12	During heating operation the fan is in fault state in the area A for 5 minutes.	
P14	Secondary current overcurrent protection	
P15	High pressure protection (high pressure sensor)	
L0	DC compressor module failure	
L1	DC bus low voltage protection	
L2	DC bus high voltage protection	
L4	MCE fault / synchronization / closed loop	
L5	Zero speed protection	
L7	Phase sequence error protection	
L8	Protection for speed change $>15\text{Hz}$ at the previous and last moments	
L9	Protection for set speed and actual running speed difference $>15\text{ Hz}$	

6 Test run

6.1 Inspection before commissioning

- 1) Check and confirm that the refrigerant pipes and communication wires for the hydronic module and the outdoor unit are connected to the same refrigeration system. Otherwise, an operational failure will occur.
- 2) The power supply voltage is within $\pm 10\%$ of the rated voltage.
- 3) Check and confirm that the power cable and control cable are connected correctly.
- 4) Before powering up, check and confirm that there is no short circuit in each line.
- 5) Check whether all units have passed the 24-hour nitrogen pressure maintaining test (40 kgf/cm^2).
- 6) Check and confirm that the system to be commissioned has been vacuum dried and filled with refrigerant as required.

6.2 Preparation before commissioning

- 1) Calculate the adding amount of refrigerant to be added to each unit according to the length of the liquid pipe on site.
- 2) Prepare the required refrigerant.
- 3) Prepare the system plan, system piping diagram and control circuit diagram.
- 4) Turn on the outdoor unit power switch in advance to ensure that it is turned on for more than 3 hours to heat the compressor oil.
- 6) Check if the power phase sequence of the outdoor unit is correct.
- 7) Check that all the DIP switches of the outdoor unit and hydronic module have been set according to the product technical requirements.

6.3 Hand over to the customer

- 1) Be sure to give the "Installation Manual" of the outdoor unit to the customer.
- 2) Explain the contents of the "Operation and Installation Manual" to the customer in detail.

Appendix 1: Names and contents of hazardous substances in the product

Part Name						
	Lead (Pb)	Mercury (Hg)	Cadmium (Cd)	Hexavalent chromium (Cr (VI))	Polybrominated biphenyl (PBB)	Polybrominated diphenyl ether (PBDE)
Compressor and accessories	×	○	×	○	○	○
Heat exchanger	○	○	○	○	○	○
Pipe fittings and valves	×	○	○	○	○	○
Refrigerant	○	○	○	○	○	○
Motor	×	○	×	○	○	○
Control box and electrical components	×	○	×	○	○	○
Power cords and cables	×	○	○	○	○	○
Fasteners such as screws and gaskets	×	○	○	○	○	○
Rubber parts	○	○	○	○	○	○
Other metal parts	○	○	○	○	○	○
Other plastic parts	○	○	○	○	○	○
Printed parts	○	○	○	○	○	○
Foam pieces	○	○	○	○	○	○
Insulated cotton	○	○	○	○	○	○

The sheet is prepared in accordance with the specification of SJ/T 11364.

■ : It indicates that the content of this hazardous substance in all homogeneous materials of this part is below the limit specified by GB/T 26572.

× : It indicates that the content of the hazardous substance in at least one of the homogeneous materials of the part exceeds the limit specified by GB/T 26572. However, it is temporarily impossible to realize that the product parts are completely free from the above-mentioned hazardous substances under the existing technical conditions. The above-mentioned harmful substances will be gradually reduced with the progress of alternative technologies.

Applicable Model:

5KW
8KW
10KW
12KW
14KW
16KW



1. Aparat će biti instaliran u skladu sa nacionalnim propisima o ožičenju.
2. Ovaj uređaj je namenjen za upotrebu od strane stručnih ili obučениh korisnika u prodavnicama, u lakoj industriji i na farmama, ili za komercijalnu upotrebu od strane laika.
3. Ovaj uređaj nije namenjen za upotrebu od strane osoba (uključujući decu) sa smanjenim fizičkim, čulnim ili mentalnim sposobnostima, ili nedostatkom iskustva i znanja, osim ako im je dat nadzor ili uputstva o upotrebi uređaja od strane osobe odgovorne za njihovu sigurnost.
4. Decu treba nadzirati kako bi se osiguralo da se ne igraju sa uređajem.
5. Ovaj uređaj mogu koristiti deca uzrasta od 8 godina ili više i osobe sa smanjenim fizičkim, senzornim ili mentalnim sposobnostima ili nedostatkom iskustva i znanja ako su pod nadzorom ili instrukcije u vezi sa upotrebom uređaja na bezbedan način i razumeju opasnosti koje su uključene.
6. Deca ne smeju da vrše čišćenje i korisničko održavanje bez nadzora.
7. Isključite izvor napajanja pre servisiranja ili zamene delova.
8. Upozorenje: pre dobijanja pristupa terminalima, sva strujna kola moraju biti isključena.

Primenljiv modeli:

5KW
8KW
10KW
12KW
14KW
16KW



9. Isključite napajanje pre čišćenja i održavanja.
10. Ako je kabl za napajanje oštećen, mora ga zameniti proizvođač, njegov serviser ili slično kvalifikovana osoba kako bi se izbegla opasnost.
11. Prekidač za sve polove sa razmakom kontakata od najmanje 3 mm na svim polovima treba da bude povezan u fiksno ožičenje.
12. Aparat se ne sme postavljati u veš.
13. F-gas , Oprema sadrži fluorisani gas staklene bašte R32, Potencijal globalnog zagrevanja (GWP): 677

	Pravilno odlaganje ovog proizvoda
	<p>Ova oznaka ukazuje da se ovaj proizvod ne sme odlagati sa drugim kućnim otpadom širom EU. Da biste sprečili moguću štetu po životnu sredinu ili ljudsko zdravlje usled nekontrolisanog odlaganja otpada, odgovorno ga reciklirajte kako biste promovisali održivu ponovnu upotrebu materijalnih resursa. Da biste vratili svoj polovni uređaj, koristite sisteme za vraćanje i prikupljanje ili kontaktirajte prodavca kod koga je proizvod kupljen. Oni mogu odneti ovaj proizvod za recikliranje bezbedno po životnu sredinu.</p>

	spoljna temperatura	unutrašnja temperatura
rad režima hlađenja	-5~46°C	-25~40°C
rad režima grejanja	-28~43°C	-25~40°C
DHW režim rada	-28~43°C	-25~40°C

1 Mere bezbednosti



Upozorenje

Ovaj klima uređaj je udoban klima uređaj. Nemojte ga koristiti na posebnim mestima za skladištenje predmeta kao što su

kompjuteri, precizni instrumenti, hrana, biljke, životinje ili umetnički predmeti.

Poverite dileru ili profesionalcu da instalira. Instalater mora imati relevantno stručno znanje. Nemojte sami instalirati, nepravilna instalacija će uzrokovati požar, strujni udar, povrede, curenje vode i druge nezgode.

—Kada instalirate u maloj prostoriji, preduzmite odgovarajuće mere kako biste osigurali da koncentracija curenja rashladnog sredstva u prostoriji ne dođe do premašiti kritični nivo. Za konkretne mere konsultujte svog prodavca.

— Pridržavajte se propisa lokalnih elektroprivrednih preduzeća kada povezujete kablove za napajanje. Prema zakonu, žica za uzemljenje mora biti dobro povezan. Ako žica za uzemljenje nije pravilno povezana, to može izazvati strujni udar.

— Kada klima-uređaj treba da se premesti ili ponovo instalira, poverite rad prodavcu ili profesionalcu. Nepravilna instalacija će dovesti do požara, strujnog udara, povreda, curenja vode i drugih nezgoda.

— Nikada ga ne menjajte ili popravljajte sami. Nepravilna popravka može dovesti do požara, strujnog udara, povreda, curenja vode, itd., i mora ih popraviti prodavac ili profesionalac.



Pažnja

Uverite se da drenažni jarak može glatko da se odvodi.

Proverite da li je prekidač za zaštitu od curenja instaliran. Prekidač za zaštitu od curenja uzemljenja mora biti instaliran. Ako nije instaliran, to može uzrokovati strujni udar.

Ne postavljajte na mesto gde lako propuštaju zapaljivi gasovi. U slučaju curenja zapaljivog gasa, može izazvati požar ako se zaglavi oko unutrašnje jedinice.

Uverite se da su osnova za ugradnju i podizanje čvrsti i pouzdani. Ako temelj i podizanje nisu dovoljno čvrsti, može pasti i izazvati nesreću.

Pravilno povežite kablove. Ako kablovi nisu pravilno povezani, električni delovi se mogu oštetiti.

Izlaganje jedinice vodi ili drugoj vlazi pre instalacije može dovesti do kratkog spoja električnih komponenti. Ne čuvajte ga na vlažnom mestu podrum ili ga izložiti kiši ili vodi.

Ako rashladno sredstvo curi tokom ugradnje, odmah proventrite prostoriju. Ako rashladni gas iscuri i dođe u kontakt sa požara, može proizvesti otrovne gasove.

Nakon što je instalacija završena, proverite i potvrdite da rashladno sredstvo nije curilo.

Ako rashladni gas uđe u prostoriju i dođe u kontakt sa izvorom vatre kao što je grejač, šporet ili šporet za pirinač, može proizvesti otrov gasovi.

Obavezno instalirajte uređaj za zaštitu od groma u skladu sa nacionalnim zakonima i propisima, inače mašina može biti oštećena gromom

2 Građevinski kontrolni punktovi

2.1 Dolazak robe (AOG) i revizija van kutije (OOBA)

- 1) 1) Nakon prijema mašine, proverite da li ima oštećenja prilikom transporta. Ako se nađe oštećenje na površini ili unutra, to treba odmah pismeno prijaviti transportnoj kompaniji.
- 2) Nakon prijema mašine, proverite da li su model, specifikacija i količina opreme u skladu sa ugovorom.
- 3) Prilikom raspakivanja čuvajte uputstva za upotrebu i proverite pribor.

2.2 Cevi za rashladno sredstvo

- 1) 1) Cevi za rashladno sredstvo treba da koriste cevovod sa određenim prečnikom i debljinom zida.
- 2) Kada je bakarna cev zavarena, mora se napuniti azotom. Pre zavarivanja, napuni se sa 0,2 kgf / cm² azota. Nakon što je zavarivanje završeno, sačekajte da se bakarna cev potpuno ohladi i zaustavite dovod azota.
- 3) Cevi za rashladno sredstvo moraju biti izolovane.
- 4) Nakon što je cev za rashladno sredstvo instaliran, unutrašnja jedinica se ne može uključiti dok se ne izvrši test hermetičnosti i usisavanje.

2.3 Ispitivanje nepropusnosti vazduha

Nakon ugradnje cevovoda za rashladno sredstvo, potrebno je ubrizgati azot pod pritiskom od 40 kgf/cm² (4,0MPa) sa strane gasa i strane tečnosti za jednocasovni test nepropusnosti.

2.4 Vakuumiranje

Nakon ispitivanja nepropusnosti vazduha, vakuumska obrada mora da se izvrši istovremeno sa obe strane gasa i tečnosti (vakuumska obrada treba da dostigne -0,1 MP a).

2.5 Dodavanje rashladnog sredstva

- 1) Izračunajte količinu dodanog rashladnog sredstva na osnovu prečnika cevi i dužine (puna dužina) cevovoda na strani tečnosti između spoljašnje jedinice i hidromodula.

2.6 Električne instalacije

- 1) 1) Molimo odaberite kapacitet napajanja i prečnik žice prema uputstvu za dizajn. Kabl za napajanje klima uređaja je deblji od kabla za napajanje opšteg motora.
- 2) Da biste sprečili kvar klima uređaja, pazite da kablovi za napajanje (220v) ne budu isprepleteni i zapetljani sa komunikacionim kablom unutrašnje i spoljašnje jedinice (niskonaponsko ožičenje).
- 3) Nakon izvođenja testa hermetičnosti i vakuumskog pumpanja, aktivirajte hidraulični modul.

2.7 Probni rad

Probni rad se može izvršiti tek nakon najmanje 3 sata prethodnog zagrevanja, inače će sistem biti oštećen.

3 Instalacija spoljne jedinice



Upozorenje


- ⌘ Instalirajte klima uređaj na čvrsto mesto gde se jedinica može podržati. IA—ako snaga nije dovoljna, jedinica može pasti i izazvati telesne povrede.
- ⌘ Izvršite specifične radove na instalaciji da biste sprečili jake vetrove ili zemljotrese. I—nepotpuna instalacija može izazvati nesreću zbog pada jedinice.

3.1 Izbor lokacije za instalaciju

- 1) 1) Obezbedite dovoljno prostora za instalaciju i održavanje.
- 2) Mesto treba da obezbedi da ulaz i izlaz vazduha budu neometani i da ne utiče jak vetar.
- 3) Suvo i provetreno mesto.
- 4) Noseća površina treba da bude ravna i da izdrži težinu spoljašnje jedinice, tako da se spoljna jedinica može postaviti horizontalno bez veće buke i vibracija.
- 5) Radna buka i izduvni vazduh ne smeju uticati na susede.
- 6) Nema curenja zapaljivog gasa.
- 7) Jednostavna instalacija priključne cevi i električne veze.


3.2 Dimenzije spoljne jedinice (jedinica: mm)

- 1) 5KW, 8KW



Slika 3-1 Dimenzije spoljne jedinice


- 2) 10KW, 12KW



Slika 3-2 Dimenzije spoljne jedinice

3 Instalacija spoljne jedinice

3) 14KW, 16KW



Slika 3-3 Dimenzije spoljne jedinice

3 Instalacija spoljne jedinice


3.3 Podizanje spoljne jedinice

1) Čvrsta i pravilna osnova ima sledeće efekte:

- ① Spoljna jedinica neće potonuti.
- ② Spoljna jedinica ne stvara abnormalnu buku koju izaziva temelj.

2) Vrste temelja

- ① Temelj čelične konstrukcije.
- ② Betonski temelj (pogledajte sledeću sliku).



Slika 3-3 Prostor za ugradnju i održavanje spoljne jedinice

Jedinica: mm

—Molimo da poverite dileru ili profesionalcu da instalira. Instalater mora imati relevantno stručno znanje. Ako je Pogrešno instalirani sami, može izazvati požar, strujni udar, povrede, curenje vode i tako dalje.

—Kada instalirate u maloj prostoriji, obezbedite odgovarajuće mere kako biste osigurali da koncentracija rashladnog sredstva curi u prostoriji ne prelazi kritični nivo. Za konkretne mere konsultujte svog prodavca.

—Pridržavajte se propisa lokalnih elektroprivrednih preduzeća prilikom povezivanja na struju. Prema zakonu, žica za uzemljenje mora biti dobro povezana. Ako žica za uzemljenje nije pravilno povezana, to može izazvati strujni udar.

—Kada klima-uređaj treba da se premesti ili ponovo instalira, poverite rad prodavcu ili profesionalcu.

Nepravilna instalacija će dovesti do požara, strujnog udara, povreda, curenja vode i drugih nezgoda.


—Nikada ga ne menjajte ili popravljajte sami. Nepravilna popravka može dovesti do požara, strujnog udara, povreda, curenja vode, itd., i mora ih popraviti prodavac ili profesionalac.

4 Montaža priključne cevi

4.1 Cevi za rashladno sredstvo

1) Širenje cevi


Isecite cev rezačem za cevi, a raširite je ekspanderom cevi.



Slika 4-1 Sečenje priključne cevi


Tabela 4-1 Veličina priključne cevi na širenje

Spoljni prečnik (mm)	A(mm)	
	MAX	MIN
Φ9.5	12.4	12.0
Φ15.9	19.0	18.6



2) Matica za pričvršćivanje

Poravnajte spojnu cev, zategnite maticu rukom, a zatim zategnite ključem.



Slika 4-2 Zatezanje

Tabela 4-2 Moment zatezanja


Veličina cevi (mm)	Moment zatezanja (N•m)
Φ9.5	32.7~39.9(333~407 kgf•cm)
Φ15.9	61.8~75.4(630~770 kgf•cm)

Pažnja

Da bi se sprečila oksidacija unutar bakarne cevi tokom zavarivanja bakarnih cevi, mora se izvršiti punjenje azotom. U suprotnom će vaga blokirati rashladni sistem!

Kada se navrtka zategne, prevelika sila će slomiti otvor zvona, a premala sila će izazvati curenje. Molimo vas pogledajte moment zatezanja u gornjoj tabeli da zategnete maticu!

4.2 Šema povezivanja hidromodula i spoljašnje jedinice



Slika 4-3

4 Installation of Connecting Pipe

4.3 Dodatna cev u cevovodu

Zbog različitih položaja ugradnje toplotne pumpe, potrebna dodatna cev može biti duga ili kratka, kako bi se izbeglo da preduga cev za rashladno sredstvo utiče na kapacitet jedinice, molimo odaberite razumnu dužinu cevi prema tabeli ispod, pokušajte da izaberete lokaciju kratkog cev za instalaciju.


1. Maksimalna dozvoljena radna udaljenost od cevi

Ocenjeno hlađenje Value	<6.5kW	6.5~10. 5kW	≥10. 5kW
A Dužina cevovoda (jednosmerno)	Maksimalna dužina 15m	Maksimalna dužina 20m	Maksimalna dužina 50m
B Visinska razlika (jednosmerno)	Maksimalna dužina 8m	Maksimalna dužina 10m	Maksimalna dužina 20m
C Količina krivina cevovoda	Do 10	Do 10	Do 15

Napomena: Pod uslovom da je zagarantovano 80% kapaciteta, u gore navedenim parametrima, gubitak kapaciteta hlađenja i povratno ulje je u potpunosti uzet u obzir.

2. Upotreba kolena za povrat ulja

Kada je visinska razlika između unutrašnje i spoljašnje jedinice veća od 5 m, da bi se olakšao povratak ulja iz kompresora, mora se koristiti koleno za povrat ulja. Nakon rada na lokaciji, mogu se pozvati na sledeće tipične metode instalacije (pogledajte sliku ispod).



Napomena: Radijus kolena povratnog ulja $R \leq 100\text{mm}$, kolena povrata ulja moraju biti postavljena na 5m kao što je prikazano gore; kada visinska razlika između unutrašnje i spoljašnje jedinice prelazi pet metara, koleno rezervnog ulja i koleno za zaustavljanje nazad treba da se podese prema relativnom položaju spoljašnje i unutrašnje jedinice.

4 Montaža priključne cevi

4.4 Određivanje prečnika glavne cevi

Tabela 4-4 Prečnik glavne cevi

Model	Glavne dimenzije cevi			
	Dužina cevovoda (jednosmerno) < 30m		Dužina cevovoda (jednosmerno) ≥ 30m	
	Tečna cev	Gasna cev	Tečna cev	Gasna cev
5KW 8KW 10KW 12KW	Φ9.52	Φ15.88	Φ9.52	Φ15.88
14KW 16KW	Φ9.52	Φ15.88	Φ9.52	Φ19.05

4.5 Uklonite stranu materiju unutar cevi


- 1) Pre postavljanja cevi za rashladno sredstvo, strane materije unutar cevi moraju biti uklonjene azotom pod visokim pritiskom.
- 2) Hidro modul se ne sme spajati tokom čišćenja.
- 3) Nije moguće zameniti azot zapaljivim i toksičnim gasovima kao što su rashladno sredstvo ili kiseonik.

4.6 Ispitivanje nepropusnosti vazduha

- 1) Nakon što je cev za rashladno sredstvo instaliran i spojen na hidraulični modul, azot sa pritiskom od 40 kgf/cm² (4,00 MPa) treba da se ubrizgava sa strane gasa i strane tečnosti pre povezivanja cevi između unutrašnjeg i spoljašnjeg na ventil spoljne jedinice. Označite vrednost pritiska i izvršite 8-časovni test nepropusnosti vazduha.
- 2) Ako se pronade pad pritiska, ponovo ispitajte curenje svih interfejsa i ponovo postavite pritisak 8 sati nakon završetka.
- 3) Spoljna jedinica ne može da se poveže kada se drži pritisak.

4.7 Vacuumiranje

- 1) Koristi se vakuum pumpa sa stepenom vakuuma od -0,1 mm ili manje i zapreminom gasa iznad 40 L/min.
- 2) Spoljnu jedinicu nije potrebno usisavati. Ne otvarajte zaporni ventil na strani gasa ili tečnosti spoljne jedinice.
- 3) Potvrdite da vakuum pumpa može da radi ispod -0,1 MPa nakon rada duže od 1 sata. Ako ne može da radi ispod -0,1 MPa nakon rada duže od 2 sata, to znači da unutra postoji vlaga ili curenje gasa i da ga treba proveriti.
- 4) Vakuum pumpa mora biti opremljena nepovratnim ventilom.



Pažnja

- Ne mešajte alate i merne instrumente koji se koriste za različite rashladne fluide u direktnom kontaktu sa rashladnim sredstvom. A—Nikada ne uklanjajte vazduh rashladnim gasom.
- Kada stepen vakuuma ne može da dostigne -0,1 MPa, razmotrite da li postoji mogućnost curenja. Ponovo potvrdite ako postoji curenje. Ako nema curenja, pokrenite vakuum pumpu još jedan ili dva sata.

4 Montaža priključne cevi

4.8 Dodavanje količine rashladnog sredstva

Metoda proračuna dodavanja količine rashladnog sredstva je prikazana u sledećoj tabeli, na osnovu prečnika cevi i dužine priključnog cevovoda na strani tečnosti između spoljašnje jedinice i hidromodula.


Tabela 4-7 Dodavanje količine rashladnog sredstva

Prečnik cevi za merenje tečnosti (mm)	Dužina cevi (m)	Dodavanje količine od refrigerant (Kg)
Φ9.52	≤5	0
Φ9.52	>5	Add 0.03 Kg for each additional 1m

Napomena: Rashladno sredstvo R32 se mora puniti u tečnom obliku sa fiksnom količinom merenom elektronskom vagom.

4.9 Uputstvo za upotrebu zapornog ventila

- 1) Biće u isključenom stanju prilikom isporuke.
- 2) Otvorite ili zatvorite ventil pomoću imbus ključa od 6 mm, okrećući se u smeru suprotnom od kazaljke na satu za otvaranje i u smeru kazaljke na satu za zatvaranje.
- 3) Poklopac ventila mora biti zategnut nakon operacije.
- 4) Operacijom usisavanja i ubrizgavanja rashladnog sredstva na servisnom priključku mora se upravljati specijalnim alatom R32. Ubrizgajte rashladno sredstvo u servisni priključak ventila na strani gasa i usisajte na strani tečnosti i servisni otvor ventila na strani gasa.



Slika 4-4 Ilustracija zapornog ventila

4.10 Obrada izolacije cevi

- 1) Odvojeno izolujte cevi za gas i stranu tečnosti.
- 2) Koristite izolacioni materijal zatvorenih ćelija, sa B1 ocenom otpornosti na plamen i otpornošću na visoke temperature od 120°C.
 - 3) Spoljni prečnik bakarne cevi je ϕ 9,52, debljina izolacionog pamuka nije manja od 15 mm; spoljašnji prečnik bakarne cevi je ϕ 15.88, a debljina izolacije nije manja od 20 mm.
 - 4) Spoj matice hidromodula takođe mora biti izolovan.



Pažnja


- Molimo dizajnirajte namensko napajanje za hidraulični modul i spoljnu jedinicu.
- Napajanje koristi strujni krug i mora biti opremljeno zaštitnikom od curenja i ručnim prekidačem.
- Molimo tretirajte priključne žice hidrauličkog modula i cevi za rashladno sredstvo kao isti sistem.
- Za unutrašnje i spoljašnje komunikacione žice, koristite dvožilni ili trožilni zaštićeni upredeni par da biste smanjili smetnje, umesto da se koriste obični višežilni kablovi.
- Izvedeno u skladu sa relevantnim nacionalnim električnim standardima.
- Ožičenje napajanja mora da obavi profesionalni električar.

5 Električne instalacije


5.1 Hidro modul/ožičenje spoljašnje jedinice

Tabela 5-1 Hidro modul/ožičenje spoljašnje jedinice

Model	Napajanje		Kabl za napajanje (mm ²)	Prekidač / fuse (a)	Signalni vod hidromodula/spoljne jedinice (mm2) (slaba signalna linija)
5/8/10/12kW	Jedna faza	220-240V~50Hz	3×4.0	40/30	3-žilni oklopljeni kabl 3×0,75 (2-žilni oklopljeni kabl 2×0,75)
14/16kW	Tri faze	380-415V3N~50Hz	5×4.0	63/45	



Slika 5-1 Ožičenje i kontrola



Slika 5-2 Način električnog povezivanja jednofazne/trofazne spoljašnje jedinice

Pažnja

Kada koristite 2-žilnu zaštićenu žicu kao signalnu žicu, povežite zaštićenu mrežu na "e" terminalnog bloka. Kada koristeći 3-žilnu zaštićenu žicu kao signalnu žicu, oklopljena mreža mora biti uzemljena. Apsolutno je zabranjeno spajanje strujne linije (jaka snaga) na terminalni blok signalne žice (slaba snaga), inače će električna kontrolna ploča izgoreti.

5.2 Kablovi za napajanje za hidromodula

Pažnja


Kada je kabl za napajanje paralelan sa signalnom žicom, postavite žice u odgovarajuće vodove i ostavite odgovarajući razmak između linija (10A ili manje: 300 mm, 50A ili manje: 500 mm).

5 Električne instalacije

5.3 Podešavanje koda za biranje glavne kontrolne ploče

Tabela 5-2 Pozivni kod glavne kontrolne table

Biranje sadržaja	Broj prekidača	Podešavanje koda	Podešena vrednost
Podešavanje vremena početka (14, 16kW)	SW3		Početno vreme 2 min
			Početno vreme 3 min
Podešavanje sposobnosti	Sw6		14KW
			16KW
	0	5KW	
	1	8KW	
	2	10KW	
	3	12KW	
4	Rezervisano		
...	...		



5 Električne instalacije

5.4 Uputstva za proveru spoljne jedinice

Tabela 5-3 Tabela za kontrolu na licu mesta spoljne jedinice

SN		Prikaži sadržaj	Primedbe
0	Normalan prikaz	Trenutna frekvencija / broj unutrašnje jedinice	Prikažite broj jedinica koje se pokreću
1	1-	Kapacitet spoljnih jedinica	50/80/100/120/140/160
2	2-	Ukupan kapacitet unutrašnjih jedinica	
3	3-	Ukupan potreban kapacitet nakon korekcije spoljne jedinice	
4	4-	Režim rada	0: U pripravnosti ; 2: Hlađenje; 3: Grejanje; 4: Prinudno hlađenje
5	5-	Stvarni radni kapacitet spoljne jedinice	
6	6-	Status ventilatora	0-8
7	7-	Tv-in ulazna temperatura vode u izmenjivač toplote	
8	8-	Tv-out izlazna temperatura izmenjivača toplote	
9	9-	T1 izlazna temperatura hidromodula	
10	10-	T3 temperatura kondenzatora spoljne jedinice	
11	11-	T4 temperatura okoline	
12	12-	T5 temperatura izduvnih gasova	
13	13-	Otvaranje elektronskog ekspanzionog ventila	50/80/100/120: Stvarna vrednost = Proverite vrednost prikaza A— 4; 140/160: Stvarna vrednost = Proverite vrednost prikaza A— 8
14	14-	Visok pritiska	
15	15-	Primarna struja	
16	16-	Sekundarna struja	
17	17-	Primarni napon	
18	18-	Sekundarni napon	
19	19-	Poslednji kvar ili zaštitni kod	Nema zaštite ili prikaza greške ---
20	20-	Kontrolni parametar	Samo za programere
21	21-	Kontrolni parametar	Samo za programere
22	22-	---	Kraj provere

5 Električne instalacije

Tabela 5-4 Kodovi grešaka spoljne jedinice

Prikaži sadržaj	Definicija kvara ili zaštite	Primedbe
E1	Trofazno napajanje kvar faznog niza	
E2	Greška u komunikaciji između unutrašnje i spoljašnje jedinice	Komunikacija je prekinuta na 2 minuta ili više između ODU i IDU
E4	Kvar senzora ambijentalne temperature	
E6	Kvar senzora temperature kondenzatora	
E9	Zaštita od prenapona / podnapona naizmjenične struje	
E10	EEPROM kvar	
H0	Greška u komunikaciji između glavnog kontrolnog čipa i ploče modula	
H1	Greška u komunikaciji između glavnog kontrolnog čipa i komunikacionog čipa	
H4	Prikažite P6 zaštitu 3 puta u roku od 30 minuta	Može se vratiti samo ponovnim napajanjem na jedinici
H5	Prikažite P2 zaštitu 3 puta u roku od 30 minuta	Može se vratiti samo ponovnim napajanjem na jedinici
H6	Prikažite P4 zaštitu 3 puta u roku od 100 minuta	Može se vratiti samo ponovnim napajanjem na jedinici
H9	Prikažite P9 zaštitu 2 puta u roku od 10 minuta	Može se vratiti samo ponovnim napajanjem na jedinici
H8	Otkazivanje senzora visokog pritiska	Izduvni pritisak $P_c < 0,3 \text{MPa}$
H10	Prikažite P3 ili P14 zaštitu 3 puta u roku od 60 minuta	Može se vratiti samo ponovnim napajanjem na jedinici
P1	Zaštita od visokog pritiska (visokonaponski prekidač)	
P2	Zaštita od niskog napona	3 puta P2 zaštita se pojavljuje u roku od 30 minuta, a zatim se javlja H5
P3	Primarna strujna prekostrujna zaštita	
P4	Temperatura izduvnih gasova je previsoka zaštita	3 puta P4 zaštita se pojavljuje u roku od 100 minuta, a zatim se javlja H6
P5	T3 zaštita od visoke temperature	
P6	Zaštita modula	3 puta P6 zaštita se pojavljuje u roku od 30 minuta, a zatim se javlja H4
P9	Kvar DC ventilatora	2 puta P9 zaštita se pojavljuje u roku od 10 minuta, a zatim se javlja H9
P10	Zaštita od vetra	
P12	Tokom rada grejanja ventilator je u stanju greške u oblasti A f ili 5 minuta.	
P14	Sekundarna strujna prekostrujna zaštita	
P15	Zaštita od visokog pritiska (senzor visokog pritiska)	
L0	Kvar modula DC kompresora	
L1	DC bus niskonaponska zaštita	
L2	DC bus visokonaponska zaštita	
L4	MCE greška / sinhronizacija / zatvorena petlja	
L5	Zaštita od nulte brzine	
L7	Zaštita od greške redosleda faza	
L8	Zaštita od promene brzine $> 15 \text{ Hz}$ u prethodnim i poslednjim trenucima	
L9	Zaštita za podešenu brzinu i stvarnu razliku brzine rada $> 15 \text{ Hz}$	

6 Probni rad

6.1 Pregled pre puštanja u rad

- 1) Proverite i potvrdite da su cevi za rashladno sredstvo i komunikacione žice za hidraulični modul i spoljnu jedinicu povezane na isti sistem za hlađenje. U suprotnom će doći do kvara u radu.
- 2) Napon napajanja je unutar $\pm 10\%$ nazivnog napona.
- 3) Proverite i potvrdite da su kabl za napajanje i kontrolni kabl ispravno povezani.
- 4) Pre uključivanja, proverite i potvrdite da nema kratkog spoja u svakoj liniji.
- 5) Proverite da li su sve jedinice prošle 24-časovni test održavanja pritiska azota (40 kgf/cm²).
- 6) Proverite i potvrdite da je sistem koji treba da bude pušten u rad vakuumski osušen i napunjen rashladnim sredstvom po potrebi.

6.2 Priprema pre puštanja u rad

- 1) Izračunajte količinu rashladnog sredstva koja se dodaje svakoj jedinici prema dužini cevi za tečnost na licu mesta.
- 2) Pripremite potrebno rashladno sredstvo.
- 3) Pripremite plan sistema, dijagram cevovoda sistema i dijagram upravljačkog kola.
- 4) Uključite prekidač za napajanje spoljne jedinice unapred kako biste bili sigurni da je uključena duže od 3 sata da zagreje ulje kompresora.
- 6) Proverite da li je redosled faza napajanja spoljašnje jedinice ispravan.
- 7) Proverite da li su svi DIP prekidači spoljašnje jedinice i hidrauličkog modula podešeni u skladu sa tehničkim zahtevima proizvođača.

6.3 Predavanje kupcu

- 1) Obavezno dajte „Priručnik za instalaciju“ spoljne jedinice kupcu.
- 2) Detaljno objasniti korisniku sadržaj „Uputstva za upotrebu i instalaciju“.

Dodatak 1: Nazivi i sadržaj opasnih materija u proizvodu


naziv dela						
	Olovo (Pb)	Živa (Hg)	Kadmijum (Cd)	Hexavalent hrom (Cr (VI))	Šestovalentni biphenyl (PBB)	Polibromovani difenil etar (PBDE)
Kompresor i pribor	×	○	×	○	○	○
Izmjenjivač toplote	○	○	○	○	○	○
Cevni spojevi i ventili	×	○	○	○	○	○
Rashladno sredstvo	○	○	○	○	○	○
Motor	×	○	×	○	○	○
Kontrolna kutija i električne komponente	×	○	×	○	○	○
Kablovi i kablovi za napajanje	×	○	○	○	○	○
Pričvršćivači kao što su zavrtnji i zaptivke	×	○	○	○	○	○
Gumeni delovi	○	○	○	○	○	○
Ostali metalni delovi	○	○	○	○	○	○
Ostali plastični delovi	○	○	○	○	○	○
Štampani delovi	○	○	○	○	○	○
Komadi od pene	○	○	○	○	○	○
Izolacioni materijal	○	○	○	○	○	○

List je pripremljen u skladu sa specifikacijom SJ/T 11364.

■ To ukazuje da je sadržaj ove opasne supstance u svim homogenim materijalima ovog dela ispod granice određene GB/T 26572.

× To ukazuje da je sadržaj opasne supstance u najmanje jednom od homogeni materijali dela prelaze granicu propisanu GB/T 26572. Međutim, privremeno je nemoguće shvatiti da su delovi proizvoda potpuno oslobođeni gore navedenih opasnih materija prema postojećim tehničkim uslovima. Pomenute štetne materije postepeno će se smanjivati napretkom alternativnih tehnologija.





www.tesla.info