

TESLA

A-THERMAL MONO ATW
HEAT PUMP UNIT

INSTALLATION
AND OPERATION
MANUAL


ENG SRB

Ver. 2023


- For your convenience, please read this statement carefully, in accordance with the specification steps.
- Please safely keeping this manual to inspection.

Note:

All the illustrations in this manual are for explanation purpose only. Your air conditioner may be slightly different. The actual shape shall prevail. They are subject to change without notice for future improvement.




4/6kW





8/10/12/14/16kW

Internal layout: 12~16kW(1-phase) for example



Please remove hollow plate after installation



Please remove the washer at the compressor foot pad
(Washer total quantity: 1)

12/14/16kW

NOTE

The picture and function described in this manual contain the backup heater components.
Pictures in this manual are for reference only, please refer to the actual product.

Unit (kW)	1-phase							3-phase						
	4	6	8	10	12	14	16	8	10	12	14	16		
Capacity of backup heater	3kW(1-phase)							9kW(3-phase)						
	Backup heater (optional)													
The standard unit without backup heater. Backup heater can be integrated in the unit for customized models(4~16kW).														

1. SAFETY PRECAUTIONS

The precautions listed here are divided into the following types. They are quite important, so be sure to follow them carefully. Meanings of DANGER, WARNING, CAUTION and NOTE symbols

INFORMATION

Read these instructions carefully before installation. Keep this manual in a handy for future reference.
Improper installation of equipment or accessories may result in electric shock, short-circuit, leakage, fire or other damage to the equipment. Be sure to only use accessories made by the supplier, which are specifically designed for the equipment and make sure to get installation done by a professional.
All the activities described in this manual must be carried out by a licensed technician. Be sure to wear adequate personal protection equipment such as gloves and safety glasses while installing the unit or carrying out maintenance activities.
Contact your dealer for any further assistance.



**Caution: Risk of fire/
flammable materials**

WARNING	Servicing shall only be performed as recommended by the equipment manufacturer. Maintenance and repair requiring the assistance of other skilled personnel shall be carried out under the supervision of the person competent in the use of flammable refrigerants.
DANGER	Indicates an imminently hazardous situation which if not avoided, will result in death or serious injury.
WARNING	Indicates a potentially hazardous situation which if not avoided, could result in death or serious injury.
CAUTION	Indicates a potentially hazardous situation which if not avoided, may result in minor or moderate injury. It is also used to alert against unsafe practices.
NOTE	Indicates situations that could only result in accidental equipment or property damage.

	WARNING	This symbol shows that this appliance used a flammable refrigerant. If the refrigerant is leaked and exposed to an external ignition source, there is a risk of fire.
	CAUTION	This symbol shows that the operation manual should be read carefully
	CAUTION	This symbol shows that a service personnel should be handling this equipment with reference to the installation manual.
	CAUTION	This symbol shows that information is available such as the operating manual or installation manual.
	CAUTION	This symbol shows that information is available such as the operating manual or installation manual.

DANGER

Before touching electric terminal parts, turn off power switch.
When service panels are removed, live parts can be easily touched by accident.
Never leave the unit unattended during installation or servicing when the service panel is removed.
Do not touch water pipes during and immediately after operation as the pipes may be hot and could burn your hands. To avoid injury, give the piping time to return to normal temperature or be sure to wear protective gloves.
Do not touch any switch with wet fingers. Touching a switch with wet fingers can cause electrical shock. Before touching electrical parts, turn off all applicable power to the unit.

WARNING

Tear apart and throw away plastic packaging bags so that children will not play with them. Children playing with plastic bags face danger of death by suffocation.
Safely dispose of packing materials such as nails and other metal or wood parts that could cause injuries.
Ask your dealer or qualified personnel to perform installation work in accordance with this manual. Do not install the unit yourself. Improper installation could result in water leakage, electric shocks or fire.
Be sure to use only specified accessories and parts for installation work. Failure to use specified parts may result in water leakage, electric shocks, fire, or the unit falling from its mount.

Install the unit on a foundation that can withstand its weight. Insufficient physical strength may cause the equipment to fall and possible injury. Perform specified installation work with full consideration of strong wind, hurricanes, or earthquakes. Improper installation work may result in accidents due to equipment falling.

Make certain that all electrical work is carried out by qualified personnel according to the local laws and regulations and this manual using a separate circuit. Insufficient capacity of the power supply circuit or improper electrical construction may lead to electric shocks or fire.

Be sure to install a ground fault circuit interrupter according to local laws and regulations. Failure to install a ground fault circuit interrupter may cause electric shocks and fire.

Make sure all wiring is secure. Use the specified wires and ensure that terminal connections or wires are protected from water and other adverse external forces. Incomplete connection or affixing may cause a fire.

When wiring the power supply, form the wires so that the front panel can be securely fastened. If the front panel is not in place there could be overheating of the terminals, electric shocks or fire.

After completing the installation work, check to make sure that there is no refrigerant leakage.

Never directly touch any leaking refrigerant as it could cause severe frostbite. Do not touch the refrigerant pipes during and immediately after operation as the refrigerant pipes may be hot or cold, depending on the condition of the refrigerant flowing through the refrigerant piping, compressor and other refrigerant cycle parts. Burns or frostbite are possible if you touch the refrigerant pipes. To avoid injury, give the pipes time to return to normal temperature or, if you must touch them, be sure to wear protective gloves.

Do not touch the internal parts (pump, backup heater, etc.) during and immediately after operation. Touching the internal parts can cause burns. To avoid injury, give the internal parts time to return to normal temperature or, if you must touch them, be sure to wear protective gloves.

CAUTION

Ground the unit.

Grounding resistance should be according to local laws and regulations.

Do not connect the ground wire to gas or water pipes, lightning conductors or telephone ground wires.

Incomplete grounding may cause electric shocks.

- Gas pipes : Fire or an explosion might occur if the gas leaks.

- Water pipes : Hard vinyl tubes are not effective grounds.

- Lightning conductors or telephone ground wires : Electrical threshold may rise abnormally if struck by a lightning bolt.

Install the power wire at least 3 feet (1 meter) away from televisions or radios to prevent interference or noise. (Depending on the radio waves, a distance of 3 feet (1 meter) may not be sufficient to eliminate the noise.)

Do not wash the unit. This may cause electric shocks or fire. The appliance must be installed in accordance with national wiring regulations. If the supply cord is damaged, it must be replaced by the manufacturer, its service agent or similarly qualified persons in order to avoid a hazard. Do not install the unit in the following places:

- Where there is mist of mineral oil, oil spray or vapors. Plastic parts may deteriorate, and cause them to come loose or water to leak.

- Where corrosive gases (such as sulphurous acid gas) are produced. Where corrosion of copper pipes or soldered parts may cause refrigerant to leak.

- Where there is machinery which emits electromagnetic waves. Electromagnetic waves can disturb the control system and cause equipment malfunction.

- Where flammable gases may leak, where carbon fiber or ignitable dust is suspended in the air or where volatile flammables such as paint thinner or gasoline are handled. These types of gases might cause a fire.

- Where the air contains high levels of salt such as near the ocean.

- Where voltage fluctuates a lot, such as in factories.

- In vehicles or vessels.

- Where acidic or alkaline vapors are present.

This appliance can be used by children 8 years old and above and persons with reduced physical, sensory or mental capabilities or lack of experience and knowledge if they are supervised or given instruction on using the unit in a safe manner and understand the hazards involved. Children should not play with the unit. Cleaning and user maintenance should not be done by children without supervision. Children should be supervised to ensure that they do not play with the appliance.

If the supply cord is damaged, it must be replaced by the manufacturer or its service agent or a similarly qualified person.

DISPOSAL: Do not dispose this product as unsorted municipal waste. Collection of such waste separately for special treatment is necessary. Do not dispose of electrical appliances as municipal waste, use separate collection facilities. Contact your local government for information regarding the collection systems available. If electrical appliances are disposed of in landfills or dumps, hazardous substance can leak into the groundwater and get into the food chain, damaging your health and well-being.

The wiring must be performed by professional technicians in accordance with national wiring regulation and this circuit diagram. An all-pole disconnection device which has at least 3mm separation distance in all pole and a residual current device(RCD) with the rating not exceeding 30mA shall be incorporated in the fixed wiring according to the national rule.

Confirm the safety of the installation area (walls, floors, etc.) without hidden dangers such as water, electricity, and gas, before wiring/pipes. Before installation , check whether the user's power supply meets the electrical installation requirements of unit (including reliable grounding , leakage , and wire diameter electrical load, etc.). If the electrical installation requirements of the product are not met, the installation of the product is prohibited until the product is rectified.

When installing multiple air conditioners in a centralized manner, please confirm the load balance of the three-phase power supply, and multiple units are prevented from being assembled into the same phase of the three-phase power supply.

Product installation should be fixed firmly. Take reinforcement measures, when necessary.

NOTE

About Fluorinated Gasses

- This air-conditioning unit contains fluorinated gasses. For specific information on the type of gas and the amount, please refer to the relevant label on the unit itself. Compliance with national gas regulations shall be observed.
- Installation, service, maintenance and repair of this unit must be performed by a certified technician.
- Product uninstallation and recycling must be performed by a certified technician.
- If the system has a leak-detection system installed, it must be checked for leaks at least every 12 months. When the unit is checked for leaks, proper record-keeping of all checks is strongly recommended

2. GENERAL INTRODUCTION


These units are used for both heating and cooling applications and domestic hot water tanks. They can be combined with fan coil units, floor heating applications, low temperature high efficiency radiators, domestic hot water tanks and solar kits, which are all field supplied.

A wired controller is supplied with the unit.

If you choose the built-in backup heater unit, the backup heater can increase the heating capacity during cold outdoor temperature. The backup heater also serves as a backup in case of malfunctioning and for frozen protection of the outside water piping during winter time.

NOTE

- Maximum length of communication wirings between the indoor unit and the controller is 50m.
- Power cords and communication wiring must be laid out separately, they can not be placed in the same conduit. Otherwise, it may lead to electromagnetic interference. Power cords and communication wirings should not come in contact with the refrigerant pipe so as to prevent the high temperature pipe from damaging wirings.
- Communication wirings must use shielded lines.



①Heat pump capacity.


②Required heating capacity (site dependent).

③Additional heating capacity provided by backup heater

Domestic hot water tank (field supply)

A domestic hot water tank(with or without booster heater) can be connected to the unit.

The requirement of the tank is different for different unit and material of heat exchanger.



The booster heater should be installed below the temperature probe

The heat exchanger (coil) should be installed below the temperature probe.

The pipe length between the outdoor unit and tank should be less than 5 meters.

Monobloc unit	4~6kW	8~10k W	12~16kW	
Volume of tank/L	Recommended	100~250	150~300	200~500
Heat exchange area/m ² (Stainless steel coil)	Minimum	1.4	1.4	1.6
Heat exchange area/m ² (Enamel coil)	Minimum	2.0	2.0	2.5

Room thermostat(field supplied)

Room thermostat can be connected to the unit(room thermostat should be kept away from heating source when selecting the installation place).

Solar kit for domestic hot water tank(field supplied)

An optional solar kit can be connected to the unit.


Operation range

Outlet water (Heating mode)	+25 ~ +65 °C	
Outlet water (Cooling mode)	+5 ~ +25 °C	
Domestic hot water	+30 ~ +60 °C	
Ambient temperature	-25 ~ +43 °C	
Water pressure	0.1~0.3 MPa	
Water flow	4 kW	0.40~1.25m ³ h
	6kW	0.40~1.25m ³ h
	8kW	0.70~3.00m ³ h
	10kW	0.70~3.00m ³ h
	12kW	0.70~3.00m ³ h
	14kW	0.70~3.00m ³ h
	16kW	0.70~3.00m ³ h

The unit have a freeze prevention function that uses the heat pump or backup heater (Customized model) to keep the water system safe from freezing in all conditions.


Since a power failure may happen when the unit is unattended, It's suggested to use anti-freezing flow switch in the water system. (Refer to 9.4"Water piping")

In cooling mode, the water flowing temperature (TW02) range in different outdoor temperature(Tao) is listed below:




Operation range by heat pump with possible limitation and protection.

In heating mode, the water flowing temperature (Tw02) range in different outdoor temperature (Tao) is listed below:



If IBH/ANS setting is valid,only iBh/as turns on;
 If IBH/AHS setting is invalid,only heat pump turns on;
 limitation and protection may occur during heat pump operation.
 Operation range by heat pump with possible limitation and protection.
 Heat pump turns off,only IBH/AHS turns on.
 Maximum inlet water temperature line for heat pump operation.

In DHW mode, the water flowing temperature(TW02) range in different outdoor temperature(Tao) is listed below:



If IBH/ANS setting is valid,only iBh/as turns on;
 If IBH/AHS setting is invalid,only heat pump turns on;
 limitation and protection may occur during heat pump operation.
 Operation range by heat pump with possible limitation and protection.
 Heat pump turns off,only IBH/AHS turns on.
 Maximum inlet water temperature line for heat pump operation.

3. ACCESSORIES

3.1 Accessories supplied with the unit

Installation Fittings		
Name	Shape	Quantity
Installation and owner's manual(this book)		1
Operation manual		1
Technical data manual		1
Y-shape filter		1
Wired controller		1
Thermistor for domestic hot water tank		1
Drain hose		2
Energy label		1
Rubber water plug		2
Wire controller communication wire		1
Wire controller communication adapter		1

3.2 Accessories available from supplier

Thermistor for balance tank(Twt-BT)		1
Extension wire for Tbt1		1
Thermistor for Zone 2 flow temp.(Twi-FLH)		1
Extension wire for Twi-FLH		1
Thermistor for solar temp.(Tsolar)		1
Extension wire for Tsolar		1

Thermistor and extension wire for Twt-BT, Twi-FLH, Tsolar can be shared, if these functions are needed at the same time, and 10m in length of the sensor cable please order these thermistors and extension wire additionally.

4. BEFORE INSTALLATION

Before installation

Be sure to confirm the model name and the serial number of the unit.

Handling


Due to relatively large dimensions and heavy weight, the unit should only be handled using lifting tools with slings. The slings can be fitted into foreseen sleeves at the base frame that are made specifically for this purpose.

CAUTION


To avoid injury, do not touch the air inlet or aluminum fins of the unit.

Do not use the grips in the fan grills to avoid damage.

The unit is top heavy! Prevent the unit from falling due to improper inclination during handling.



The position of barycenter for different units can be seen in the picture below



4/6kW

8/10/12/14/16kW

(unit:mm)

Model	A	B	C
4/6kW	300	540	200
8/10kW	340	580	280
12/14/16kW	300	605	245

5. IMPORTANT INFORMATION FOR THE REFRIGERANT

This product has the fluorinated gas, which is forbidden to release to air.

Refrigerant type: R32; Volume of GWP: 675.

GWP=Global Warming Potential

Model	Factory charged refrigerant volume in the unit	
	Refrigerant /kg	Tonnes CO ₂ equivalent
4kW	1.05	0.71
6kW	1.05	0.71
8kW	1.45	0.98
10kW	1.45	0.98
12kW	1.70	1.15
14 kW	1.70	1.15
16 kW	1.70	1.15

CAUTION

Frequency of Refrigerant Leakage Checks

- For unit that contains fluorinated greenhouse gases in quantities of 5 tonnes of CO₂ equivalent or more, but of less than 50 tonnes of CO₂ equivalent, at least every 12 months, or where a leakage detection system is installed, at least every 24 months.
- For unit that contains fluorinated greenhouse gases in quantities of 50 tonnes of CO₂ equivalent or more, but of less than 500 tonnes of CO₂ equivalent, at least every six months, or where a leakage detection system is installed, at least every 12 months.
- For unit that contains fluorinated greenhouse gases in quantities of 500 tonnes of CO₂ equivalent or more, at least every three months, or where a leakage detection system is installed, at least every six months.
- This air-conditioning unit is a hermetically sealed equipment that contains fluorinated greenhouse gases.
- Only certificated person is allowed to do installation, operation and maintenance.

6. INSTALLATION SITE

WARNING

There is flammable refrigerant in the unit and it should be installed in a well-ventilated site. If the unit is installed inside, an additional refrigerant detection device and ventilation equipment must be added in accordance with the standard EN378. Be sure to adopt adequate measures to prevent the unit from being used as a shelter by small animals.

Small animals making contact with electrical parts can cause malfunction, smoke or fire. Please instruct the customer to keep the area around the unit clean.


Select an installation site where the following conditions are satisfied and one that meets with your customer's approval.

- Places that are well-ventilated.
- Places where the unit does not disturb neighbors.
- Safe places which can bear the unit's weight and vibration and where the unit can be installed at an even level.
- Places where there is no possibility of flammable gas or product leak.
- The equipment is not intended for use in a potentially explosive atmosphere.
- Places where servicing space can be well ensured.
- Places where the units' piping and wiring lengths come within the allowable ranges.
- Places where water leaking from the unit cannot cause damage to the location (e.g. in case of a blocked drain pipe).
- Places where rain can be avoided as much as possible.
- Do not install the unit in places often used as a work space. In case of construction work (e.g. grinding etc.) where a lot of dust is created, the unit must be covered.
- Do not place any object or equipment on top of the unit (top plate).
- Do not climb, sit or stand on top of the unit.
- Be sure that sufficient precautions are taken in case of refrigerant leakage according to relevant local laws and regulations.
- Don't install the unit near the sea or where there is corrosion gas.

When installing the unit in a place exposed to strong wind, pay special attention to the following.


Strong winds of 5 m/sec or more blowing against the unit's air outlet causes a short circuit (suction of discharge air), and this may have the following consequences:

- Deterioration of the operational capacity.
- Frequent frost acceleration in heating operation.
- Disruption of operation due to rise of high pressure.
- When a strong wind blows continuously on the front of the unit, the fan can start rotating very fast until it breaks. In normal condition, refer to the figures below for installation of the unit.




Unit	A(mm)
4~6kW	≥300
8~16kW	≥300

In case of strong wind and the wind direction can be foreseen, refer to the figures below for installation of the unit(any one is OK). Turn the air outlet side toward the building's wall, fence or screen.



Unit	B(mm)
4~6kW	≥1000
8~16kW	≥1500

Make sure there is enough room to do the installation.
Set the outlet side at a right angle to the direction of the wind



Prepare a water drainage channel around the foundation, to drain waste water from around the unit.
If water does not easily drain from the unit, mount the unit on a foundation of concrete blocks, etc. (the height of the foundation should be about 100 mm (3.93 in)).
If you install the unit on a frame, please install a waterproof plate (about 100 mm) on the underside of the unit to prevent water from coming in from the low side.
When installing the unit in a place frequently exposed to snow, pay special attention to elevate the foundation as high as possible.
If you install the unit on a building frame, please install a waterproof tray (field supply) (about 100mm, on the underside of the unit) in order to avoid drain water dripping. (See the picture in the right).



6.1 Selecting a location in cold climates

Refer to "Handling" in section "4 Before installation"

NOTE


When operating the unit in cold climates, be sure to follow the instructions described below.

To prevent exposure to wind, install the unit with its suction side facing the wall.

Never install the unit at a site where the suction side may be exposed directly to wind.

To prevent exposure to wind, install a baffle plate on the air discharge side of the unit.

In heavy snowfall areas, it is very important to select an installation site where the snow will not affect the unit. If lateral snowfall is possible, make sure that the heat exchanger coil is not affected by the snow (if necessary construct a lateral canopy).



①Construct a large canopy.

②Construct a pedestal.


Install the unit high enough off the ground to prevent it from being buried in snow.

6.2 Selecting a location in hot climates

As the outdoor temperature is measured via the outdoor unit air thermistor, make sure to install the outdoor unit in the shade or a canopy should be constructed to avoid direct sunlight, so that it is not influenced by the sun's heat, otherwise protection may be possible to the unit.enough off the ground to prevent it from being buried in snow.

7. INSTALLATION PRECAUTIONS


7.1 Dimensions




Model	A	B	C	D	E	F	G	H	I	J
4/6kW	1257	388	320	261	735	261	99	195	766	136
8/10/12/14/16kW	1377	520	421	274	830	274	99	216	934	120

7.2 Installation requirements

Check the strength and level of the installation ground so that the unit may not cause any vibrations or noise during its operation. In accordance with the foundation drawing in the figure, fix the unit securely by means of foundation bolts. (Prepare four sets each of $\Phi 10$ Expansion bolts, nuts and washers which are readily available in the market.) Screw in the foundation bolts until their length is 20 mm from the foundation surface.



7.3 Drain hole position



NOTE


It's necessary to install an electrical heating belt if water can't drain out in cold weather even the big drain hole has opened.

7.4 Servicing space requirements

7.4.1 In case of stacked installation

1) In case obstacles exist in front of the outlet side.


2) In case obstacles exist in front of the air inlet.



Unit	A(mm)
4~6kW	≥1000
8~16kW	≥1500

7.4.2 In case of multiple-row installation (for roof top use, etc.)

In case of installing multiple units in lateral connection per row.




Unit	A(mm)	B1(mm)	B2(mm)	C(mm)
4~6kW	≥2500	≥1000	≥300	≥600
8~16kW	≥3000	≥1500		

8. TYPICAL APPLICATIONS

8.1 Space Heating Only

The room thermostat is used as a switch. When there is a heating request from the room thermostat, the unit operates to achieve the target water temperature set on the Wired controller. When the room temperature reaches the thermostats set temperature, the unit stops. When the heating terminal uses floor heating and Heating radiator at the same time, the two ends of the floor heating and low temperature radiator require different working water temperatures. In order to meet these two different working water temperatures at the same time, it is necessary to install a mixing valve and a mixing water pump at the inlet and outlet of the floor heating , The outlet water temperature of the unit is set to the water temperature required by the heating radiator, and the water mixing valve and water mixing pump are set to reduce the inlet water temperature of the floor heating.




REMARK

1	Outdoor unit	9	Distributor
2	Plate heater exchange	10	Collector
3	Backup electric heater(optional)	11	Bypass valve
4	Internal circulating pump	12	External circulation pump
5	Wired controller	RDT	Heating radiator
6	Stop valve (local)	FLH	Floor heating loops
7	Balance water tank	RT	Room thermostats
8	Mixing valve and mixing water pump		

8.2 Space Heating and Domestic Hot Water


The room thermostats also can connect to a motorized valve. Each rooms temperature is regulated by the motorized valve on its water circuit. Domestic hot water is supplied from the domestic hot water tank connected to the hydraulic module. The water tank should built in a temperature sensor which connect to the hydraulic module. A bypass valve is required.



REMARK			
1	Outdoor unit	11	Collector
2	Plate heater exchange	12	Bypass valve
3	Backup electric heater	13	Electric heating
4	Internal circulating pump	14	Domestic hot water tank
5	Wired controller	15	Coil in the water tank
6	Stop valve (field supplied)	16	External circulation pump
7	Motorized 3way valve	RDT	Heating Radiator
8	Balance water tank	FLH	Floor heating loops
9	Mixing valve and mixing water pump	RT	Room thermostats
10	Distributor		

8.3 Space Heating, Space Cooling and Domestic Hot Water


Floor heating loops & Heating radiator & Fan coil units are used for space heating , fan coil units are used for space cooling. Domestic hot water is supplied from the domestic hot water tank connected to the hydraulic module. The unit switches to heating or cooling mode according to the temperature detected by the room thermostat. In space cooling mode, the 2way valve is closed to prevent cold water entering the floor heating loops & Heating radiator.



REMARK			
1	Outdoor unit	12	Distributor
2	Plate heater exchange	13	Distributor
3	Backup electric heater(optional)	14	Bypass valve
4	Internal circulating pump	15	Electric heating
5	Wired controller	16	Domestic hot water tank
6	Stop valve	17	Coil in the water tank
7	Motorized 3way valve	RDT	Heating Radiator
8	Balance water tank	FLH	Floor heating loops
9	External circulation pump	FCU	Fan coil units
10	Two way valve	RT	Room thermostats
11	Mixing valve and mixing water pump		

8.4 Space Heating and Space Cooling


Floor heating loops & Heating radiator & fan coil units are used for space heating , fan coil units are used for space cooling. In space cooling mode, the 2way valve is closed to prevent cold water entering the floor heating loops & Heating radiator.



REMARK			
1	Outdoor unit	10	Mixing valve and mixing water pump
2	Plate heater exchange	11	Distributor
3	Backup electric heater(optional)	12	Distributor
4	Internal circulating pump	13	Bypass valve
5	Wired controller	RDT	Radiator
6	Stop valve	FLH1n	Floor heating loops
7	Balance water tank	FCU	Fan coil units
8	External circulation pump	RT	Room thermostats
9	Two way valve		

8.5 Auxiliary heat source provides space heating only

Users can also use only gas water heaters for heating




REMARK			
1	Outdoor unit	10	Distributor
2	Plate heater exchange	11	Water collector
3	Backup electric heater(optional)	12	Bypass valve
4	Internal circulating pump	13	External circulation pump
5	Wired controller	RDT	Heating Radiator
6	Stop valve	FLH	Floor heating loops
7	One way valve	AHS	Auxiliary heating source
8	Balance water tank	RT	Room thermostats
9	Mixing valve and mixing water pump		

8.6 Space Heating Through Floor Heating Loops and Fan Coil Units

The floor heating loops and fan coil units require different operating water temperatures. To achieve these two set points, a mixing station is required. Room thermostats for each zone are optional.


The outlet water temperature of the unit is set to the water temperature required by the fan coil unit, and the mixing valve and mixing pump are set to reduce the inlet water temperature of the floor heating.



REMARK			
1	Outdoor unit	9	Mixing valve and mixing water pump
2	Plate heater exchange	10	Distributor
3	Backup electric heater(optional)	11	Distributor
4	Internal circulating pump	12	Bypass valve
5	Wired controller	FCU	Fan coil units
6	Stop valve	FLH	Floor heating loops
7	Balance water tank	RT	Room thermostats
8	External circulation pump		

8.7 Space Heating, Space Cooling and Domestic Hot Water Compatible with Solar Water Heater


Floor heating loops & Heating Radiator &fan coil units are used for space heating, and fan coil units are used for space cooling. The temperature in the domestic hot water tank is controlled by the hydraulic module. A temperature sensor needs to be placed in the domestic hot water tank and connected to the hydraulic module. When it is detected that the temperature of the domestic hot water tank is lower than the set temperature and meets the requirements for solar hot water activation When conditions are met, turn on the solar water pump to realize the solar hot water function.



REMARK			
1	Outdoor unit	13	Water collector
2	Plate heater exchange	14	Bypass valve
3	Backup electric heater(optional)	15	Electric heating
4	Internal circulating pump	16	Domestic hot water tank
5	Wired controller	17	Coil 1 in the water tank
6	Stop valve	18	Coil 2 in the water tank
7	Motorized 3way valve	19	solar water pump
8	Balance water tank	20	Solar panel
9	External circulation pump	RDT	Heating Radiator
10	Two way valve	FLH	Floor heating loops
11	Mixing valve and mixing water pump	FCU	Fan coil units
12	Distributor	RT	Room thermostats

8.8 Space Heating with heat pump and AHS, space cooling with heat pump and solar for hot water

When the heating insufficient, the gas boiler (AHS) is used as an additional heat source, and floor heating or fan coils or low temperature radiators are used for space heating (also can be used in combination with various types of terminals). The fan coil is used for space cooling. The temperature in the domestic hot water tank is controlled by the hydraulic module. A temperature sensor needs to be placed in the domestic hot water tank and connected to the hydraulic module. When it is detected that the temperature of the domestic hot water tank is lower than the set temperature and meets the requirements for solar hot water activation When conditions are met, turn on the solar water pump to realize the solar hot water function.



REMARK

1	Outdoor unit	14	Water collector
2	Plate heater exchange	15	Bypass valve
3	Backup electric heater(optional)	16	Electric heating
4	Internal circulating pump	17	Domestic hot water tank
5	Wired controller	18	Coil 1 in the water tank
6	Stop valve	19	Coil 2 in the water tank
7	Motorized 3way valve	20	solar water pump
8	One way valve	21	Solar panel
9	Balance water tank	RDT	Radiator
10	External circulation pump	FLH	Floor heating loops
11	One way valve	FCU	Fan coil units
12	Mixing valve and mixing water pump	RT	Room thermostats
13	Distributor		

CAUTION

Make sure to connect the 3MV1/2MV/3MV2 terminals in the wired controller correctly,please refer to 9.3


The Balance tank volume requirement

NO.	Indoor unit model	Balance tank(L)
1	4~6kW	≥ 25
2	8~16kW	≥ 40


9. OVERVIEW OF THE UNIT

9.1 Disassembling the unit

Door 1 To access to the compressor and electrical parts.



4/6kW




8/10/12/14/16kW

WARNING


Switch off all power — i.e. unit power supply and backup heater and domestic hot water tank power supply (if applicable) — before removing door 1.
Parts inside the unit may be hot.

9.2 Main components

9.2.1 Hydraulic module



Without backup heater for example (optional)




With backup heater for example (optional)

Code	Assembly	Explanation
1	Automatic air purge valve	Remaining air in the water circuit will be automatically removed via the automatic air purge valve.
2	Internal backup beater	The backup heater consists of an electrical heating element that will provide additional heating capacity to the water circuit if the heating capacity of the unifisn sufficient due to low outdoor temperature, it also protects the external water piping from freezing during cold periods
3	Flow switch	If water flow is below 0.6m³/h, the flow switch opens (8~16kW) If water flow is below 0.36m³/h, the flow switch opens (4~6kW)
4	Water outlet pipe	/
5	Water inlet pipe	/
6	Refrigerant liquid pipe	/
7	Pump_i	The pump circulates the water in the water circuit
8	Refrigerant liquid pipe	/
9	Temperature sensors	Five temperature sensors determine the water and refrigerant temperature at various points (9.1; 9.2; 9.3; 9.4; 9.5)
10	Drainage port	/
11	Pressure relief valve	The pressure relief valve prevents excessive water pressure in the water circuit by opening at 43.5 psi(g)/0.3Mpa(g) and discharging some water
12	Plate heat exchanger	Heat exchanging between water and refrigerant
13	Expansion vessel (8L)	/

9.3 Electronic control box


The figure is only for reference, please refer to the actual product.




Components description:

KM1	AC Contactor1
KM2	AC Contactor2
KM3	AC Contactor3
TCO	Thermostat
ATCO	Automatic Thermostat
AFLP	Anti-freezing Low Pressure Switch
FLS	Water flow switch
EH	Electric Heater
XT1	Power terminal board
XT2	Terminal board (32P)
3WV1	3-Way Valve1
3WV2	3-Way Valve2
2WV	2-Way Valve
KM4	Zone1 PUMP AC Contactor4
KM5	DHW PIPE PUMP AC Contactor5
KM6	Electric heating for water tank AC contactor6
KM8	Solar PUMP AC contactor8
KM9	Zone 2 PUMP AC contactor9
KM10	Additional heat source AC contactor10
TWO1	Outlet water temp. sensor of plate heat exchanger
TWO2	Outlet water temp. sensor of Electric heating
TWI	Inlet water temp. sensor of plate heat exchanger
TICO	Evaporator Outlet Sensor
TICI	Evaporator Inlet Sensor
TWT_BT	Balance tank temp. sensor
TWT_FLH	Floor heating water inlet temp. sensor
TWT	Tank water temp. sensor
ROOM	Room temp. sensor
TSOLAR	Solar panel temp. sensor
T1	Temperature Sensor
T2	Compressor Suction Sensor
T3	Defrost Sensor
T4	Condenser Mid Sensor
T5	Exhaust Sensor


Position description




4~6kW(1-phase)



8~16kW(1-phase)




8-10kW(3-phase)




12-16kW(3-phase)

4~6kW(1-phase)




BK:Black
BN:Brown
BU:Blue
GN:Green
YG:Yellow/Green
C:COOL
H:HEAT
SG:Solar electric power
EV:D:Commercial power

- Notes:
- The wiring instructions of XT2 is for user wiring(wiring according to user).
 - Disconnect the power supply when connecting cables.
 - Some models have no content inside dashed frame.




2(4)

2(4)




Power

8~16kW(1-phase)




8-10kW(3-phase)



BK:Black	GY: Gray
BN:Brown	RD:Red
BU:Blue	WH:White
GN:Green	YE:Yellow
YG:Yellow/Green	
C:COOL	
H:HEAT	


1. The wiring instructions of X12 is for user wiring(wiring according to user)
2. Disconnect the power supply when connecting cables.
3. Some models have no content inside dashed frame.

12 - 16kW(3-phase)




9.3.1 Specifications of standard wiring components

Equipment main Power Supply Wiring



Single phase power




Three phase power

- Stated values are maximum values (see electrical data for exact values).

Unit	6kW(3kW-1PH heater)	10kW(3kW-1PH heater)	10kW(9kW-3PH heater)	16kW(3kW-1PH heater)	16kW(9kW-3PH heater)
1PH-wiring size(mm^2)	6.0	6.0	4.0	10.0	/
3PH-wiring size(mm^2)	/	/	4.0	/	6.0

CAUTION

When connecting to the power supply terminal, use the circular wiring terminal with the insulation casing (see Figure 8.1). Use power cord that conforms to the specifications and connect the power cord firmly. To prevent the cord from being pulled out by external force, make sure it is fixed securely.




NOTE

The ground fault circuit interrupter must be a high-speed type breaker of 30 mA (<0.1 s). Flexible cord must meet 60245IEC(HO5VV-F) standards.

9.3.2 Connection for other components



Port provide the signal with 220V voltage. If the current of load is < 0.2A load can connect to the port directly. If the current of load is 0.2A, the AC contactor is required to connected for the load.

1) For solar energy input signal



Voltage	220-240VAC
Maximum running current(A)	0.2
Wiring size(mm^2)	0.75

2)For 3-way value 3WV1、2WV、3WV2 and Solar pump




Voltage	220-240VAC
Maximum running current(A)	0.2
Wiring size(mm^2)	0.75

a)Procedure

Connect the cable to the appropriate terminals as shown in the picture. Fix the cable reliably.

3WV1: Motorized 3way valve
2WV: Two way valve
3WV2: Mixing valve


3)For Zone1 pump and DHW pipe pump:



Voltage	220-240VAC
Maximum running current(A)	0.2
Wiring size(mm^2)	0.75


Zone1 pump: External circulation pump;
KM4: Zone1 pump AC Contactor4
KM5: DHW pipe pump AC Contactor5

4) For tank booster heater:



Voltage	220-240VAC
Maximum running current(A)	0.2
Wiring size(mm^2)	0.75

5) For zone2 pump and additional heat source control:




Voltage	220-240VAC
Maximum running current(A)	0.2
Wiring size(mm^2)	0.75
Control port signal type	Type 2

Zone2 pump: Mixing valve
KM9: Zone2 pump AC Contactor9
Additional heat source control: AHS
KM10: additional heat source control AC Contactor10




WARNING

This part only applies to Basic. For Customized, cause thereis an interval backup heater in the unit, the indoor unitshould not be connected to any additional heat source.

6)For smart grid :

The unit has smart grid function, there are two ports on PCB to connect SG signal and EVU signal as following:

- 1.when EVU signal is on, the unit operate as below:
DHW mode turn on, the setting temperature will be changed to 70°C automatically, and the TBH operate as below.T5<69. the TBH is on, T5≥70, the TBH is off. The unit operate in cooling/heating mode as the normal logic.
2. When EVU signal is off, and SG signal is on, the unit operate normally.
- 3 When EVU signal is off, SG signal is off, the DHW mode is off, and the TBH is invalid, disinfect function is invalid. The max running time for cooling/heating is “SG RUNNIN TIME”, then unit will be off.

7)Room Thermostat(Low Voltage)**8)Room Thermostat(High Voltage)****9)For modbus**

9.4 Water piping

All piping lengths and distances have been taken into consideration.

NOTE

- If no glycol is in the system, in case of a power supply failure or pump operating failure, drain all the water system if the water temperature is below 0°C in the cold winter (as suggested in the figure below figure 1).
- When water is at standstill inside the system, freezing is very likely to happen and damage the system in the process.

9.4.1 Check the water circuit

The unit is equipped with a water inlet and water outlet for connection to a water circuit. This circuit must be provided by a licensed technician and must comply with local laws and regulations.

The unit is only to be used in a closed water system. Application in an open water circuit can lead to excessive corrosion of the water piping.

Before continuing installation of the unit, check the following:

- The maximum water pressure \leq 3 bar.
- The maximum water temperature \leq 70°C according to safety device setting.
- Always use materials that are compatible with the water used in the system and with the materials used in the unit.
- Ensure that components installed in the field piping can withstand the water pressure and temperature.
- Drain taps must be provided at all low points of the system to permit complete drainage of the circuit during maintenance.
- Air vents must be provided at all high points of the system. The vents should be located at points that are easily accessible for service. An automatic air purge is provided inside the unit. Check that this air purge valve is not tightened so that automatic release of air in the water circuit is possible.

9.4.2 Water volume and sizing expansion vessels

The units are equipped with an expansion vessel of 8L that has a default pre-pressure of 1.5 bar. To assure proper operation of the unit, the pre-pressure of the expansion vessel might need to be adjusted.

1) Check that the total water volume in the installation, excluding the internal water volume of the unit, is at least 40L. See 14 "Technical specifications" to find the total internal water volume of the unit.

NOTE

- In most applications this minimum water volume will be satisfactory.
- In critical processes or in rooms with a high heat load though, extra water might be required.
- When circulation in each space heating loop is controlled by remotely controlled valves, it is important that this minimum water volume is kept even if all the valves are closed.

2) Expansion vessel volume must fit the total water system volume.

3) To size the expansion for the heating and cooling circuit.




figure 1

9.4.3 Water circuit connection

Water connections must be made correctly in accordance with respect to the water inlet and water outlet.

CAUTION

Be careful not to deform the unit's piping by using excessive force when connecting the piping. Deforming the piping can cause the unit to malfunction.

If air, moisture or dust gets in the water circuit, problems may occur. Therefore, always take into account the following when connecting the water circuit:

- Use clean pipes only.
- Hold the pipe end downwards when removing burrs.
- Cover the pipe end when inserting it through a wall to prevent dust and dirt entering.
- Use a good thread sealant for sealing the connections. The sealing must be able to withstand the pressures and temperatures of the system.
- When using non-copper metallic piping, be sure to insulate two kind of materials from each other to prevent galvanic corrosion.
- As copper is a soft material, use appropriate tools for connecting the water circuit. Inappropriate tools will cause damage to the pipes.

NOTE

The unit is only to be used in a closed water system. Application in an open water circuit can lead to excessive corrosion of the water piping:

- Never use Zn-coated parts in the water circuit. Excessive corrosion of these parts may occur as copper piping is used in the unit's internal water circuit.
- When using a 3-way valve in the water circuit. Preferably choose a ball type 3-way valve to guarantee full separation between the domestic hot water and floor heating water circuit.
- When using a 3-way valve or a 2-way valve in the water circuit. The recommended maximum changeover time of the valve should be less than 60 seconds.

9.4.4 Water circuit anti-freeze protection

All internal hydronic parts are insulated to reduce heat loss. Insulation must also be added to the field piping.

The software contains special functions using the heat pump and backup heater (if it is available) to protect the entire system against freezing. When the temperature of the water flow in the system drops to a certain value, the unit will heat the water, either using the heat pump, the electric heating tap, or the backup heater. The freeze protection function will turn off only when the temperature increases to a certain value.

In event of a power failure, the above features would not protect the unit from freezing.

CAUTION

When the unit is not running for a long time make sure the unit is powered on all the time. If you want to cut off the power, the water in the system pipe needs to be drained clean, avoid the pump and pipeline system be damaged by freezing. Also the power of the unit needs to be cut off after water in the system is drained clean.


Water may enter into the flow switch and cannot be drained out and may freeze when the temperature is low enough. The flow switch should be removed and dried, then can be reinstalled in the unit.

NOTE

1. Counterclockwise rotation, remove the flow switch.
2. Drying the flow switch completely.

9.5 Filling water

- Connect the water supply to the filling valves and open the valve.
- Make sure all the automatic air purge valves are open (at least 2 turns).
- Filling with water until the manometer indicates a pressure of approximately 2.0bar. Remove air in the circuit as much as possible using the automatic air purge valves.



NOTE

During filling, it might not be possible to remove all air in the system. Remaining air will be removed through the automatic bleed valve during the first operating hours of the system. Topping up the water afterwards might be required.

- The water pressure indicated on the manometer will vary depending on the water temperature (higher pressure at higher water temperature). However, at all times water pressure should remain above 0.3bar to avoid air entering the circuit.
- The unit might drain-off too much water through the pressure relief valve.
- Water quality should be complied with EN 98/83 EC Directives.
- Detailed water quality condition can be found in EN 98/83 EC Directives.

9.6 Water piping insulation

The compete water circuit including all piping, water piping must be insulated to prevent condensation during cooling operation and reduction of the heating and cooling capacity as well as prevention of freezing of the outside water piping during winter. The insulation material should at least of B1 fire resistance rating and complies with all applicable legislation. The thickness of the sealing materials must be at least 13 mm with thermal conductivity 0.039 W/mK in order to prevent freezing on the outside water piping.

If the outdoor ambient temperature is higher than 30°C and the humidity is higher than RH 80%, then the thickness of the sealing materials should be at least 20 mm in order to avoid condensation on the surface of the seal.

9.7 Field wiring

WARNING

A main switch or other means of disconnection, having a contact separation in all poles, must be incorporated in the fixed wiring in accordance with relevant local laws and regulations. Switch off the power supply before making any connections. Use only copper wires. Never squeeze bundled cables and make sure they do not come in contact with the piping and sharp edges. Make sure no external pressure is applied to the terminal connections. All field wiring and components must be installed by a licensed electrician and must comply with relevant local laws and regulations.

The field wiring must be carried out in accordance with the wiring diagram supplied with the unit and the instructions given below.

Be sure to use a dedicated power supply. Never use a power supply shared by another appliance.

Be sure to establish a ground. Do not ground the unit to a utility pipe, surge protector, or telephone ground. Incomplete grounding may cause electrical shock.

Be sure to install a ground fault circuit interrupter (30 mA). Failure to do so may cause electrical shock.

Be sure to install the required fuses or circuit breakers.

9.7.1 Precautions on electrical wiring work

- Fix cables so that cables do not make contact with the pipes (especially on the high pressure side).
- Fix the wire with cable ties so that it will not contact the pipe, especially on the high-voltage side.
- Make sure no external pressure is applied to the terminal connectors.
- When installing the ground fault circuit interrupter make sure that it is compatible with the inverter (resistant to high frequency electrical noise) to avoid unnecessary opening of the ground fault circuit interrupter.

NOTE

The ground fault circuit interrupter must be a high- speed type breaker of 30 mA (< 0.1 s).

This unit is equipped with an inverter. Installing a phase advancing capacitor not only will reduce the power factor improvement effect, but also may cause abnormal heating of the capacitor due to high-frequency waves. Never install a phase advancing capacitor as it could lead to an accident.

9.7.2 Wiring overview

Loads requiring field wiring. Refer also to "8 typical application".

(a) Minimum cable section AWG18 (0.75 mm²).

(b) The thermistor cable are delivered with the unit: if the current of the load is large, an AC contactor is needed.

NOTE

Please use HO7RN-F for the power wire, all the cables are connect to high voltage except for thermistor cable and cable for user interface.

- Equipment must be grounded.
- All high-voltage external load, if it is metal or a grounded port, must be grounded.
- All external load current is needed less than 0.2A, if the single load current is greater than 0.2A, the load must be controlled through AC contactor.
- Plate heat exchanger E-Heating tape and Flow switch E-Heating tape share a control port.
Field wiring guidelines.
- Most field wiring on the unit is to be made on the terminal block inside the switch box. To gain access to the terminal block, remove the switch box service panel.

WARNING

Switch off all power including the unit power supply and backup heater and domestic hot water tank power supply (if applicable) before removing the switch box service panel.

- Fix all cables using cable ties.
- A dedicated power circuit is required for the backup heater.
- Installations equipped with a domestic hot water tank (field supply) require a dedicated power circuit for the booster heater. Please refer to the domestic hot water tank Installation & Owner's Manual.
- Lay out the electrical wiring so that the front cover does not rise up when doing wiring work and attach the front cover securely.
- Follow the electric wiring diagram for electrical wiring works (the electric wiring diagrams are located on the rear side of door 2).
- Install the wires and fix the cover firmly so that the cover may be fit in properly.

9.7.3 Precautions on wiring of power supply

- Use a round crimp-style terminal for connection to the power supply terminal board. In case it cannot be used due to unavoidable reasons, be sure to observe the following instructions.
 - Do not connect different gauge wires to the same power supply terminal.(Loose connections may cause overheating.)
- Use the correct screwdriver to tighten the terminal screws. Small screwdrivers can damage the screw head and prevent appropriate tightening.
- Over-tightening the terminal screws can damage the screws.
- Attach a ground fault circuit interrupter and fuse to the power supply line.
- In wiring, make certain that prescribed wires are used, carry out complete connections, and fix the wires so that outside force cannot affect the terminals.

9.7.4 Safety device requirements

1. Select the wire diameters (minimum value) individually for each unit based on the table below.
2. Select circuit breaker that having a contact separation in all poles not less than 3 mm providing full disconnection, where MFA is used to select the current circuit breakers and residual current operation breakers:

1-phase 4-16kW(Backup heater:3kW) and 3-phase 8-16kW(Backup heater:9kW) standard

System	Power Current						WPM	
	Hz	Voltage(V)	Min(V)	Max(V)	MCA(A)	MFA(A)	kW	FLA(A)
4-6kW	50	220-240/1N	198	264	33	/	0.095	0.75
8-10kW	50	220-240/1N	198	264	35	/	0.095	0.75
8-10kW 3-PH	50	380-415/3N	342	456	21	/	0.095	0.75
12-16kW	50	220-240/1N	198	264	43	/	0.095	0.75
12-16kW 3-PH	50	380-415/3N	342	456	25	/	0.095	0.75

1-phase 4-16kW and 3-phase 12-16kW standard without backup heater

System	Power Current						WPM	
	Hz	Voltage(V)	Min(V)	Max(V)	MCA(A)	MFA(A)	kW	FLA(A)
4-6kW	50	220-240/1N	198	264	20	/	0.095	0.75
8-10kW	50	220-240/1N	198	264	21	/	0.095	0.75
12 - 16kW	50	220-240/1N	198	264	29	/	0.095	0.75
12-16kW 3-PH	50	380-415/3N	342	456	12	/	0.095	0.75

NOTE

MCA: Max. Circuit Amps.(A)

MFA: MAX. Fuse Amps.(A)

WPM: Water Pump Motor

FLA: Full Load Amps.(A)

- A creepage circuit breaker above the maximum current must be installed to avoid possible electric shocks.

10.START-UP AND CONFIGURATION

The unit should be configured by the installer to match the installation environment (outdoor climate, installed options, etc.) and user expertise.

CAUTION

It is important that all information in this chapter is read sequentially by the installer and that the system is configured as applicable.

10.1 Initial start-up at low outdoor ambient temperature

During initial start-up and when water temperature is low, it is important that the water is heated gradually. Failure to do so may result in concrete floors cracking due to rapid temperature change. Please contact the responsible cast concrete building contractor for further details.

To do so, the lowest water flow set temperature can be decreased to a value between 25°C and 35°C by adjusting the FOSERVICEMAN. Refer to SPECIAL FUNCTION.

10.2 Pre-operation checks

Checks before initial start-up.

DANGER

switch of the power supply before making any connections.

After the installation of the unit, check the following before switching on the circuit breaker;

- Field wiring :Make sure that the field wiring between the local supply panel and unit and valves (when applicable),unit and room thermostat (when applicable), unit and domestic hot water tank, and unit and backup heater kit have been connected according to the instructions described in the chapter 9.8 "Field wiring", according to the wiring diagrams and to local laws and regulations.
- Fuses, circuit breakers, or protection devices Check that the fuses or the locally installed protection devices are of the size and type specified in 14 "Technical specifications". Make sure that no fuses or protection devices have been bypassed.
- Backup heater circuit breaker: Do not forget to turn on the backup heater circuit breaker in the switchbox (it depends on the backup heater type). Refer to the wiring diagram.
- Booster heater circuit breaker: Do not forget to turn on the booster heater circuit breaker (applies only to units with optional domestic hot water tank installed).
- Ground wiring: Make sure that the ground wires have been connected properly and that the ground terminals are tightened.
- Internal wiring: Visually check the switch box for loose connections or damaged electrical components.
- Mounting: Check that the unit is properly mounted, to avoid abnormal noises and vibrations when starting up the unit.
- Damaged equipment: Check the inside of the unit for damaged components or squeezed pipes.
- Refrigerant leak: Check the inside of the unit for refrigerant leakage. If there is a refrigerant leak, call your local dealer.
- Power supply voltage: Check the power supply voltage on the local supply panel. The voltage must correspond to the voltage on the identification label of the unit.
- Air purge valve: Make sure the air purge valve is open (at least 2 turns).
- Shut-off valves: Make sure that the shut-off valves are fully open.

11.TEST RUN AND FINAL CHECKS

The installer is obliged to verify correct operation of unit after installation.

11.1 Final checks

Before switching on the unit, read following recommendations:

- When the complete installation and all necessary setting have been carried out, close all front panels of the unit and refit the unit cover.
- The service panel of the switch box may only be opened by a licensed electrician for maintenance purpose.

Note:

hat during the first running period of the unit, required power input may be higher than stated on the nameplate of the unit. This phenomenon originates from the compressor that needs elapse of a 50 hours run in period before reaching smooth operation and stable power consumption.

11.2 Test run operation (manually)

If required, the installer can perform a manual test run operation at any time to check correct operation of air purge, heating, cooling and domestic water heating.

12. MAINTENANCE AND SERVICE

In order to ensure optimal availability of the unit, a number of checks and inspections on the unit and the field wiring have to be carried out at regular intervals.

This maintenance needs to be carried out by your local technician.

In order to ensure optimal availability of the unit, a number of checks and inspections on the unit and the field wiring have to be carried out at regular intervals.

This maintenance has to be carried out by your local technician.

DANGER

Electric Shock

- Before carrying out any maintenance or repairing activity, must switch off the power supply on the supply panel.
- Do not touch any live part for 10 minutes after the power supply is turned off.
- The crank heater of compressor may operate even in standby.
- Please note that some sections of the electric component box are hot.
- Forbid touch any conductive parts.
- Forbid rinse the unit. It may cause electric shock or fire.

Forbid leave the unit unattended when service panel is removed.

The following checks must be performed at least once a year by qualified person:

- Water pressure
Check the water pressure, if it is below 1 bar, fill water to the system.
- Water filter
Clean the water filter.
- Water pressure relief valve
Check for correct operation of the pressure relief valve by turning the black knob on the valve counter-clockwise:
-If you do not hear a clacking sound, contact your dealer.
-In case the water keeps running out of the unit, close both the water inlet and outlet shut-off valves first and then contact your local dealer.
- Pressure relief valve hose
Check that the pressure relief valve hose is positioned appropriately to drain the water.
- Backup heater vessel insulation cover
Check that the backup heater insulation cover is fastened tightly around the backup heater vessel.
- Domestic hot water tank pressure relief valve (field supply)Applies only to installation with a domestic hot water tank
Check for correct operation of the pressure relief valve on the domestic hot water tank.
- Domestic hot water tank booster heater
Applies only to installations with a domestic hot water tank. It is advisable to remove lime buildup on the booster heater to extend its life span, especially in regions with hard water. To do so, drain the domestic hot water tank, remove the booster heater from the domestic hot water tank and immerse in a bucket(or similar)with lime-removing product for 24 hours.
- Unit switch box
-Carry out a thorough visual inspection of the switch box and look for obvious defects such as loose connections or defective wiring.
-Check for correct operation of contactors with an ohm meter, All contacts of these contactors must be in open position.
Use of glycol(Refer to 9.5.4 "Water circuit anti-freeze protection")Document the glycol concentration and the pH-valve in the system at least once a year.
-A PH-value below 8.0 indicates that a significant portion of the inhibitor has been depleted and that more inhibitor needs to be added.
-When the PH-value is below 7.0 then oxidation of the glycol occurred, the system should be drained and flushed thoroughly before severe damage occurs.
Make sure that the disposal of the glycol solution is done in accordance with relevant local laws and regulations.

13. TROUBLE SHOOTING

This section provides useful information for diagnosing and correcting certain troubles which may occur in the unit. This troubleshooting and related corrective actions may only be carried out by your local technician.

13.1 General guidelines

Before starting the troubleshooting procedure, carry out a thorough visual inspection of the unit and look for obvious defects such as loose connections or defective wiring.

WARNING

- When carrying out an inspection on the switch box of the unit, always make sure that the main switch of the unit is switched off.
- When a safety device was activated, stop the unit and find out why the safety device was activated before resetting it. Under no circumstance can safety devices be bridged or changed to a valve other than the factory setting. If the cause of the problem cannot be found, call your local dealer.
- If the pressure relief valve is not working correctly and is to be replaced, always reconnect the flexible hose attached to the pressure relief valve to avoid dripping out of the unit!

Note: For problems related to the optional solar kit for domestic water heating, refer to the troubleshooting in the Installation and owner's manual for that kit.

13.2 General Symptoms

Symptom 1: The unit is turned on but the unit is not heating or cooling as expected

Possible Causes	Corrective Action
The temperature setting is not correct.	Check the parameters Tao_HMAX, Tao_HMIN in heat mode. Tao_CMAX, Tao_CMIN in cool mode. Tao_DHWMAX, Tao_DHWMIN in DHW mode.
The water flow is too low.	<ul style="list-style-type: none"> ● Check that all shut off valves of the water circuit are in the right position. ● Check the water filter is plugged. ● Make sure there is no air in the water system. ● Check on the manometer that there is sufficient water pressure. The water pressure must be >1 bar(water is cold). ● Make sure that the expansion vessel is not too high for the pump.
The water volume in the installation is too low.	Make sure the water volume in the installation is above the minimum required value(refer to "9.4.2 Water volume and sizing expansion vessels")

Symptom 2: The unit is turned on but the compressor is not starting(space heating or domestic water heating)

Possible Causes	Corrective Action
The unit maybe operate out of its operation range (the water temperature is too low).	In case of low water temperature, the system utilizes the backup heater to reach the minimum water temperature first(18°C). <ul style="list-style-type: none"> ● Check that the backup heater power supply is correct. ● Check that the backup heater thermal fuse is closed. ● Check that the backup heater thermal protector is not activated. ● Check that the backup heater thermal contactors are not broken.

Symptom 3: Pump is making noise(cavitation)

Possible Causes	Corrective Action
There is air in the system.	Purge air.
Water pressure at pump inlet is too low.	<ul style="list-style-type: none"> ● Check on the manometer that there is sufficient water pressure. The water pressure must be >1bar(water is cold). ● Check that the manometer is not broken. ● Check that the expansion vessel is not broken. ● Check that the setting of the pre-pressure of the expansion vessel is correct (refer to "9.4.2 Water volume and sizing expansion vessels").

Symptom 4: The water pressure relief valve opens

Possible Causes	Corrective Action
The expansion vessel is broken.	Replace the expansion vessel.
The filling water pressure in the installation is higher than 0.3MPa.	Make sure that the filling water pressure in the installation is about 0.1 ~ 0.2MPa(refer to "9.4.2 Water volume and sizing expansion vessels").

Symptom 5: The water pressure relief valve leaks

Possible Causes	Corrective Action
Dirt is blocking the water pressure relief valve outlet.	<p>Check for correct operation of the pressure relief valve by turning the red knob on the valve counter clockwise:</p> <ul style="list-style-type: none"> • If you do not hear a clacking sound, contact your local dealer. • In case the water keeps running out of the unit, close both the water inlet and outlet shut-off valves first and then contact your local dealer.

Symptom 6: Space heating capacity shortage at low outdoor temperatures

Possible Causes	Corrective Action
Backup heater operation is not activated.	<p>Check that the "OTHER HEATING SOURCE/BACKUP HEATER" is enable, see "Wired Controller Instruction" Check whether or not the thermal protector of the backup heater has been activated(refer to "Controls parts for backup heater(IBH)").</p> <p>Check if booster heater is running, the backup heater and booster heater can't operate simultaneously.</p>
Too much heat pump capacity is used for heating domestic hot water (applies only to installations with a domestic hot water tank).	<p>Check that the "t_DHWHP_MAX" and "t_DHWHP_RESTRICT" are configured appropriately:</p> <ul style="list-style-type: none"> • Make sure that the "DHW PRIORITY" in the user interface is disabled. • Enable the "Tao_TBH_ON" in the user interface/FOR SERVICEMAN to active the booster heater for domestic water heating.

Symptom 7: Heat mode can't change to DHW mode immediately

Possible Causes	Corrective Action
There is air in the system.	Purge air.
Volume of tank is too small and the location of water temperature probe not high enough	<ul style="list-style-type: none"> • Set "t-DHWHP_RESTRICT" to minimum value. • Enable TBH, and TBH should be controlled by the outdoor unit. • If AHS is available, turn on first, if requirement for turn heat pump on is fulfilled, the heat pump will turn on. • If both TBH and AHS are not available, try to change the position of TWT probe(refer to 5 "General introduction").

Symptom 8:DHW mode can't change to Heat mode immediately.

Possible Causes	Corrective Action
Heat exchange for space heating not big enough	<ul style="list-style-type: none"> • Set "t_DHWHP_MAX" to minimum value, the suggested value is 60min. • If circulating pump out of unit is not controlled by unit, try to connect it to the unit. • Add 3-way valve at the inlet of fan coil to ensure enough water flow.
Space heating load is small	Normal, no need for heating
Disinfect function is enabled but without TBH	<ul style="list-style-type: none"> • Disable disinfect function • Add TBH or AHS for DHW mode
Manual turn on the FAST WATER function, after the hot water meets the requirements, the heat pump fails to switch to the air-conditioning mode in time when the air conditioner is in demand	Manual turn off the FAST WATER Add TBH or AHS for DHW mode
When the ambient temperature is low, the hot water is not enough and the AHS is not operated or operated late	<ul style="list-style-type: none"> • Set "Tao_DHWMIN", the suggested value is $\geq -5^{\circ}\text{C}$ • Set "Tao_TBH_ON", the suggested value is $\geq 5^{\circ}\text{C}$
DHW mode priority	If there is AHS or IBH connect to the unit ,when the outdoor unit failed , the indoor unit must run DHW mode till the water temperature reach the setting temperature before change to heating mode.

Symptom 9: DHW mode heat pump stop work but setpoint not reached, space heating require heat but unit stay in DHW mode

Possible Causes	Corrective Action
Surface of coil in the tank not large enough	The same solution for Symptom 7
TBH or AHS not available	Heat pump will stay in DHW mode until "t_DHWHP_MAX" reached or setpoint. Add TBH or AHS for DHW mode, TBH and AHS should be controlled by the unit

13.3 Error codes

When a safety device is activated, an error code will be displayed on the user interface.

A list of all errors and corrective actions can be found in the table below.

Reset the safety by turning the unit OFF and back ON.

In case this procedure for resetting the safety is not successful, contact your local dealer.

ERROR CODE	MALFUNCTION OR PROTECTION	FAILURE CAUSE AND CORRECTIVE ACTION
A7	Water flow falut	1.The wire circuit is short connected or open. Reconnect the Wire correctly. 2.Water flow rate is too low. 3. Water flow switch is failed, switch is open or close continuously, change the water flow switch.
AA	Communication fault between controller and indoor unit	1.Wire doesn't connect between wired controller and unit. connect the wire. 2.Communication wire sequence is not right. Reconnect the Communication fault wire in the right sequence. between controller. 3.Whether there is a high magnetic field or high power and indoor unit interfere, such as lifts, large power transformers, etc.. To add a barrier to protect the unit or to move the unit to the other place.
93	Final outlet water temp.sensor(TWO2) fault	1.Check the resistance of the sensor. 2.The TWO2 sensor connector is loosen. Reconnect it. 3.The TWO2 sensor connector is wet or there is water in. remove the water, make the connector dry. Add waterproof adhesive. 4.The TWO2 sensor failure, change a new sensor.
96	Water tank temp. sensor(TWT)fault	1.Check the resistance of the sensor. 2.The TWTsensor connector is loosen. Reconnect it. 3.The TWT sensor connector is wet or there is water in. remove the water, make the connector dry. Add waterproof adhesive 4.The TWT sensor failure, change a new sensor.
94	Inlet water temp. sensor(TWI)malfunc	1. Check the resistance of the sensor. 2. The TWI sensor connector is loosen. Re connect it. Inlet water temp.sensor 3.The TWI sensor connector is wet or there is water in. (TWI) malfunction remove the water, make the connector dry. Add waterproof adhesive 4. The TWI sensor failure, change a new sensor.
A9	Communication fault between indoor unit and outdoor unit	1.wire doesn't connect between outdoor unit and main controll board of indoor unit. connect the wire. 2.Communication wire sequence is not right. Reconnect the wire in the right sequence. 3. Whether there is a high magnetic field or high power interfere, such as lifts, large power transformers, etc.. To add a barrier to protect the unit or to move the unit to the other place.
A3	Refrigerant liquid temp.sensor(TICl) fault	1.Check the resistance of the sensor. 2.The TICI sensor connector is loosen. Re connect it. 3.The TICI sensor connector is wet or there is water in. remove the water, make the connector dry. Add waterproof adhesive 4. The TICI sensor failure, change a new sensor.
A4	Refrigerant gas temp.sensor(TICO) fault	1.Check the resistance of the sensor. 2. The TICO sensor connector is loosen. Reconnect it. 3.The TICO sensor connector is wet or there is water in. remove the water, make the connector dry. Add waterproof adhesive. 4. The TICO sensor failure, change a new sensor.
95	Outlet water temp.sensor(TWO1) fault	1. The TWO1 sensor connector is loosen. Reconnect it. 2.The TWO1 sensor connector is wet or there is water in. remove the water, make the connector dry. add waterproof adhesive. 3. The TWO1 sensor failure, change a new sensor.
7F	Solar temp.sensor(Tsolar) fault	1.Check the resistance of the sensor. 2.The Tsolar sensor connector is loosen, reconnect it. 3.The Tsolar sensor connector is wet or there is water in, remove the water ,make the connector dry. Add waterproof adhesive. 4.The Tsolar sensor failure,change a new sensor.

ERROR CODE	MALFUNCTION OR PROTECTION	FAILURE CAUSE AND CORRECTIVE ACTION
7E	Floor heating water inlet temp. sensor (TWI_FLH)	1.Check the resistance of the sensor. 2.The TWI_FLH sensor connector is loosen, reconnect it. 3.The TWI_FLH sensor connector is wet or there is water in, remove the water ,make the connector dry. Add waterproof adhesive. 4.The TWI_FLH sensor failure, change a new sensor.
A5	IDU water pump fault	1.Check whether the water valve is open 2.Check whether the water pump control line is loose 3.Check whether the filter is dirty and blocked 4. Check whether the pump voltage is lower than 170V or higher than 270V 5.The water pump failure, change a new water pump
98	Early closing fault of water flow switch	1. Check whether the wiring of water flow switch is correct 2. Check whether other equipment is connected in series with the host 3. Water flow switch failure, change a new water flow switch
97	Anti-freezing Low Pressure Switch (AFLP) protection	1. Check whether AFLP is loose 2. Check whether there is insufficient refrigerant 3. Check whether the filter is dirty and blocked 4. The AFLP failure,change a new AFLP
AF	Electric heating overheat protection	1. Check whether the filter is dirty and blocked 2.Check whether the thermal protection switch falls off
7D	Expansion Board Comm fault.	Check whether the connection line is normal
A8	EE fault	1.check whether the internal and external connecting lines are connected normally 2.The control panel failure,change a new control panel

CAUTION

In winter, if the unit has failure and the unit is not repaired in time, the water pump and pipeline system may be damaged by freezing, so failure must be repaired in time.

14. TECHNICAL SPECIFICATIONS

14.1 General

Model	1-phase	1-phase	3-phase	1-phase	3-phase
	4/6 kW	8/10 kW	8/10 kW	12/14/16 kW	12/14/16 kW
Nominal	Refer to the Technical Data				
Dimensions HxWxD	765×1265×323mm	933×1385×520mm	933×1385×520mm	933×1385×520mm	933×1385×520mm
Packing Dimensions HxWxD	930×1330×428mm	1095×1465×550mm	1095×1465×550mm	1095×1465×550mm	1095×1465×550mm
Weight (backup heater have to be integrated in the unit)					
Net weight	90kg	124kg	128kg	137kg	140kg
Gross weight	98kg	136kg	140kg	149kg	152kg
Weight (without backup heater)					
Net weight	87kg	121kg	/	134kg	137kg
Gross weight	95kg	133kg	/	146kg	149kg
Connections					
water inlet/outlet	G1"BSP	G1"BSP	G1"BSP	G1"BSP	G1"BSP
Water drain	hose nipple				
Expansion vessel					
volume	8L				
Maximum working pressure (MWP)	3 bar				
Pump					
Type	Water cooled	Water cooled	Water cooled	Water cooled	Water cooled
No. of speed	Variable speed	Variable speed	Variable speed	Variable speed	Variable speed
Pressure relief valve water circuit	3 bar				
Operation range - water side					
heating	+12~+65°C				
cooling	+5~+25°C				
Operation range - air side					
heating	-25~35°C				
cooling	-5~43°C				
domestic hot water by heat pump	-25~43°C				

14.2 Electrical specifications

Model		1-phase 4/6/8/10/12/14/16kW	3-phase 8/10/12/14/16kW
Standard unit	Power Supply	220-240V~ 50Hz	380 - 415V 3N~50Hz
	Nominal Running Current	See "9.7.4 Safety device requirement"	
Backup heater	Power Supply	See "9.7.4 Safety device requirement"	
	Nominal Running Current	See "9.7.4 Safety device requirement"	

15. MAINTENANCE NOTICE

Attention:

For maintenance or scrap, please contact authorized service centers.

Maintenance by unqualified person may cause dangers.

Feed air conditioner with R32 refrigerant, and maintain the air conditioner in strictly accordance with manufacturer's requirements. The chapter is mainly focused on special maintenance requirements for appliance with R32 refrigerant. Ask repairer to read after-sales technical service handbook for detailed information.

Qualification requirements of maintenance personnel

1. Special training additional to usual refrigerating equipment repair procedures is required when equipment with flammable refrigerants is affected. In many countries, this training is carried out by national training organisations that are accredited to teach the relevant national competency standards that may be set in legislation. The achieved competence should be documented by a certificate.
2. The maintenance and repair of the air conditioner must be conducted according to the method recommended by the manufacturer. If other professionals are needed to help maintain and repair the equipment, it should be conducted under the supervision of individuals who have the qualification to repair AC equipped with flammable refrigerant.

Inspection of the Site

- Safety inspection must be taken before maintaining equipment with R32 refrigerant to make sure the risk of fire is minimized. Check whether the place is well ventilated, whether anti-static and fire prevention equipment is perfect.
- While maintaining the refrigeration system, observe the following precautions before operating the system.

Operating Procedures

1. General work area:

All maintenance staff and others working in the local area shall be instructed on the nature of work being carried out. Work in confined spaces shall be avoided. The area around the workspace shall be sectioned off. Ensure that the conditions within the area have been made safe by control of flammable material.

2. Checking for presence of refrigerant:

The area shall be checked with an appropriate refrigerant detector prior to and during work, to ensure the technician is aware of potentially toxic or flammable atmospheres. Ensure that the leak detection equipment being used is suitable for use with all applicable refrigerants, i.e. no-sparking, adequately sealed or intrinsically safe.

3. Presence of fire extinguisher:

If any hot work is to be conducted on the refrigeration equipment or any associated parts, appropriate fire extinguishing equipment shall be available to hand. Have a dry powder or CO₂ fire extinguisher adjacent to the charging area.

4. No ignition sources:

No person carrying out work in relation to a refrigeration system which involves exposing any pipe work shall use any sources of ignition in such a manner that it may lead to the risk of fire or explosion. All possible ignition sources, including cigarette smoking, should be kept sufficiently far away from the site of installation, repairing, removing and disposal, during which refrigerant can possibly be released to the surrounding space. Prior to work taking place, the area around the equipment is to be surveyed to make sure that there are no flammable hazards or ignition risks. No Smoking' signs shall be displayed.

5. Ventilated Area(open the door and window):

Ensure that the area is in the open or that it is adequately ventilated before breaking into the system or conducting any hot work. A degree of ventilation shall continue during the period that the work is carried out. The ventilation should safely disperse any released refrigerant and preferably expel it externally into the atmosphere.

6. Checks to the refrigeration equipment:

Where electrical components are being changed, they shall be fit for the purpose and to the correct specification.

At all times the manufacturer's maintenance and service guidelines shall be followed. If in doubt, consult the manufacturer's technical department for assistance. The following checks shall be applied to installations using flammable refrigerants:

- The charge size is in accordance with the room size within which the refrigerant containing parts are installed.
- The ventilation machinery and outlets are operating adequately and are not obstructed.
- If an indirect refrigerating circuit is being used, the secondary circuit shall be checked for the presence of refrigerant.
- Refrigeration pipe or components are installed in a position where they are unlikely to be exposed to any substance which may corrode refrigerant containing components, unless the components are constructed of materials which are inherently resistant to being corroded or are suitably protected against being so corroded.

7. Checks to electrical devices:

Repair and maintenance to electrical components shall include initial safety checks and component inspection procedures. If a fault exists that could compromise safety, then no electrical supply shall be connected to the circuit until it is satisfactorily dealt with. If the fault cannot be corrected immediately but it is necessary to continue operation, an adequate temporary solution shall be used. This shall be reported to the owner of the equipment so all parties are advised.

Initial safety checks shall include:

- That capacitors are discharged: this shall be done in a safe manner to avoid possibility of sparking.
- That no live electrical components and wiring are exposed while charging, recovering or purging the system.
- Keep continuity of earthing.

Inspection of Cable

Check the cable for wear, corrosion, overvoltage, vibration and check if there are sharp edges and other adverse effects in the surrounding environment. During the inspection, the impact of aging or the continuous vibration of the compressor and the fan on it should be taken into consideration.

Leakage check of R32 refrigerant

Note: Check the leakage of the refrigerant in an environment where there is no potential ignition source. No halogen probe (or any other detector that uses an open flame) should be used.

Leak detection method:

For systems with refrigerant R32, electronic leak detection instrument is available to detect and leak detection should not be conducted in environment with refrigerant. Make sure the leak detector will not become a potential source of ignition, and is applicable to the measured refrigerant. Leak detector shall be set for the minimum ignitable fuel concentration (percentage) of the refrigerant. Calibrate and adjust to proper gas concentration (no more than 25%) with the used refrigerant.

The fluid used in leak detection is applicable to most refrigerants. But do not use chloride solvents to prevent the reaction between chlorine and refrigerants and the corrosion of copper pipeline.

If you suspect a leak, then remove all the fire from the scene or put out the fire.

If the location of the leak needs to be welded, then all refrigerants need to be recovered, or isolate all refrigerants away from the leak site (using cut-off valve). Before and during the welding, use OFN to purify the entire system.

Removal and Vacuum Pumping

1. Make sure there is no ignited fire source near the outlet of the vacuum pump and the ventilation is well.

2. Allow the maintenance and other operations of the refrigeration circuit should be carried out according to the general procedure, but the following best operations that the flammability is already taken into consideration are the key. You should follow the following procedures:

- Remove the refrigerant.
- Decontaminate the pipeline by inert gases.
- Evacuation.
- Decontaminate the pipeline by inert gases again.
- Cut or weld the pipeline.

3. The refrigerant should be returned to the appropriate storage tank. The system should be blown with oxygen free nitrogen to ensure safety. This process may need to be repeated for several times. This operation shall not be carried out using compressed air or oxygen.

4. Through blowing process, the system is charged into the anaerobic nitrogen to reach the working pressure under the vacuum state, then the oxygen free nitrogen is emitted to the atmosphere, and in the end, vacuum the system.

Repeat this process until all refrigerants in the system is cleared. After the final charging of the anaerobic nitrogen, discharge the gas into the atmosphere pressure, and then the system can be welded. This operation is necessary for welding the pipeline.

Procedures of Charging Refrigerants

As a supplement to the general procedure, the following requirements need to be added:

- Make sure that there is no contamination among different refrigerants when using a refrigerant charging device. The pipeline for charging refrigerants should be as short as possible to reduce the residual of refrigerants in it.
- Storage tanks should remain vertically up.
- Make sure the grounding solutions are already taken before the refrigeration system is charged with refrigerants.
- After finishing the charging (or when it is not yet finished), label the mark on the system.
- Be careful not to overcharge refrigerants.

Scrap and Recovery

Scrap:

Before this procedure, the technical personnel shall be thoroughly familiar with the equipment and all its features, and make a recommended practice for refrigerant safe recovery. For recycling the refrigerant, shall analyze the refrigerant and oil samples before operation. Ensure the required power before the test.

1. Be familiar with the equipment and operation.

2. Disconnect power supply.

3. Before carrying out this process, you have to make sure:

- If necessary, mechanical equipment operation should facilitate the operation of the refrigerant tank.
- All personal protective equipment is effective and can be used correctly.
- The whole recovery process should be carried out under the guidance of qualified personnel.
- The recovering of equipment and storage tank should comply with the relevant national standards.

4. If possible, the refrigerating system should be vacuumized.

5. If the vacuum state can't be reached, you should extract the refrigerant in each part of the system from many places.

6. Before the start of the recovery, you should ensure that the capacity of the storage tank is sufficient.

7. Start and operate the recovery equipment according to the manufacturer's instructions.

8. Don't fill the tank to its full capacity (the liquid injection volume does not exceed 80% of the tank volume).

9. Even the duration is short, it must not exceed the maximum working pressure of the tank.

10. After the completion of the tank filling and the end of the operation process, you should make sure that the tanks and equipment should be removed quickly and all closing valves in the equipment are closed.

11. The recovered refrigerants are not allowed to be injected into another system before being purified and tested.

Note: The identification should be made after the appliance is scrapped and refrigerants are evacuated. The identification should contain the date and endorsement. Make sure the identification on the appliance can reflect the flammable refrigerants contained in this appliance.

Recovery:

- 1.The clearance of refrigerants in the system is required when repairing or scrapping the appliance. It is recommended to completely remove the refrigerant.
- 2.Only a special refrigerant tank can be used when loading the refrigerant into the storage tank. Make sure the capacity of the tank is appropriate to the refrigerant injection quantity in the entire system. All tanks intended to be used for the recovery of refrigerants should have a refrigerant identification (i.e.refrigerant recovery tank).
Storage tanks should be equipped with pressure relief valves and globe valves and they should be in a good condition.
If possible, empty tanks should be evacuated and maintained at room temperature before use.
- 3.The recovery equipment should be kept in a good working condition and equipped with equipment operating instructions for easy access. The equipment should be suitable for the recovery of R32 refrigerants. Besides, there should be a qualified weighting apparatus which can be normally used. The hose should be linked with detachable connection joint of zero leakage rate and be kept in a good condition.
Before using the recovery equipment, check if it is in a good condition and if it gets perfect maintenance. Check if all electrical components are sealed to prevent the leakage of the refrigerant and the fire caused by it. If you have any question, please consult the manufacturer.
- 4.The recovered refrigerant shall be loaded in the appropriate storage tanks, attached with a transporting instruction, and returned to the refrigerant manufacturer. Don't mix refrigerant in recovery equipment, especially a storage tank.
- 5.The space loading R32 refrigeration can't be enclosed in the process of transportation.
Take anti electrostatic measures if necessary in transportation. In the process of transport, loading and unloading, necessary protective measures must be taken to protect the air conditioner to ensure that the air conditioner is not damaged.
- 6.When removing the compressor or clearing the compressor oil, make sure the compressor is pumped to an appropriate level to ensure that there is no residual R32 refrigerants in the lubricating oil. The vacuum pumping should be carried out before the compressor is returned to the supplier. Only the electrical heating method for heating the compressor housing is allowed to speed up the process.
Ensure the safety when discharging oil from the system.

DE-COMMISSIONING, DISMANTLING & DISPOSAL

This product contains refrigerant under pressure, rotating parts, and electrical connections which may be a danger & cause injury.
All work must only be carried out by competent persons using suitable protective clothing and safety precautions.



Read the Manual



Risk of Electric Shock



Unit is Remotely controlled
& may start without warning




1. Isolate all sources of electrical supply to the unit including any control system supplies switched by the unit. Ensure that all points of electrical and gas isolation are secured in the OFF position. The supply cables and gas pipe work may then be disconnected and removed. For points of connection refer to unit installation instructions.
2. Remove all refrigerant from each system of the unit into a suitable container using a refrigerant reclaim or recovery unit. This refrigerant may then be reused, if appropriate, or returned to the manufacturer for disposal. Under NO circumstances should refrigerant be vented to atmosphere. Where appropriate, drain the refrigerant oil from each system into a suitable container and dispose of according to local laws and regulations governing disposal of oily wastes.
3. Packaged units can generally be removed in one piece after disconnection as above. Any fixing down bolts should be removed and then unit lifted from position using the points provided and equipment of adequate lifting capacity. Reference MUST be made to the unit installation instructions for unit weight and correct methods of lifting. Note that any residual or spilt refrigerant oil should be mopped up and disposed of as described above.
4. After removal from position the unit parts may be disposed of according to local laws and regulations.
5. Meaning of crossed Out wheeled dustbin: Do not dispose of electrical appliances as unsorted municipal waste, use separate collection facilities. Contact your local government for information regarding the collection systems available. If electrical appliances are disposed of in landfills or dumps, hazardous substances can leak into the groundwater and get into the food chain, damaging your health and well-being. When replacing old appliances with new ones, the retailer is legally obligated to take back your old appliance for disposals at least free of charge.


- Za vašu praktičnost, molimo vas da pažljivo pročitate ovaj priručnik u skladu sa koracima specifikacijama.
- Molimo vas da ovaj priručnik sigurno sačuvate radi pregleda.

Napomena:

Sve ilustracije u ovom priručniku su samo u svrhu objašnjenja. Vaš klima uređaj može biti malo drugačiji. Stvarni oblik će preovladati. Moguće su promene bez prethodne najave radi budućih poboljšanja.




4/GkW





8/10/12/14/1GkW

Interni raspored: 12~16kW (jednofazni) na primer



Molim vas, uklonite šuplju ploču nakon instalacije



Molimo vas da uklonite podlošku sa noge kompresora (Ukupna količina podloški: 1).

12/14/16kW

NAPOMENA

Slike i funkcija opisane u ovom priručniku obuhvataju komponente rezervnog grejača. Slike u ovom priručniku služe samo kao referenca. Molimo vas da se obratite pažnju na stvarni proizvod.

Jedinica (kW)	Jednofazna							Trofazna										
	4	6	8	10	12	14	16	8	10	12	14	16						
Kapacitet rezervnog grejača	3kW(jednofazna)							9kW(trofazna)										
Rezervni grejač (opciono)																		
Standardna jedinica bez rezervnog grejača. Rezervni grejač može biti integrisan u jedinicu za prilagođene modele (4-16 kW).																		

1 MERE OPREZA ZA BEZBEDNOST

Mere predostrožnosti navedene ovde su podeljene u sledeće tipove. One su veoma važne, stoga budite sigurni da ih pažljivo pratite. Značenja simbola OPASNOST, UPOZORENJE, PAŽNJA i NAPOMENA su sledeća

INFORMACIJA!

Pažljivo pročitajte ove upute pre instalacije. Sačuvajte ovaj priručnik na dostupnom mestu radi buduće reference. Nepropisna instalacija opreme ili dodataka može rezultirati električnim udarom, kratkim spojem, curenjem, požarom ili drugim oštećenjima opreme. Obavezno koristite samo dodatke koje je proizvođač odobrio, a koji su posebno dizajnirani za opremu, i uverite se da instalaciju obavlja stručnjak. Sve aktivnosti opisane u ovom priručniku mora izvršiti ovlašćeni tehničar. Obezbedite odgovarajuću ličnu zaštitnu opremu, poput rukavica i zaštitnih naočara, dok instalirate uređaj ili obavljate aktivnosti održavanja. Za dodatnu pomoć, kontaktirajte svog prodavca.



Upozorenje: Rizik od požara / zapaljivih materijala

UPOZORENJE	Servisiranje se sme vršiti samo prema preporuci proizvođača opreme. Održavanje i popravke koji zahtevaju pomoć drugih stručnih osoba trebalo bi da se obavljaju pod nadzorom osobe koja je kompetentna za rad sa zapaljivim rashladnim sredstvima.
OPASNOST	Označava trenutno opasnu situaciju koja će, ako se ne izbegne, rezultovati smrću ili teškim povredama.
UPOZORENJE	Označava potencijalno opasnu situaciju koja, ako se ne izbegne, može rezultirati smrću ili teškom povredom.
PAŽNJA	Označava potencijalno opasnu situaciju koja, ukoliko se ne izbegne, može rezultirati lakšim ili umerenim povredama. Takođe se koristi kao upozorenje protiv nesigurnih praksi.
NAPOMENA	Označava situacije koje mogu rezultirati isključivo slučajnim oštećenjem opreme ili imovine.

	UPOZORENJE	Ovaj simbol ukazuje da uređaj koristi zapaljivo rashladno sredstvo. U slučaju curenja rashladnog sredstva i izloženosti spoljnem izvoru paljenja, postoji rizik od požara.
	PAŽNJA	Ovaj simbol ukazuje da bi uputstvo za upotrebu trebalo pažljivo pročitati.
	PAŽNJA	Ovaj simbol pokazuje da osoblje za servisiranje treba rukovati ovom opremom uz upućivanje na instalacioni priručnik.
	PAŽNJA	Ovaj simbol ukazuje da su dostupne informacije, poput uputstva za rad ili instalacije.
	PAŽNJA	Ovaj simbol pokazuje da su dostupne informacije, poput uputstva za rad ili instalaciju.

OPASNOST!

Pre dodira električnih terminalnih delova, isključite prekidač napajanja.
Kada su servisni paneli uklonjeni, živi delovi mogu lako biti dodirnuti slučajno.
Nikada ne ostavljajte uređaj bez nadzora tokom instalacije ili održavanja kada je servisni panel uklonjen.
Ne dodirujte vodovodne cevi tokom i neposredno nakon rada, jer cevi mogu biti vrueće i mogu izazvati opekotine na rukama. Da biste izbegli povredu, sačekajte da se cevi vrate na normalnu temperaturu ili obavezno nosite zaštitne rukavice.

UPOZORENJE!

Uklonite i bacite plastične ambalažne vreće tako da deca ne mogu da se igraju s njima. Igra dece s plastičnim vrećama može dovesti do opasnosti od gušenja i smrti.
Sigurno se oslobođite pakirajućih materijala poput eksera i drugih metalnih ili drvenih delova koji mogu prouzrokovati povrede.
Za instalaciju, obratite se svom prodavcu ili kvalifikovanom osobljlu i insistirajte da se posao obavi prema ovom uputstvu. Nemojte samostalno instalirati uređaj, jer nepravilna instalacija može rezultirati curenjem vode, električnim udarom ili požarom.
Obavezno koristite samo navedene dodatke i delove prilikom instalacije. Neprisklada upotreba delova može dovesti do curenja vode, električnog udara, požara ili pada uređaja sa nosača.

Spustite uredaj na podlogu koja može izdržati njegovu težinu. Nedostatak fizičke snage može uzrokovati pad opreme i moguće povrede. Izvedite određene instalacijske radove uz potpuno razmatranje jakog vетра, uragana ili zemljotresa. Nepravilni rad pri instalaciji može rezultirati nesrećama zbog pada opreme.

Obavezno se pobrinite da svi električni radovi obavlja kvalifikovano osoblje u skladu sa lokalnim zakonima i propisima, kao i ovim uputstvom, koristeći poseban krug. Nedovoljni kapacitet napajanja ili nepravilna električna izrada mogu dovesti do električnih udara ili požara.

Obavezno instalirajte prekidač za zaštitu od zemljospoja prema lokalnim zakonima i propisima. Nedostatak instalacije prekidača za zaštitu od zemljospoja može izazvati električne udare i požare.

Proverite da su svii vodovi sigurno postavljeni. Koristite navedene žice i obezbedite da su terminalne veze ili žice zaštićene od vode i drugih nepovoljnih spoljnih sila. Nepotpuna vezu ili postavljanje može izazvati požar.

Prilikom povezivanja napajanja, oblikujte žice tako da prednja ploča može sigurno da se pričvrsti. Ako prednja ploča nije na mestu, može doći do pregrevanja terminala, električnih udara ili požara.

Nakon završetka instalacije, proverite da nema curenja rashladnog sredstva.

Nikada direktno ne dodirujte curenje rashladnog sredstva jer može izazvati ozbiljno ozeb. Ne dodirujte cevi za rashladno sredstvo tokom i odmah nakon rada, jer cevi za rashladno sredstvo mogu biti vruće ili hladne, u zavisnosti od stanja rashladnog sredstva koje teče kroz cevi za rashladno sredstvo, kompresor i druge delove rashladnog kruga. Opekotine ili ozbiljan ozeb su mogući ako dodirnete cevi za rashladno sredstvo. Kako biste izbegli povrede, ostavite cevi da se vrati na normalnu temperaturu ili, ako morate da ih dodirnete, obavezno nosite zaštitne rukavice.

Ne dodirujte unutrašnje delove (pumpu, rezervni grejač, itd.) tokom i odmah nakon rada. Dodirivanje unutrašnjih delova može izazvati opekotine. Kako biste izbegli povrede, ostavite unutrašnjim delovima da se vrati na normalnu temperaturu ili, ako morate da ih dodirnete, obavezno nosite zaštitne rukavice.

PAŽNJA!

Uzemljite uredaj.

Otpor uzemljenja treba biti u skladu sa lokalnim zakonima i propisima. Ne povezujte uzemljenje sa gasnim ili vodovodnim cevima, gromobranima ili uzemljenjem telefonskih kablova. Nepotpuno uzemljenje može izazvati električne udare.

- Gasne cevi: Može doći do požara ili eksplozije ako dođe do curenja gasa.
- Vodovodne cevi: Tvrdi vinilni materijali nisu efikasni za uzemljenje.

• Gromobrani ili uzemljenje telefonskih kablova: Električni prag može abnormalno porasti ako ga pogodi munja.

Instalirajte električni kabl najmanje 3 stope (1 metar) udaljeno od televizora ili radio-aparata kako biste sprečili interferenciju ili buku. (Zavisno o radio talasima, udaljenost od 3 stope (1 metar) možda nije dovoljna da eliminiše buku.)

Ne perite uredaj. To može prouzrokovati električne udare ili požar. Aparat se mora instalirati u skladu s nacionalnim propisima o elektroinstalacijama. Ako je napojni kabl oštećen, mora ga zameniti proizvođač, njegov servisni agent ili slično kvalifikovane osobe kako bi se izbegla opasnost. Ne instalirajte uredaj na sledećim mestima:

- Gde postoji magla mineralnog ulja, prskanje ulja ili pare. Plastični delovi mogu propasti i izazvati njihovo ispadanje ili curenje vode.
- Gde se proizvode korozivni gasovi (kao što je gas sumporne kiseline). Gde korozija bakarnih cevi ili lemljenih delova može izazvati curenje rashladnog sredstva.
- Gde se nalazi mašinerija koja emituje elektromagnetne talase. Elektromagnetični talasi mogu ometati kontrolni sistem i izazvati kvar opreme.
- Gde mogu cureti zapaljivi gasovi, gde je suspendovan ugljenični prah ili zapaljivi prah, ili gde se rukuje lakozapaljivim materijalima kao što su razredivač ili benzin. Ovi tipovi gasova mogu izazvati požar.
- Gde vazduh sadrži visok nivo soli, na primer, blizu okeana.
- Gde napon značajno varira, kao što je slučaj u fabrikama.
- U vozilima ili plovilima.
- Gde postoje kisele ili alkalne pare.

Ovaj uredaj mogu koristiti deca stara 8 godina i stariji, kao i osobe sa smanjenim fizičkim, senzornim ili mentalnim sposobnostima, ili nedostatkom iskustva i znanja, ukoliko su pod nadzorom ili su im pružene instrukcije o sigurnom korišćenju uredaja i razumeju opasnosti koje su uključene. Deca ne bi trebala da se igraju sa uredajem. Čišćenje i održavanje koje obavlja korisnik ne bi trebalo da se vrši bez nadzora dece. Deca treba da budu pod nadzorom kako bi se osiguralo da se ne igraju sa uredajem.

Ako je napojni kabl oštećen, mora ga zameniti proizvođač, njegov servisni agent ili osoba slično kvalifikovana.

ODLAGANJE: Ne odlagati ovaj proizvod kao nesortiran komunalni otpad. Potrebno je posebno prikupljanje takvog otpada radi posebnog tretmana. Električne aparate ne odlagati kao komunalni otpad, koristiti posebne kontejnere za prikupljanje. Kontaktirajte lokalnu vlast radi informacija o dostupnim sistemima prikupljanja. Ako se električni aparati odbacuju na deponiju ili otpad, opasne supstance mogu iscuriti u podzemne vode i ući u lanac ishrane, oštęćujući vaše zdravlje i dobrobit.

Električno ožičenje mora se izvoditi od strane stručnih tehničara u skladu s nacionalnim propisima o ožičenju i ovim elektrohemama. Svi-polni prekidač sa barem 3 mm razmaka u svim polovima i uredaj za zaštitu od struje u slučaju curenja struje (RCD) sa ocenom ne većom od 30mA treba biti ugrađen u fiksno ožičenje prema nacionalnom pravilu.

Potvrdite bezbednost prostora za instalaciju (zidovi, podovi, itd.) bez skrivenih opasnosti poput vode, struje i gase pre postavljanja žica/cevi. Pre instalacije, proverite da li korisnikovo napajanje ispunjava električne zahteve za instalaciju uredaja (uključujući pouzdanu uzemljenost, odsustvo curenja i prečnik žica za električno opterećenje, itd.). Ako se električni zahtevi proizvoda ne ispunjavaju, zabranjena je instalacija proizvoda dok se ne isprave neusaglašenosti.

Prilikom instalacije više klima uredaja na centralizovan način, potvrdite ravnotežu opterećenja trofaznog napajanja, a sprečite da se više uredaja montira na istu fazu trofaznog napajanja.

Instalacija proizvoda treba biti čvrsto fiksirana. Preduzmite mere ojačavanja kad god je to potrebno.

NAPOMENA

O fluoriranim gasovima

- Ovaj klima uredaj sadrži fluorirane gasove. Za specifične informacije o vrsti gasa i količini, molimo pogledajte odgovarajuću oznaku na samom uredaju. Treba poštovati usklađenost sa nacionalnim propisima o gasu.
- Instalacija, servis, održavanje i popravka ovog uredaja moraju biti obavljeni od strane sertifikovanog tehničara.
- Deinstalacija proizvoda i recikliranje moraju biti obavljeni od strane sertifikovanog tehničara.
- Ako sistem ima instaliran sistem za detekciju curenja, mora se proveriti na curenja najmanje svakih 12 meseci. Prilikom provere curenja, snažno se preporučuje pravilno vođenje evidencije svih provera.

2 OPŠTI UVOD


Ovi uređaji se koriste i za grejanje i hlađenje, kao i za domaće bojlere sa topлом vodom. Mogu se kombinovati sa jedinicama za ventilacione zavese, podnim grejanjem, radijatorima visoke efikasnosti pri niskim temperaturama, bojlerima za toplu vodu i solarnim setovima, koji se svi nabavljaju na terenu.

Uz uređaj se isporučuje žičani kontroler.


Ako izaberete ugrađeni rezervni grejač, rezervni grejač može povećati kapacitet grejanja tokom hladnih spoljnih temperatura. Rezervni grejač takođe služi kao rezerva u slučaju kvara i za zaštitu od smrzavanja vodovodnih cevi na spoljoj strani tokom zimskog perioda.

NAPOMENA

- Maksimalna dužina komunikacionih kablova između unutrašnje jedinice i kontrolera je 50 metara.
- Električni kablovi i komunikacioni kablovi moraju biti postavljeni odvojeno, ne smeju se nalaziti u istoj cevi. U suprotnom, može doći do elektromagnetne interferencije. Električni kablovi i komunikacioni kablovi ne smeju dolaziti u kontakt sa cevima za rashladno sredstvo kako bi se sprečilo oštećenje kablova od visokotemperaturne cevi.
- Komunikacioni kablovi moraju koristiti zaštićene linije.



1. Kapacitet grejne pumpe
2. Potrebna snaga za grejanje (zavisno od lokacije).
3. Dodatna snaga za grejanje koju obezbeđuje rezervni grejač.



Pomoćni grejač treba biti instaliran ispod sonde za temperaturu. Izmenjivač topline (cev) takođe treba biti instaliran ispod sonde za temperaturu. Dužina cevi između spoljne jedinice i bojlera treba biti manja od 5 metara.

	Monoblok jedinica	4~6kW	8-10kW	12-16kW
Zapremina rezervoara/L	Preporučeno	100-250	150-300	200-500
Površina izmenjivača topline/m (Inox cev)	Minimum	1.4	1.4	1.6
Površina izmenjivača topline/m ² (Cevi sa emajlom)	Minimum	2.0	2.0	2.5

Termostat za prostor (isporučuje se sa terenom)

Termostat za prostor može se povezati s uređajem (termostat za prostor treba držati dalje od izvora grejanja prilikom odabira mesta za instalaciju).

Solarni set za bojler za topalu vodu (isporučuje se sa terenom)


Opcioni solarni set može se povezati s uređajem.

Radni opseg

Izlazna voda (režim grejanja)	+25 ~ +65°C
Izlazna voda (režim hlađenja)	+5- +25°C
Topla sanitarna voda	+30- +60°C
Temperatura okoline	-25 ~ +43 °C
Pritisak vode	0.1-0.3 MPa
	4kW
	6kW
Protok vode	BkW
	10kW
	12kW
	14kW
	16kW


Jedinica ima funkciju sprečavanja smrzavanja koja koristi topotnu pumpu ili rezervni grejač (prilagođeni model) kako bi održala sigurnost vodovodnog sistema od smrzavanja u svim uslovima. Pošto može doći do prekida napajanja kada je jedinica nenadzirana, predlaže se upotreba prekidača protoka protiv smrzavanja u vodovodnom sistemu. (Pogledajte odeljak 9.4 "Vodovod").

U režimu hlađenja, opseg temperature protoka vode (TW02) u zavisnosti od različite spoljne temperature (Tao) naveden je u nastavku:




Raspon rada toploplne pumpe sa mogućim ograničenjem i zaštitom.

Uključena u režimu grejanja, temperatura protoka vode (Tw02) varira u zavisnosti od različitih spoljnih temperatura (Tao), prikazano ispod:



	Ako je IBH/ANS podešavanje validno, samo će se IBH/ANS uključiti.
	Ako je IBH/AHS podešavanje nevažeće, samo će se uključiti dizalica toplove. Ograničenja i zaštita mogu se javiti tokom rada dizalice toplove.
	Raspon rada toploplne pumpe sa mogućim ograničenjem i zaštitom. Toploplna pumpa se isključuje, a samo IBH/AHS se uključuje.
	Maksimalna linija temperature ulazne vode za rad toploplne pumpe.

U režimu pripreme tople vode (DHW), opseg temperature protoka vode (TW02) u zavisnosti od različite temperature spoljnog vazduha (Tao) naveden je u nastavku:



	Ako je IBH/ANS podešavanje validno, samo će se IBH/ANS uključiti.
	Ako je IBH/AHS podešavanje nevažeće, samo će se uključiti dizalica toplove. Ograničenja i zaštita mogu se javiti tokom rada dizalice toplove.
	Opseg rada dizalice toplove s mogućim ograničenjem i zaštitom. Dizalica toplove se isključuje, samo IBH/AHS se uključuje.
	Maksimalna temperatura ulazne vode za rad dizalice toplove.

3 DODACI

3.1 Dodaci isporučeni uz jedinicu

Montažni priključci		
Ime	Oblik	Količina
Instalacija i korisničko uputstvo (ovaj priručnik)		1
Operativno uputstvo		1
Tehničko uputstvo		1
Filter Y oblika		1
Žičani kontroler		1
Termistor za bojler za toplu vodu u domaćinstvu		1
Drenažno crevo		2
Energetska oznaka		1
Gumeni čep za vodu		2
Žičani komunikacioni kabl za kontroler		1
Adapter za komunikaciju žičanog kontrolera		1

3.2 Dodaci dostupni od dobavljača

Termistor za balansni rezervoar (Twt-BT)		1
Produžni kabl za Tbt1		1
Termistor za temperaturu protoka Zone 2 (Twi-FLH)		1
Produžni kabl za Twi-FLH		1
Termistor za solarnu temperaturu (Tsolar)		1
Produžni kabl za Tsolar		1

Termistor i produžni kabl za Twt-BT, Twi-FLH, Tsolar mogu se deliti ako su ove funkcije potrebne istovremeno, i molimo da dodatno naručite ove termistore i produžni kabl dužine 10 m za senzorski kabl.

4 PRE INSTALACIJE

Obavezno potvrdite model i serijski broj jedinice.

Rukovanje


Zbog relativno velikih dimenzija i teške mase, jedinica bi trebalo da se rukuje samo pomoću alata za podizanje sa sajlama. Sajle se mogu postaviti u predviđene rukave na osnovnom ramu koji su posebno napravljeni u tu svrhu.




Da biste izbegli povredu, ne dodirujte usisni otvor ili aluminijumske rešetke uređaja.

Ne koristite hvataljke na rešetkama ventilatora kako biste izbegli oštećenje.

Uredaj je vrlo težak na vrhu! Sprečite da uredaj ne padne usled nepravilnog nagiba tokom rukovanja.



Položaj težišta za različite jedinice može se videti na slici ispod.



600-1000 nm

Model	A	B	C
4/6kW	300	540	200
8/10kW	340	580	280
12/14/16kW	300	605	245

5 VAŽNE INFORMACIJE O RASHLADNOM SREDSTVU

Ovaj proizvod sadrži fluorisane gasove, čije ispuštanje u vazduh je zabranjeno.

Tip rashladnog sredstva: R32; Zapremina GWP: 675.

GWP = Globalni potencijal za globalno zagrevanje.

Model	Zapremina fabrički napunjene rashladne sredstva u jedinici	
	Rashladno sredstvo /kg	Tone CO ₂ ekvivalenta
4kW	1.05	0.71
6kW	1.05	0.71
8kW	1.45	0.98
10kW	1.45	0.98
12kW	1.70	1.15
14kW	1.70	1.15
16kW	1.70	1.15

PAŽNJA!

Čestoća provere curenja rashladnog sredstva

- Za uređaje koji sadrže fluorirane gasove staklenika u količinama od 5 tona ekvivalenta CO₂ ili više, ali manje od 50 tona ekvivalenta CO₂, najmanje svakih 12 meseci, ili gde je instaliran sistem za detekciju curenja, najmanje svakih 24 meseca.
- Za uređaje koji sadrže fluorirane gasove staklenika u količinama od 50 tona ekvivalenta CO₂ ili više, ali manje od 500 tona ekvivalenta CO₂, najmanje svakih šest meseci, ili gde je instaliran sistem za detekciju curenja, najmanje svakih 12 meseci.
- Za uređaje koji sadrže fluorirane gasove staklenika u količinama od 500 tona ekvivalenta CO₂ ili više, najmanje svakih tri meseca, ili gde je instaliran sistem za detekciju curenja, najmanje svakih šest meseci.
- Ovaj klima uređaj je hermetički zatvorena oprema koja sadrži fluorirane gasove staklenika.
- Samo sertifikovana osoba ima dozvolu za instalaciju, rad i održavanje.

6 LOKACIJA INSTALACIJE


UPOZORENJE!

U uređaju se nalazi zapaljivo rashladno sredstvo i trebalo bi ga instalirati na dobro provetrenom mestu. Ako se uređaj instalira unutra, mora se dodati dodatni uređaj za detekciju rashladnog sredstva i ventilaciona oprema u skladu sa standardom EN378. Obavezno preuzmite odgovarajuće mere kako biste sprečili da uređaj bude korišćen kao sklonište za male životinje.

Male životinje koje dolu u dodir sa električnim delovima mogu izazvati kvar, dim ili požar. Molimo vas da uputite kupca da održava prostor oko uređaja čistim.


Izaberite lokaciju za instalaciju gde su ispunjeni sledeći uslovi i gde se slaže sa odobrenjem kupca.

- Mesta koja su dobro provetrena.
- Mesta gde jedinica ne smeta komšijama.
- Sigurna mesta koja mogu nositi težinu i vibracije jedinice i gde se jedinica može instalirati na ravnomernom nivou.
- Mesta gde nema mogućnosti curenja zapaljivog gasa ili proizvoda.
- Oprema nije namenjena za upotrebu u potencijalno eksplozivnoj atmosferi.
- Mesta gde je obezbeden dovoljan prostor za servisiranje.
- Mesta gde dužine cevi i provodnika jedinica dolaze unutar dozvoljenih granica.
- Mesta gde voda koja curi iz jedinice ne može prouzrokovati oštećenje lokacije (npr. u slučaju začepljenog odvoda).
- Mesta gde se kiša može izbegavati koliko je to moguće.
- Ne instalirajte jedinicu na mestima koja se često koriste kao radni prostor. U slučaju radova (npr. brušenje itd.) gde se stvara puno prašine, jedinica mora biti pokrivena.
- Ne postavljajte nikakve predmete ili opremu na vrh jedinice (gornju ploču).
- Nemojte se penjati, sedeti ili stajati na vrhu jedinice.
- Pazite da se preduzmu dovoljne mere opreza u slučaju curenja rashladnog sredstva prema relevantnim lokalnim zakonima i propisima.
- Ne instalirajte jedinicu blizu mora ili mesta gde ima korozivnih gasova. Prilikom instalacije jedinice na mestu izloženom jakom vetrusu, obratite posebnu pažnju na sledeće. Jaki vetrovi od 5 m/s ili više koji duvaju prema izlazu vazduha jedinice izazivaju kratak spoj (usisavanje ispušnog vazduha), a to može imati sledeće posledice:
- Pogoršanje radne sposobnosti.
- Često ubrzanje smrzavanja pri grejanju.
- Poremećaj rada zbog porasta visokog pritiska.
- Kada jak vjetar neprestano duva na prednju stranu jedinice, ventilator može početi vrlo brzo rotirati dok se ne pokida. U normalnim uslovima, pogledajte figure ispod za instalaciju jedinice.




Jedinica	A (mm)
4-6kW	≥300
8-16kW	≥300

U slučaju jakog veta i kada se pravac vetra može predvideti, обратите se slikama ispod za instalaciju uređaja (bilo koja je prihvativljiva). Okrenite stranu izduvnog vazduha prema zidu zgrade, ogradu ili ekranu.



Jedinica	B (mm)
4-6kW	≥1000
8-16kW	≥1500

Proverite da ima dovoljno prostora za instalaciju.
Postavite izlaznu stranu pod pravim uglom u odnosu na smer veta.



Pripremite odvodni kanal oko temelja kako biste odvodili otpadnu vodu sa oko uređaja. Ako voda ne otiče lako sa uređaja, montirajte uređaj na temelju od betonskih blokova, itd. (visina temelja trebala bi biti oko 100 mm ili 3,93 inča). Ako postavljate uređaj na okvir, molimo vas da instalirate vodootpornu ploču (oko 100 mm) na donjoj strani uređaja kako biste sprecili ulazak vode sa niže strane. Prilikom postavljanja uređaja na mestu koje je često izloženo snegu, obratite posebnu pažnju na podizanje temelja što je više moguće.

Ako postavljate uređaj na okvir zgrade, molimo vas da instalirate vodootporu tepsiiju (terenski izvor) (oko 100mm, na donjoj strani uređaja) kako biste izbegli curenje odvodne vode. (Pogledajte sliku desno).



6.1 Izbor lokacije u hladnim klimatskim uslovima

Pogle odeljakdajte "Rukovanje" u delu "4 Pre instalacije".

NAPOMENA


Prilikom rada uređaja u hladnim klimama, obavezno pratite navedene instrukcije ispod.

Kako biste sprecili izloženost vetrui, instalirajte uređaj sa usisnom stranom okrenutom prema zidu.

Nikada ne postavljajte uređaj na mestu gde bi usisna strana mogla biti direktno izložena vetrui.

Da biste sprecili izloženost vetrui, postavite deflektor na strani izduvnog vazduha uređaja.

Na područjima sa obilnim snegom, vrlo je važno odabrati mesto za instalaciju gde sneg neće uticati na uređaj. Ako je moguće padanje snega sa strane, pobrinite se da kalem izmenjivača toplove ne bude pogoden snegom (po potrebi izgradite lateralni krov).



1. Construct a large canopy.

2. Construct a pedestal.


Install the unit high enough off the ground to prevent it from being buried in snow.

6.2 Selecting a location in hot climates

Pošto se temperatura na otvorenom meri putem termistora vazduha na spoljnoj jedinici, pobrinite se da instalirate spoljnju jedinicu u hladovinu ili da se postavi nadstrešnica kako bi se izbegla direktna sunčeva svetlost, kako ne bi bila izložena uticaju sunčeve toplosti, inače može doći do oštećenja uređaja. Takođe, postavite je dovoljno visoko od zemlje kako biste je zaštitili od zatrpanja snegom.

7 POSTUPCI PRILIKOM MONTAŽE

7.1 Dimenzijs




Model	A	B	C	D	E	F	G	H	I	J
4/6kW	1257	388	320	261	735	261	99	195	766	136
8/10/12/14/16kW	1377	520	421	274	830	274	99	216	934	120

7.2 Preduslovi za instalaciju


Proverite čvrstoću i ravnotežu instalacione podlove kako uredaj ne bi izazivao vibracije ili buku tokom rada.

U skladu sa osnovnim crtežom na slici, čvrsto pričvrstite uređaj pomoću temeljnih vijaka. (Pripremite četiri kompleta od 10 ekspanzionih vijaka, matica i podloški, koji su lako dostupni na tržištu.)

Zavijte temeljne vijke dok njihova dužina ne bude 20 mm ispod površine temelja.



7.3 Pozicija odvoda




NAPOMENA

Ako voda ne može oticati tokom hladnog vremena, čak i kada je velika odvodna rupa otvorena, neophodno je instalirati električni grejni kabl.


7.4 Zahtevi za prostor za servisiranje

7.4.1 U slučaju postavljanja jedne jedinice na drugu

1) U slučaju da postoje prepreke ispred izlazne strane.




2) U slučaju da postoje prepreke ispred ulaznog vazduha.



Jedinica	A(mm)
4~6kW	1000
8-16kW	1500

7.4.2. U slučaju instalacije više redova (za krovnu upotrebu, itd.)

U slučaju instalacije više jedinica u lateralnom povezivanju po redu.




Jedinica	A (mm)	B1 (mm)	B2 (mm)	C (mm)
4-6kW	≥2500	≥1000	≥300	≥600
8~16kW	≥3000	≥1500		

8 TIPIČNE PRIMENE

8.1 Samo grejanje prostora

Termostat u sobi se koristi kao prekidač. Kada termostat u sobi zatraži grejanje, uređaj radi kako bi postigao ciljnu temperaturu vode postavljenu na žičanom kontroleru. Kada temperatura u sobi dostigne postavljenu temperaturu termostata, uređaj se zaustavlja. Kada grejni terminal koristi Sistem podnog grejanja i grejni radijator istovremeno, dva kraja podnog grejanja i radijatora niskih temperatura zahtevaju različite radne temperature vode. Kako bi se istovremeno zadovoljile ove dve različite radne temperature vode, potrebno je instalirati mešalicu i pumpu za mešanje vode na ulazu i izlazu podnog grejanja. Temperatura izlazne vode uređaja postavlja se na temperaturu vode koja je potrebna za grejni radijator, a mešać vode i pumpa za mešanje vode postavljaju se kako bi se smanjila temperatura ulazne vode podnog grejanja.




NAPOMENA

1	Spoljna jedinica	9	Distributer
2	Zamena grejača ploče	10	Kolektor
3	Rezervni električni grejač (opciono)	11	Ventil za obilazak
4	Unutrašnja cirkulaciona pumpa	12	Spoljna cirkulaciona pumpa
5	Žičani kontroler	ROT	Radijator
6	Zaustavni ventil (lokalni)	FLH	Sistem podnog grejanja
7	Balansni voden rezervoar	RT	Sobni termostat
8	Ventil za mešanje i pumpa za mešanje vode		

8.2 Grejanje prostora i priprema tople vode

Termostati prostorija takođe mogu biti povezani sa motorizovanim ventilom. Temperatura svake prostorije reguliše se putem motorizovanog ventila na njenom vodovodnom krugu. Topla voda se isporučuje iz rezervoara za toplu vodu povezanog sa hidrauličnim modulom. Rezervoar za vodu treba da ima ugrađen temperaturni senzor koji se povezuje sa hidrauličnim modulom. Potreban je i Bajpas ventil.




 NAPOMENA

1	Spoljna jedinica	11	Kolektor
2	Razmenjivač toplotne ploče	12	Ventil za obilazak (bypass ventil)
3	Rezervni električni grejač	13	Električno grejanje
4	Unutrašnja cirkulaciona pumpa	14	Rezervoar za topлу vodu
5	Žičani kontroler	15	Spirala u rezervoaru vode
6	Ventil za zaustavljanje (isporučuje se na terenu)	16	Spoljna cirkulaciona pumpa
7	Motorizovani trosmerni ventil	ROT	Grejanje radijatora
8	Balansni voden rezervoar	FLH	Petlje podnog grejanja
9	Mešajući ventil i pumpa za mešanje vode	RT	Sobni termostati
10	Distributer		

8.3 Grejanje prostora, hlađenje prostora i topla voda


Podni grejni krugovi, grejni radijatori i ventilkonvektorske jedinice koriste se za grejanje prostora, dok se ventilkonvektorske jedinice koriste za hlađenje prostora. Topla voda za domaćinstvo dolazi iz bojlera za toplu vodu povezаног sa hidrauličnim modulom. Uredaj prelazi u režim grejanja ili hlađenja prema temperaturi detektovanoj termostatom u prostoriji. U režimu hlađenja prostora, dvostruki ventil se zatvara kako bi se sprecilo unošenje hladne vode u podne grejne krugove i grejne radijatore.


 NAPOMENA

1	Spoljna jedinica	12	Distributer
2	Zameni grejača ploče	13	Distributer
3	Rezervni električni grejač (opciono)	14	Bajpas ventil
4	Unutrašnja cirkulaciona pumpa	15	Električno grejanje
5	Žičani kontroler	16	Rezervoar za toplu vodu
6	Zaustavni ventil	17	Spirala u rezervoaru vode
7	Motorizovani ventil sa tri položaja	ROT	Radijator
8	Balansirani voden rezervoar	FLH	Sistem podnog grejanja
9	Spoljašnja cirkulaciona pumpa	FCU	Ventilatorske jedinice
10	Dvoploni ventil	RT	Sobni termostat
11	Ventil za mešanje i pumpa za mešanje vode		

8.4 Grejanje prostora i hlađenje prostora

Podni grejni krugovi, grejni radijatori i ventilokonvektorske jedinice koriste se za grejanje prostora, dok se ventilokonvektorske jedinice koriste za hlađenje prostora. U režimu hlađenja prostora, dvosmerni ventil se zatvara kako bi se spričilo unošenje hladne vode u podne grejne krugove i grejne radijatore.




NAPOMENA

1	Spoljna jedinica	10	Ventil za mešanje i pumpa za mešanje vode
2	Zamena grejača ploče	11	Distributer
3	Rezervni električni grejač (opciono)	12	Distributer
4	Unutrašnja cirkulaciona pumpa	13	Bajpas ventil
5	Žičani kontroler	RDT	Radijator
6	Zaustavni ventil	FLH1n	Sistem podnog grejanja
7	Balansirani voden rezervoar	FCU	Ventilatorske jedinice
8	Spoljašnja cirkulaciona pumpa	RT	Sobni termostat
9	Dvoploni ventil		

8.5 Pomoći izvor topline obezbeđuje samo grejanje prostora

Korisnici takođe mogu koristiti samo gasne bojlere za grejanje.




 NAPOMENA

1	Spoljna jedinica	10	Distributer
2	Zamena grejača ploče	11	Kolektor vode
3	Rezervni električni grejač (opciono)	12	Bajpas ventil
4	Unutrašnja cirkulaciona pumpa	13	Spoljašnja cirkulaciona pumpa
5	Žičani kontroler	ROT	Radijator
6	Zaustavni ventil	FLH	Sistem podnog grejanja
7	Jednosmerni ventil	AHS	Izvor pomoćnog grejanja
8	Balansirani voden rezervoar	RT	Sobni termostat
9	Ventil za mešanje i pumpa za mešanje vode		

8.6 Grejanje prostora putem petlji za Sistem podnog grejanja i ventilator-kalem jedinica

Podni grejni krugovi i ventilkonvektorske jedinice zahtevaju različite radne temperature vode. Da bi se postigli ova dva postavljena cilja, potrebna je mešajuća stanica. Termostati za svaku zonu su opciona.


Temperatura izlazne vode uređaja postavlja se na temperaturu vode potrebnu za ventilkonvektorskiju jedinicu, a mešna ventila i pumpa za mešanje postavljaju se kako bi se smanjila temperatura ulazne vode podnog grejanja.


 NAPOMENA

1	Spoljna jedinica	9	Ventil za mešanje i pumpa za mešanje vode
2	Zamena grejača ploče	10	Distributer
3	Rezervni električni grejač (opciono)	11	Distributer
4	Unutrašnja cirkulaciona pumpa	12	Bajpas ventil
5	Žičani kontroler	FCU	Ventilatorske jedinice
6	Zaustavni ventil	FLH	Sistem podnog grejanja
7	Balansirani voden rezervoar	RT	Sobni termostat
8	Spoljašnja cirkulaciona pumpa		

8.7 Grejanje prostora, hlađenje prostora i priprema tople vode kompatibilni sa solarnim bojlerom

Podni grejni krugovi, grejni radijatori i ventilokonvektorske jedinice koriste se za grejanje prostora, dok se ventilokonvektorske jedinice koriste za hlađenje prostora. Temperatura u bojleru za toplu vodu kontroliše se hidrauličkim modulom. Potrebno je postaviti temperaturni senzor u bojleru za topalu vodu i povezati ga sa hidrauličkim modulom. Kada se detektuje da je temperatura u bojleru za topalu vodu niža od postavljene temperature i ispunjavaju se uslovi za aktivaciju solarnog toplole vode, uključuje se pumpa za solarnu vodu kako bi se ostvarila funkcija solarnog toplole vode.




NAPOMENA

1	Spoljašnja jedinica	13	Kolektor
2	Zamenjujući grejač	14	Bajpas ventil
3	Rezervni električni grejač (opcionalno)	15	Električno grejanje
4	Unutrašnja cirkulaciona pumpa	16	Rezervoar za topalu vodu
5	Žičani kontroler	17	Kalem 1 u vodenom posudi
6	Zaustavni ventil	18	Kalem 2 u vodenom posudi
7	Motorizovani ventil sa tri položaja	19	Solarna vodena pumpa
8	Balansirani voden rezervoar	20	Solarni panel
9	Spoljašnja cirkulaciona pumpa	ROT	Radijator
10	Dvoploni ventil	FLH	Sistem podnog grejanja
11	Ventil za mešanje i pumpa za mešanje vode	FCU	Ventilatorske jedinice
12	Distributer	RT	Sobni termostat

8.8 Grejanje prostora pomoću topotne pumpe i AHS (sistema za rukovanje vazduhom), hlađenje prostora pomoću topotne pumpe i solarno za toplu vodu

Kada grejanje nije dovoljno, gasni kotao (AHS) se koristi kao dodatni izvor toplove, a Sistem podnog grejanja ili ventilokonvektorske jedinice ili radijatori niskih temperatura koriste se za grejanje prostora (takođe se mogu koristiti u kombinaciji sa različitim vrstama terminala). Ventilokonvektorska jedinica se koristi za hlađenje prostora. Temperatura u bojleru za toplu vodu kontroliše se hidrauličkim modulom. Potrebno je postaviti temperaturni senzor u bojleru za toplu vodu i povezati ga sa hidrauličkim modulom. Kada se detektuje da je temperatura u bojleru za toplu vodu niža od postavljene temperature i ispunjavaju se uslovi za aktivaciju solarnog toplove vode, uključuje se pumpa za solarnu vodu kako bi se ostvarila funkcija solarnog toplove vode.



NAPOMENA

1	Spoljna jedinica	14	Kolektor vode
2	Zamena grejača ploče	15	Bajpas ventil
3	Rezervni električni grejač (opciono)	16	Električno grejanje
4	Unutrašnja cirkulaciona pumpa	17	Rezervoar za toplu vodu
5	Žičani kontroler	18	Kalem 1 u vodenoj posudi
6	Zaustavni ventil	19	Kalem 2 u vodenoj posudi
7	Motorizovani ventil sa tri položaja	20	Solarna vodena pumpa
8	Jednosmerni ventil	21	Solarni panel
9	Balansirani vodeni rezervoar	ROT	Radijator
10	Spolašnja cirkulaciona pumpa	FLH	Sistem podnog grejanja
11	Jednosmerni ventil	FCU	Ventilatorske jedinice
12	Ventil za mešanje i pumpa za mešanje vode	RT	Sobni termostat
13	Distributer		

UPOZORENJE!

Obavezno pravilno povežite priključke 3MV1/2MV/3MV2 na žičanom upravljaču, molimo vas da se pozovete na odeljak 9.3.


Zahtev za zapreminu balansnog rezervoara

BR.	Model unutrašnje jedinice	Balansni rezervoar(L)
1	4~6kW	≥25
2	8~16kW	≥40


9 PREGLED JEDINICE

9.1 Rastavljanje jedinice

Vrata 1 Za pristup kompresoru i električnim delovima



4/6kW




8/10/12/14/16kW

UPOZORENJE!


Isključite svu struju - tj. napajanje jedinice i napajanje rezervnog grejača i rezervoara za toplu vodu (ako je primenljivo) - pre nego što skinete vrata 1. Delovi unutar jedinice mogu biti vrući.

9.2 Glavne komponente

9.2.1 Hidraulični modul



Bez rezervnog grejača, na primer (opciono)




Sa rezervnim grejačem, na primer (opciono)

Šifra	Montažna jedinica	Objašnjenje
1	Automatski ventil za izduvavanje vazduha	Preostali vazduh u vodenom krugu će se automatski ukloniti preko automatskog ventila za ispuštanje vazduha
2	Unutrašnji rezervni grejač	Rezervni grejač sastoji se od električnog grejnog elementa koji će pružiti dodatni kapacitet grejanja vodene mreže ako kapacitet grejanja uređaja nije dovoljan zbog niskih temperatura na otvorenom, takođe štiti spoljne vodovodne cеви od smrzavanja tokom hladnih perioda.
3	Prekidač protoka	Ako je protok vode ispod 0.6 m3/h, prekidač protoka će se otvoriti (16 kW). Ako je protok vode ispod 0.36 m3/h, prekidač protoka će se otvoriti (6 kW).
4	Cev za izlaz vode	/
5	Cev za ulaz vode	/
6	Cev za tečni rashladni fluid	/
7	Pumpa_i	Pumpa cirkuliše vodu u vodenoj cevi.
8	Cev za tečni rashladni fluid	/
9	Senzori temperature	Pet senzora temperature određuju temperaturu vode i rashladnog sredstva na različitim tačkama (9.1; 9.2; 9.3; 9.4; 9.5)
10	Drenažni otvor	/
11	Ventil za oslobođanje pritiska	Ventil za oslobođanje pritiska sprečava prekomerni pritisak vode u vodovodnom krugu otvaranjem na 43.5 psi(g)/0.3 MPa(g) i ispuštanjem određene količine vode
12	Rekuperator topline pločasti tip	Razmena topline između vode i rashladnog sredstva
13	Proširni sud (8 litara)	/

9.3 Elektronska kontrolna kutija


Slika je samo za referencu, molimo vas da obratite pažnju na stvarni proizvod.




Opis komponenti:

KM1	AC kontaktor1
KM2	AC kontaktor2
KM3	AC kontaktor3
TCO	Termostat
ATCO	Automatski termostat
AFLP	Prekidač niskog pritiska protiv smrzavanja
FLS	Prekidač protoka vode
EH	Električni grejač
XT1	Terminalna ploča napajanja
XT2	Terminalna ploča (32P)
3WV1	Trosmerni ventil 1
3WV2	Trosmerni ventil 2
2WV	Dvopolni ventil
KM4	Kontaktor pumpe zone 1 AC kontaktor4
KM5	Kontaktor pumpe cevi za toplu vodu AC kontaktor5
KM6	Električno grejanje za AC kontaktor rezervoara za vodu 6
KM8	Kontaktor pumpe solarnog panela AC kontaktor8
KM9	Kontaktor pumpe zone 2 AC kontaktor9
KM10	Kontaktor dodatnog izvora topline AC kontaktor10
TWO1	Senzor temperature izlazne vode iz izmenjivača topline ploče
TWO2	Senzor temperature izlazne vode od električnog grejanja
TWI	Senzor temperature ulazne vode u izmenjivač topline ploče
TICO	Senzor izlazne temperature isparivača
TICI	Senzor ulazne temperature isparivača
TWT_BT	Senzor temperature balansnog rezervoara
TWT_FLH	Senzor temperature ulaza vode za Sistem podnog grejanja
TWT	Senzor temperature vode u rezervoaru
ROOM	Senzor temperature u sobi
TSOLAR	Senzor temperature solarnog panela
T1	Senzor temperature
T2	Senzor usisa kompresora
T3	Senzor odmrzavanja
T4	Senzor sredine kondenzatora
T5	Senzor ispuštanja


Opis pozicije




4~6kW (jednofazna)




8~16kW (jednofazna)




8~10kW (trofazna)




12~16kW (trofazna)



Kontrolna tabela 1



Kontrolna tabela 2




Ekspanzioni
panel

Napomena:


1. Uputstva za ožičenje XT12 su namenjena korisničkom ožičenju (ožičavanje prema korisniku).
 2. Isključite napajanje prilikom povezivanja kablova.
 3. Neki modeli nemaju sadržaj unutar isprekidanog okvira.

RD:Cveuna
BU:Plava
WH:Bela
GN:Zelena
YE:Žuta
VY:Žuta/Zelena
C:HЛАДЕНJE
H:GREJANJE
SG: Solarna e električna energija
EVĐ:Komeričljana električna energija


8~16kW(jednofazna)



8-10kW (trifazna)



12-16kW(trifazna)



Napomena:

1. Upustava za povezivanje XT2 su za korisničko povezivanje (povezivanje prema korisniku);
 2. Isključite napajanje priklom povezivanja kablova;
 3. Neki modeli nemaju sadržaj unutar iscrtanog okvira.


C:\HLABENJE H:\GREJANJ
SG: Solarna električna energija
EVD: Komercijalna struja

C:HLABENJE H:GREJANJ
SG: Solarna električna energija


三

9.3.1 Specifikacije standardnih komponenata za žičano povezivanje

Povezivanje glavnog napajanja opreme



Jednofazna struja




Trofazna struja

Navedene vrednosti su maksimalne vrednosti (videti električne podatke za tačne vrednosti).

Jedinica	6kW(3kW-1 PH grejač)	10kW(3kW-1PH grejač)	10kW (9kW-3PH grejač)	16kW(3kW-1PH grejač)	16kW(9kW-3PHgrejač)
1PH-večina žice(mm^2)	6.0	6.0	4.0	10.0	/
3PH-večina žice(mm^2)	/	/	4.0	/	6.0

PAŽNJA!

Prilikom povezivanja na terminal napajanja, koristite kružni žičani terminal sa izolacionim omotačem (pogledajte Sliku 8.1). Koristite napojni kabl koji odgovara specifikacijama i čvrsto povežite napojni kabl. Kako biste sprečili da kabl bude izvučen spoljnom silom, pobrinite se da je čvrsto pričvršćen.




NAPOMENA

Prekidač za prekid strujnog kola zbog zemljospaja mora biti prekidač visoke brzine od 30 mA (<0.1 s). Fleksibilni kabl mora zadovoljiti standarde 60245IEC (H05VV-F).

9.3.2 Povezivanje sa drugim komponentama



Port pruža signal sa naponom od 220V. Ako je struja opterećenja manja od 0.2A, opterećenje se može direktno povezati sa portom. Ako je struja opterećenja 0.2A, potreban je AC kontaktor za povezivanje sa opterećenjem.

1) Za signal solarnog ulaza



Napon	220-240VAC
Maksimalna radna struja (A)	0.2
Veličina žice (mm^2)	0.75

2) Za 3-smerni ventil 3WV1, 2-smerni ventil 2WV, 3-smerni ventil 3WV2 i solarnu pumpu




Napon	220-240VAC
Maksimalna radna struja (A)	0.2
Veličina žice (mm ²)	0.75

a) Postupak

Povežite kabl sa odgovarajućim terminalima kako je prikazano na slici.
Sigurno fiksirajte kabl.

3WV1: Motorizovani trosmerni ventil
2WV: Dvopolni ventil
3WV2: Mešajući ventil


3) Za pumpu Zone 1 i pumpu DHW cevi:



Napon	220-240VAC
Maksimalna radna struja (A)	0.2
Veličina žice (mm ²)	0.75


Pumpa Zone 1: Spoljni cirkulaciona pumpa;
KM4: Kontaktor4 za spoljni cirkulacionu pumpu Zone1
KMS: Kontaktor5 za pumpu za DHW cevi

4) Za dodatni grejač rezervoara:



Napon	220-240VAC
Maksimalna radna struja (A)	0.2
Veličina žice (mm ²)	0.75

5) Za pumpu zone 2 i kontrolu dodatnog izvora toplote:



Napon	220-240VAC
Maksimalna radna struja (A)	0.2
Veličina žice (mm ²)	0.75
Tip signala za kontrolni port	Tip 2

Zona 2 pumpa: mešajući ventil


KM9: Zona 2 pumpa AC kontaktor 9

Kontrola dodatnog izvora topline: AHS

KM10: kontrola AC kontaktora 10 za dodatni izvor topline




⚠️ UPOZORENJE!

Ovaj deo se odnosi samo na osnovnu verziju. Za Prilagođenu verziju, jer postoji intervalni rezervni grejač u jedinici, unutrašnja jedinica ne bi trebalo da bude povezana sa dodatnim izvorom topline.

6) Za pametne mrežePametna mreža
(nizak napon)

Ovaj uređaj ima funkciju pametne mreže, sa dva priključka na PCB-u za povezivanje signala SG (Smart Grid) i EVU (Electric Vehicle Usage) kao što sledi:

1. Kada je signal EVU uključen, uređaj će raditi na sljedeći način:
Način zagrevanja vode (DHW) će se uključiti, a postavljena temperatura će automatski biti promenjena na 70°C. Takođe, TBH će raditi kako sledi: Kada je $T_5 < 69$, TBH će biti uključen. Kada je $T_5 = 2$ i $T_5 > 70$, TBH će biti isključen.
Uredaj će raditi u režimu hlađenja/grejanja prema normalnoj logici.
2. Kada je EVU signal isključen, a SG signal je uključen, uređaj će raditi normalno.
3. Kada su EVU signal i SG signal isključeni, režim grejanja vode (DHW) će biti isključen, TBH će biti nevažeći, a funkcija dezinfekcije će biti onemogućena. Maksimalno vreme rada za hlađenje/grejanje je "SG RUNNING TIME", nakon čega će uređaj biti isključen.

7) Sobni termostat (nizak napon)**8) Sobni termostat (visoki napon)****9) Za modbus**

9.4 Vodovodne cevi

Sve dužine i udaljenosti cevi su uzete u obzir.

NAPOMENA

- Ako nema glikola u sistemu, u slučaju prekida napajanja ili kvara pumpe, ispraznite ceo vodovodni sistem ako je temperatura vode ispod 0°C tokom hladne zime (kako je predloženo na slici ispod, slika 1).
- Kada je voda nepokretna u sistemu, vrlo je verovatno da će doći do smrzavanja i oštećenja sistema u procesu.

9.4.1 Provera vodovodnog sistema

Uredaj je opremljen ulazom vode i izlazom vode za povezivanje sa vodovodnim krugom. Ovaj krug mora biti obezbeđen od strane licenciranog tehničara i mora se pridržavati lokalnih zakona i propisa.

Uredaj se sme koristiti samo u zatvorenom vodovodnom sistemu. Korišćenje u otvorenom vodovodnom sistemu može dovesti do prekomerne korozije vodovodnih cevi.

- Pre nego što nastavite sa instalacijom jedinice, proverite sledeće:
- Maksimalni pritisak vode: 53 bara.
- Maksimalna temperatura vode: 70°C prema postavkama sigurnosnog uređaja.
- Uvek koristite materijale koji su kompatibilni sa vodom koja se koristi u sistemu i sa materijalima koji se koriste u jedinici.
- Osigurajte da komponente instalirane u poljskim cevima mogu izdržati pritisak vode i temperaturu.
- Otvori za pražnjenje moraju biti postavljeni na svim niskim tačkama sistema kako bi omogućili potpuno pražnjenje kruga tokom održavanja.
- Ventili za izbacivanje vazduha moraju biti postavljeni na svim visokim tačkama sistema. Ventili treba da budu postavljeni na mestima koja su lako dostupna za servisiranje. Automatsko izbacivanje vazduha obezbeđeno je unutar jedinice. Proverite da li je ovaj ventil za izbacivanje vazduha odvijen kako bi automatsko oslobadanje vazduha u vodovodnom krugu bilo moguće.

9.4.2 Zapremina vode i dimenzioniranje ekspanzionih posuda

Jedinice su opremljene ekspanzionim sudom tipa BL sa fabričkim predpritiskom od 1,5 bara. Da bi se obezbedio pravilan rad jedinice, možda će biti potrebno podešiti predpritisak ekspanzionog suda.


1) Proverite da li je ukupna zapremina vode u instalaciji, isključujući unutrašnju zapreminu vode jedinice, barem 40L. Pogledajte odeljak 14 "Tehničke specifikacije" da biste pronašli ukupnu unutrašnju zapreminu vode jedinice.

NAPOMENA

- U većini primena, ovaj minimalni zapreminski protok vode će biti zadovoljavajući.
- U kritičnim procesima ili u prostorijama s visokim opterećenjem grejanjem, može biti potrebna dodatna količina vode.
- Kada se cirkulacija u svakoj petlji za grejanje prostora kontroliše daljinski upravljanim ventilima, važno je da se ova minimalna zapremina vode održava čak i kada su svi ventili zatvoreni.

2) Zapremina ekspanzione posude mora odgovarati ukupnoj zapremini vodovodnog sistema.

3) Dimenzioniranje ekspanzione posude za grejanje i hlađenje kruga.



9.4.3 Priključak vodenog kruga

Priključci za vodu moraju biti napravljeni ispravno u skladu sa ulazom i izlazom za vodu.

UPOZORENJE!

Budite oprezni da ne deformišete cevi jedinice upotrebom prevelike sile prilikom povezivanja cevovoda. Deformacija cevi može uzrokovati netačno funkcionisanje jedinice.

Ako vazduh, vлага ili prašina dospeju u vodenim krugom, mogu se pojavit problemi. Zato uvek obratite pažnju na sledeće prilikom povezivanja vodenog kruga:

- Koristite samo čiste cevi.
- Držite kraj cevi nadole prilikom uklanjanja ostruga.
- Pokrijte kraj cevi prilikom ubacivanja kroz zid kako biste sprečili ulazak prašine i prljavštine.
- Koristite dobro brtivo za narezivanje veza. Brtljenje mora moći izdržati pritiske i temperature sistema.
- Prilikom korišćenja cevi od metala koji nije bakar, pobrinite se da izolujete dva različita materijala jedan od drugog kako biste sprečili galvansku koroziju.
- Kako je bakar mekan materijal, koristite odgovarajuće alate za povezivanje vodovodnog kruga. Neodgovarajući alati mogu oštetiti cevi.

NAPOMENA

Jedinica se sme koristiti samo u zatvorenom vodovodnom sistemu. Korišćenje u otvorenom vodovodnom krugu može dovesti do prekomerne korozije vodovodnih cevi:

- Nikada ne koristite delove sa cinkom u vodovodnom sistemu. Prekomerna korozija ovih delova može se javiti zbog upotrebe bakarnih cevi u unutrašnjem vodovodnom sistemu jedinice.
- Prilikom korišćenja trosmernog ventila u vodovodnom sistemu, poželjno je odabrat trosmerni ventil tipa kugla kako biste garantovali potpuno odvajanje između sistema za toplu sanitarnu vodu i sistema za Sistem podnog grejanja.
- Prilikom korišćenja trosmernog ventila ili dvopolnog ventila u vodovodnom sistemu, preporučeno maksimalno vreme promene ventila trebalo bi da bude manje od 60 sekundi.

9.4.4 Zaštita od zamrzavanja vodovodnog kruga

Svi unutrašnji hidronički delovi su izolovani radi smanjenja gubitka toplote. Izolacija se takođe mora dodati na terenske cevi.

Softver sadrži posebne funkcije koje koriste dizalicu toplote i rezervni grejač (ako je dostupan) kako bi zaštitele ceo sistem od smrzavanja. Kada temperatura vode u sistemu padne na određenu vrednost, jedinica će zagrejati vodu, ili pomoći dizalice toplote, električnog grejanja, ili rezervnog grejača. Funkcija za zaštitu od smrzavanja će se isključiti tek kada temperatura poraste do odredene vrednosti.

U slučaju prekida napajanja, navedene funkcije ne bi štitile uređaj od smrzavanja.

OPREZ!

Kada jedinica dugo ne radi, pobrinite se da je jedinica uvek uključena. Ako želite isključiti napajanje, voda u cevnom sistemu treba biti potpuno ispraznjena, kako bi se izbeglo oštećenje pumpe i cevovodnog sistema usled smrzavanja. Takođe, napajanje jedinice treba isključiti nakon što se voda u sistemu potpuno isprazni.

Voda može ući u prekidač protoka i ne može se isprazniti, a može se smrznuti kada temperatura padne dovoljno nisko. Prekidač protoka treba ukloniti, osušiti, a zatim ponovo instalirati u jedinici.


NAPOMENA

1. Suprotno smeru kazaljke na satu, uklonite prekidač protoka.
2. Potpuno osušite prekidač protoka.

9.5 Punjenje vode

- Povežite vodosnabdevanje sa ventilima za punjenje i otvorite ventile.
- Uverite se da su svi automatski ventili za izbacivanje vazduha otvoreni (najmanje 2 okreta).
- Punite vodom dok manometar ne pokaže pritisak od otprilike 2.0 bara. Uklonite vazduh u krugu što je više moguće pomoći automatskim ventilima za izbacivanje vazduha.

Ne pričvršćujte crnu plastičnu kapicu na automatski ventil za izduvavanje na gornjoj strani jedinice dok je sistem u funkciji. Otvorite automatski ventil za izduvavanje, okrećući ga u smeru suprotnom od kazaljke na satu, barem 2 puna okreta kako biste oslobođili vazduh iz sistema.




NAPOMENA

Tokom punjenja, možda neće biti moguće ukloniti sav vazduh iz sistema. Preostali vazduh će biti uklonjen putem automatskog ventila za ispuštak tokom prvih radnih sati sistema. Može biti potrebno nadopuniti vodu nakon toga.

- Pritisak vode prikazan na manometru će varirati u zavisnosti od temperature vode (viši pritisak pri višoj temperaturi vode). Međutim, pritisak vode bi uvek trebalo da ostane iznad 0,3 bara kako bi se izbeglo unošenje vazduha u krug.
- Jedinica može isprazniti previše vode putem sigurnosnog ventila za pritisak.
- Kvalitet vode treba da bude u skladu sa Direktivama EN 98/83 EC.
- Detaljni uslovi kvaliteta vode mogu se pronaći u Direktivama EN 98/83 EC.

9.6 Izolacija vodovodnih cevi

Ceo vodovodni krug, uključujući sve cevi za vodu, mora biti izolovan kako bi se sprečila kondenzacija tokom rada u režimu hlađenja, smanjenje kapaciteta grejanja i hlađenja, kao i sprečavanje smrzavanja spoljnih vodovodnih cevi tokom zime. Materijal za izolaciju treba imati najmanje B1 klasifikaciju otpornosti na požar i mora biti u skladu sa svim važećim zakonima. Debljina materijala za izolaciju mora biti najmanje 13 mm, sa toplotnom provodljivošću od 0,039 W/mK kako bi se sprečilo smrzavanje spoljnih vodovodnih cevi. Ako je spoljna temperatura viša od 30°C i vlažnost viša od 80%, tada debljina materijala za izolaciju treba biti najmanje 20 mm kako bi se izbegla kondenzacija na površini izolacije.

9.7 Terensko ožičenje

 **UPOZORENJE!**

Glavni prekidač ili drugo sredstvo isključenja, sa razdvajanjem kontakata u svim polovicama, mora biti ugrađeno u fiksnu instalaciju u skladu sa relevantnim lokalnim zakonima i propisima. Isključite napajanje pre nego što napravite bilo kakve veze. Koristite samo bakarne žice. Nikada ne stiskajte grupisane kablove i pobrinite se da ne dolaze u kontakt sa cevima i oštrim ivicama. Proverite da na spojevima terminala nema izloženog pritiska. Svu terensku instalaciju i komponente mora instalirati licencirani električar i moraju se pridržavati relevantnih lokalnih zakona i propisa.

Poljsko ožičenje mora se izvesti prema dijagramu ožičenja koji je isporučen sa uređajem i uputstvima data u nastavku.

Obavezno koristite posebno napajanje. Nikada nemojte koristiti napajanje koje delite sa drugim uređajem.

Obavezno uspostavite uzemljenje. Ne uzemljujte uređaj na cev za vodu, zaštitnik od prenapona ili uzemljenje telefona. Nepotpuno uzemljenje može izazvati električni udar.

Obavezno instalirajte prekidač za zaštitu od zemljospaja (30 mA). Nedostatak istog može izazvati električni udar. Obavezno instalirajte potrebne osigurače ili prekidače.

9.7.1 Mere opreza prilikom električnih instalacija

- Fiksirajte kablove tako da ne dolazi do kontakta sa cevima (posebno na strani visokog pritiska).
- Fiksirajte žicu pomoću vezica za kablove tako da ne dolazi do kontakta sa cevima, posebno na strani visokog napona.
- Uverite se da nema spoljnog pritiska na priključne stezaljke.
- Prilikom instalacije uređaja za prekidanje kola sa prekidom uzemljenja, uverite se da je kompatibilan sa invertorom (otpornim na električnu buku visoke frekvencije) kako biste izbegli nepotrebno otvaranje uređaja za prekidanje kola sa prekidom uzemljenja.


NAPOMENA

Prekidač sa prekidom uzemljenja mora biti brzog tipa od 30 mA (< 0,1 s).

Ova jedinica je opremljena invertorom. Postavljanje kondenzatora za fazno pomeranje neće samo smanjiti efekat poboljšanja faktora snage, već može izazvati nepravilno zagrevanje kondenzatora zbog visokofrekventnih talasa. Nikada ne instalirajte kondenzator za fazno pomeranje, jer to može dovesti do nesreće.

9.7.2 Pregled instalacije žica

Preopterećenja koja zahtevaju terensko ožičenje. Pogledajte i "8tipična primena".

- Minimalna sekcija kabla AWG18 (0,75 mm²).
- Kablovi termistora isporučuju se s jedinicom: ako je struja opterećenja velika, potreban je AC kontaktor.


NAPOMENA

Koristite HO7RN-F za napajanje, svi kablovi su povezani na visoki napon osim kabla za termistor i kabla za korisnički interfejs.

- Oprema mora biti uzemljena.
- Svi visokonaponski spoljni tereti, ako su od metala ili imaju uzemljeni priključak, moraju biti uzemljeni.
- Sva struja spoljnog opterećenja mora biti manja od 0,2A. Ako je pojedinačna struja opterećenja veća od 0,2A, opterećenje mora biti kontrolisano putem AC kontaktora.
- Razmenjivač toplove ploče E-grejni kabl i prekidač protoka E-grejni kabl dele kontrolni port. Smernice za ožičenje na terenu.
- Većina ožičenja na jedinici treba se izvršiti na terminalnom bloku unutar prekidačke kutije. Da biste pristupili terminalnom bloku, uklonite servisnu ploču prekidačke kutije.

 **UPOZORENJE!**

Isključite sve izvore napajanja, uključujući napajanje jedinice, rezervnog grejača i napajanja rezervoara za toplu vodu (ako postoji), pre nego što uklonite servisnu ploču prekidačkog okvira.

- Fiksirajte sve kablove pomoću kablovskih vezica.
- Za rezervni grejač potreban je poseban napojni krug.
- Instalacije opremljene rezervoarom za toplu sanitarnu vodu (isporučen sa terenom) zahtevaju poseban napojni krug za pojačivač grejača. Molimo pogledajte Uputstvo za instalaciju i vlasnika rezervoara za toplu sanitarnu vodu.
- Postavite električnu instalaciju tako da prednji poklopac ne podiže prilikom postavljanja žica i čvrsto pričvrstite prednji poklopac.
- Pratite električni dijagram za radove na električnoj instalaciji (električni dijagrami se nalaze na zadnjoj strani vrata 2).
- Postavite žice i čvrsto pričvrstite poklopac kako bi se on pravilno uklopio.

9.7.3 Mere opreza pri ožičenju napajanja

- Koristite kružni spojni terminal za povezivanje s terminalnom pločom napajanja. U slučaju da se ne može koristiti iz neizbežnih razloga, obavezno poštujte sledeće upute.
-Ne povezujte žice različitih preseka na isti terminal napajanja. (Labave veze mogu izazvati pregrevanje.)
- Koristite odgovarajući odvijač za zatezanje vijaka terminala. Mali odvijači mogu oštetiti glavu vijka i sprečiti odgovarajuće zatezanje.
- Prekomerno zatezanje vijaka terminala može ih oštetiti.
- Povežite prekidač prekidača curenja na zemlji i osigurač na napojnu liniju.
- Pri provlačenju žica, pobrinite se da se koriste propisane žice, izvršite potpuno povezivanje i pričvrstite žice tako da spoljna sila ne može uticati na priključke.

9.7.4 Zahtevi za sigurnosne uređaje

1. Odaberite pojedinačno debljinu žice (minimalnu vrednost) za svaku jedinicu na osnovu tabele ispod.
2. Odaberite prekidač kola koji ima razdvajanje kontakata u svim polovima od najmanje 3 mm pružajući potpuno isključenje, gde se MFA koristi za odabir trenutnih prekidača kola i prekidača sa radom na preostalom struju:

Jednofazni 4-16 kW (rezervni grejač: 3 kW) i trofazni 8-16 kW (rezervni grejač: 9 kW) standard

Sistem	Struja napajanja						WPM	
	Hz	Napon(V)	Min(V)	Max(V)	MCA(A)	MFA(A)	kW	FLA(A)
4-6kW	50	220-240/1 N	198	264	33		0.095	0.75
8-10kW	50	220-240/1 N	198	264	35		0.095	0.75
8-10kW 3-PH	50	380-415/3N	342	456	21		0.095	0.75
12-16kW	50	220-240/1 N	198	264	43		0.095	0.75
12-16kW 3-PH	50	380-415/3N	342	456	25		0.095	0.75

Jednofazni 4-16 kW i trofazni 12-1 GW standard bez rezervnog grejača

Sistem	Struja napajanja						WPM	
	Hz	Napon(V)	Min(V)	Max(V)	MCA(A)	MFA(A)	kW	FLA(A)
4-6kW	50	220-240/1N	198	264	20	I	0.095	0.75
8-10kW	50	220-240/1N	198	264	21	I	0.095	0.75
12-16kW	50	220-240/1N	198	264	29	I	0.095	0.75
12-16kW 3- PH	50	380-415/3N	342	456	12	I	0.095	0.75

 **NAPOMENA**

MCA: Maksimalna struja kola (A)

MFA: Maksimalna amperaža osigurača (A)

WPM: Motor vodene pumpe

FLA: Amperaža pri punom opterećenju (A)

- Potrebno je instalirati prekidač za krug probroja iznad maksimalne struje kako bi se izbegli mogući električni udari.

10 POKRETANJE I KONFIGURACIJA

Jedinica treba biti konfigurisana od strane instalatera kako bi odgovarala okolini instalacije (spoljna klima, instalirane opcije, itd.) i stručnosti korisnika.

UPOZORENJE!

Važno je da instalater pažljivo pročita sve informacije u ovom poglavlju i da sistem bude konfigurisan prema potrebi.

10.1 Početno pokretanje pri niskoj spoljnoj temperaturi

Prilikom početnog pokretanja i kada je temperatura vode niska, važno je da se voda zagревa postepeno. Nemanje ovog u vidu može rezultirati pucanjem betonskih podova usled brze promene temperature. Molimo vas da kontaktirate odgovornog izvođača radova na livenju betona za dodatne informacije.

Da biste postigli ovo, najniža postavljena temperatura vode može se smanjiti na vrednost između 25°C i 35°C prilagođavanjem FOSERVICEMAN. Pogledajte SPECIJALNU FUNKCIJU za uputstva.

10.2 Provere pre pokretanja

Provere pre prvog pokretanja.

OPASNOST!

Isključite napajanje pre nego što izvršite bilo kakve veze.

Nakon instalacije jedinice, proverite sledeće pre nego što uključite prekidač:

- Terensko ozičenje: Proverite da li je terensko ozičenje između lokalnog panela napajanja i jedinice, ventila (kada je primenljivo), jedinice i sobnog termostata (kada je primenljivo), jedinice i rezervoara za toplu sanitarnu vodu, i jedinice i kompletom za rezervni grejač, povezano prema uputstvima opisanim u poglavlju 9.8 "Terensko ozičenje", prema dijagramima ozičenja i lokalnim zakonima i propisima.
- Osigurači, prekidači kruga ili uređaji za zaštitu: Proverite da li su osigurači ili lokalno instalirani uređaji za zaštitu odgovarajuće veličine i tipa navedenog u 14. "Tehničke specifikacije". Uverite se da nijedan osigurač ili uređaj za zaštitu nije zaobiđen.
- Prekidač za rezervni grejač: Ne zaboravite da uključite prekidač za rezervni grejač u kutiji sa prekidačem (zavisi od vrste rezervnog grejača). Pogledajte dijagram ozičenja.
- Prekidač za pojačivač grejača: Ne zaboravite da uključite prekidač za pojačivač grejača (važi samo za jedinice sa optionalnim rezervoarom za toplu sanitarnu vodu instaliranim).
- Ozičenje uzemljenja: Uverite se da su žice uzemljenja pravilno povezane i da su terminali uzemljenja stegnuti.
- Interno ozičenje: Vizuelno proverite kutiju sa prekidačem na prisustvo labavih veza ili oštećenih električnih komponenti.
- Montaža: Proverite da je jedinica pravilno montirana kako biste izbegli abnormalne zvuke i vibracije prilikom pokretanja jedinice.
- Oštećena oprema: Proverite unutrašnjost jedinice na oštećene komponente ili stisнуте cevi.
- Curenje rashladnog sredstva: Proverite unutrašnjost jedinice na curenje rashladnog sredstva. Ako postoji curenje rashladnog sredstva, pozovite svog lokalnog prodavca.
- Napajanje: Proverite Napon napajanja na lokalnom panelu napajanja. Napon mora odgovarati naponu navedenom na identifikacionoj etiketi jedinice.
- Ventil za ispuštanje vazduha: Uverite se da je ventil za ispuštanje vazduha otvoren (najmanje 2 okreta). Ventili za zatvaranje: Uverite se da su ventili za zatvaranje potpuno otvoreni.

11 PROBA POKRETANJA I FINALNE PROVERE

Instalater je obavezan da proveri ispravan rad uređaja nakon instalacije.

11.1 Finalne provere:

Pre uključivanja jedinice, pročitajte sledeće preporuke:

- Kada je kompletan instalacioni proces završen i svi potrebni parametri su podešeni, zatvorite sve prednje panele jedinice i vratite poklopac jedinice na mesto.
- Servisna ploča prekidačke kutije sme se otvarati samo od strane ovlašćenog električara u svrhu održavanja.

NAPOMENA

Tokom prvog perioda rada uređaja, potrebni ulazni električni napon može biti veći od vrednosti navedene na pločici sa imenom uređaja. Ovaj fenomen potiče od kompresora koji zahteva period od 50 sati rada kako bi postigao glatko funkcionisanje i stabilnu potrošnju električne energije.

11.2 Provera rada (ručno)

Ako je potrebno, instalater može izvršiti ručni testni rad u bilo koje vreme kako bi proverio ispravno funkcionisanje pročišćavanja vazduha, grejanja, hlađenja i grejanja potrošne vode.

12 ODRŽAVANJE I SERVIS

Da biste obezbedili optimalnu dostupnost jedinice, nekoliko provera i inspekcija na jedinici i terenskom ožičenju mora se sprovoditi u redovnim intervalima.

Ovo održavanje treba sprovoditi vaš lokalni tehničar.

OPASNOST!

Električni udar:

- Pre nego što započnete bilo kakve radove održavanja ili popravke, obavezno isključite napajanje na glavnom panelu snabdevanja.
- Ne dodirujte nijedan živi deo 10 minuta nakon isključivanja napajanja.
- Grejač klipa kompresora može raditi čak i u stanju pripravnosti.
- Imajte na umu da su neki delovi električne kutije komponenti vrući.
- Zabranjeno je dodirivati bilo koje provodne delove.
- Zabranjeno je ispiranje jedinice. To može izazvati električni udar ili požar.
- Zabranjeno je ostavljati jedinicu bez nadzora kada je servisni panel uklonjen.

Naredni pregledi moraju se obavljati barem jednom godišnje od strane kvalifikovane osobe:

- Vodeni pritisak:
Proveriti vodeni pritisak; ako je ispod 1 bara, dopuniti vodu u sistem.
- Vodeni filter:
Očistiti vodeni filter.
- Ventil za oslobođanje pritiska vode:
Proveriti ispravnost ventila za oslobođanje pritiska tako što se crna ručica ventila okreće suprotno smeru kazaljke na satu:
-Ako ne čujete kliktanje, kontaktirajte prodavca.
-U slučaju da voda i dalje curi iz uređaja, prvo zatvorite ventile na ulazu i izlazu vode, a zatim kontaktirajte lokalnog prodavca.
- Crevo za odvod vode iz ventila za oslobođanje pritiska:
Proveriti da li je crevo za odvod vode postavljeno na odgovarajući način.
- Izolacioni poklopac rezervoara za rezervno grejanje:
Proveriti da li je izolacioni poklopac rezervoara za rezervno grejanje pričvršćen oko rezervoara za rezervno grejanje.
- Ventil za oslobođanje pritiska vode u rezervoaru za toplu potrošnu vodu (za instalacije sa rezervoarom):
(Važi samo za instalacije sa rezervoarom za toplu potrošnu vodu) Proveriti ispravnost ventila za oslobođanje pritiska u rezervoaru za toplu potrošnu vodu.
- Grejač-booster za rezervoar za toplu potrošnu vodu:
(Važi samo za instalacije sa rezervoarom za toplu potrošnu vodu) Preporučuje se uklanjanje kamenca sa grejača-booster kako bi se produžio vek trajanja, posebno u regionima sa tvrdom vodom. Da biste to uradili, ispraznite rezervoar za toplu potrošnu vodu, izvadite grejač-booster iz rezervoara za toplu potrošnu vodu i potopite ga u kantu (ili slično) sa sredstvom za uklanjanje kamenca tokom 24 sata.
- Kutija prekidača uređaja:
-Obaviti temeljan vizuelni pregled kutije prekidača i tražiti očigledne nedostatke poput labavih veza ili oštećenih žica.
-Proveriti ispravnost rada kontaktora pomoću ohmmetra. Svi kontakti ovih kontaktora moraju biti u otvorenom položaju.
Korišćenje glikola (Vidi odeljak 9.5.4 "Zaštita od smrzavanja vodovodnog sistema"):
Zabeležiti koncentraciju glikola i pH-vrednost u sistemu barem jednom godišnje.
-pH-vrednost ispod 8.0 ukazuje da je značajan deo inhibitora iscrpljen i da je potrebno dodati više inhibitora.
-Kada je pH-vrednost ispod 7.0, došlo je do oksidacije glikola, sistem treba isprazniti i temeljno isprati pre nego što dođe do ozbiljne štete.
Paziti da se odlaganje rastvora glikola vrši u skladu sa relevantnim lokalnim zakonima i propisima.

13 REŠAVANJE PROBLEMA

Ovaj odeljak pruža korisne informacije za dijagnostikovanje i ispravljanje određenih problema koji se mogu pojaviti u jedinici. Ove procedure za otklanjanje problema i povezane ispravne radnje mogu se sprovoditi samo od strane vašeg lokalnog tehničara.

13.1 Opšte smernice

Pre nego što započnete postupak otklanjanja problema, izvršite temeljan vizuelni pregled uređaja i potražite očigledne nedostatke kao što su labave veze ili oštećene žice.

UPOZORENJE!

- Prilikom izvođenja inspekcije na kutiji prekidač jedinice, uvek se uverite da je glavni prekidač jedinice isključen.
- Kada se sigurnosni uredaj aktivira, zaustavite jedinicu i saznajte zašto je sigurnosni uredaj aktiviran pre nego što ga ponovo resetujete. Pod nikakvim okolnostima sigurnosni uredaji ne smeju biti premosteni ili promenjeni u odnosu na fabrička podešavanja ventila. Ako uzrok problema nije pronađen, pozovite svog lokalnog prodavca.
- Ako sigurnosni ventil ne radi ispravno i treba da bude zamenjen, uvek ponovo povežite fleksibilno crevo priključeno na sigurnosni ventil kako biste izbegli curenje iz jedinice!

NAPOMENA

Za probleme koji se odnose na opcioni solarni set za grejanje potrošne vode, obratite se odeljku za otklanjanje problema u Instalacionom i korisničkom priručniku za taj set.

13.2 Generalni uzroci

Simptom 1: Jedinica je uključena, ali ne zagrevava ili ne hlađi kako se očekivalo	
Mogući uzroci	Korektivne mere
Postavka temperature nije ispravna.	Proverite parametre. Tao_HMAX, Tao_HMIN u režimu grejanja. Tao_CMAX, Tao_CMIN u režimu hlađenja. Tao_DHWMAX, Tao_DHWMIN u režimu pripreme tople vode.
Protok vode je prenizak.	<ul style="list-style-type: none"> • Proverite da li su svi zatvarači vodenog kruga u ispravnom položaju. • Proverite da li je voden filter začepljen. • Obezbedite da nema vazduha u vodnom sistemu. • Proverite na manometru da li postoji dovoljan pritisak vode. Pritisak vode mora biti >1 bara (voda je hladna). • Proverite da ekspanziona posuda nije postavljena previše u odnosu na pumpu.
Volumen vode u instalaciji je prenizak.	Uverite se da je zapremina vode u instalaciji iznad minimalne potrebne vrednosti (vidi "8.5.2 Zapremina vode i dimenzioniranje ekspanzionih posuda").
Simptom 2: Jedinica je uključena, ali kompresor se ne pokreće (za grejanje prostora ili zagrevanje potrošne vode).	
Mogući uzroci	Korektivne mere
Jedinica može raditi van svog opsega rada (temperatura vode je preniska).	<p>U slučaju niske temperature vode, sistem koristi rezervni grejač kako bi prvo dostigao minimalnu temperaturu vode (18°C).</p> <ul style="list-style-type: none"> • Proverite da li je napajanje za rezervni grejač ispravno. • Proverite da li je termofuzija rezervnog grejača zatvorena. • Proverite da li je termički prekidač rezervnog grejača neaktiviran. • Proverite da li su termički kontaktori rezervnog grejača neoštećeni.
Simptom 3: Pumpa proizvodi buku (kavitacija)	
Mogući uzroci	Korektivne mere
U sistemu se nalazi vazduh.	Ispraznite vazduh.
Pritisak vode na ulazu pumpe je prenizak.	<ul style="list-style-type: none"> • Proverite na manometru da li postoji dovoljan pritisak vode. Pritisak vode mora biti >1 bara (ako je voda hladna). • Proverite da manometar nije oštećen. • Proverite da ekspanziona posuda nije oštećena. • Proverite da li je podešavanje pred-pritska ekspanzione posude ispravno (pogledajte "9.4.2 Zapremina vode i podešavanje ekspanzionih posuda").
Simptom 4: Ventil za oslobođanje pritiska vode se otvara	
Mogući uzroci	Korektivne mere
Ekspanzioni sud je oštećen.	Zamenite ekspanzionali sud.
Pritisak vode za punjenje u instalaciji je veći od 0,3 MPa.	Proverite da pritisak vode za punjenje u instalaciji iznosi otprilike 0,1 - 0,2 MPa (vidi "8.5.2 Volumen vode i dimenzioniranje ekspanzionih posuda").

Simptom 5: Ventil za oslobođanje pritiska vode curi.

Mogući uzroci	Korektivne mere
Prljavština blokira izlaz ventila za oslobođanje pritiska vode.	<p>Proverite ispravno funkcionisanje ventila za oslobođanje pritiska vode okretanjem crvene ručke na ventilu u smeru suprotnom od kazaljke na satu:</p> <ul style="list-style-type: none"> • Ako ne čujete karakterističan zvuk, kontaktirajte lokalnog dilera. • Ako voda nastavlja da curi iz uređaja, prvo zatvorite oba ventila vode (ulazni i izlazni) i potom kontaktirajte lokalnog prodavca.

Simptom 6: Nedovoljan kapacitet za zagrevanje prostora pri niskim spoljnim temperaturama.

Mogući uzroci	Korektivne mere
Rad rezervnog grejača nije aktiviran.	<p>Proverite da li je opcija "OTHER HEATING SOURCE/BACKUP HEATER" (DRUGI IZVOR GREJANJA/REZERVNI GREJAČ) omogućena, pogledajte "Uputstvo za žičani kontroler". Proverite da li je termalni prekidač rezervnog grejača aktiviran, pogledajte "Delovi kontrole za rezervni grejač (IBH)". Proverite da li je bojler za zagrevanje potrošne tople vode uključen; rezervni grejač i bojler ne mogu raditi istovremeno.</p>
Prekomerna upotreba kapaciteta toplotne pumpe za grejanje tople vode (važi samo za instalacije sa rezervoarom za topnu vodu).	<p>Proverite da li su "t_DHWHP_MAX" i "t_DHWHP_RESTRICT" pravilno konfigurisani:</p> <ul style="list-style-type: none"> • Proverite da li je opcija "DHW PRIORITY" onemogućena u korisničkom interfejsu. • Omogućite opciju "Tao_TBH_ON" u korisničkom interfejsu / FOR SERVICEMAN (ZA SERVISERE) da biste omogućili grejač potrošne tople vode.

Simptom 7: Grejna funkcija se ne može odmah promeniti u režim grejanja sanitарне vode (DHW).

Mogući uzroci	Korektivne mere
Postoji vazduh u sistemu.	Ispraznite vazduh.
Zapremina rezervoara je premala, a položaj sonde za temperaturu vode nije dovoljno visok.	<ul style="list-style-type: none"> • Postavite "t-DHWHP_RESTRICT" na minimalnu vrednost. • Omogućite TBH, i TBH bi trebalo da se kontroliše pomoću Spoljne jedinice. • Ako je dostupan AHS, prvo ga uključite. Ako su ispunjeni uslovi za uključivanje toplotne pumpe, toplotna pumpa će se uključiti. • Ako nisu dostupni ni TBH ni AHS, pokušajte promeniti položaj TWT sonde (pogledajte odeljak 5 "Opšti uvod").

Simptom 8: Način za pripremu tople vode (DHW) se ne može odmah promeniti u režim grejanja.

Mogući uzroci	Korektivne mere
Toplotna razmena za grejanje prostora nije dovoljno velika	<ul style="list-style-type: none"> • Podesite "t_DHWHP_MAX" na minimalnu vrednost, predložena vrednost je 60 minuta. • Ako cirkulaciona pumpa van jedinice nije kontrolisana od strane jedinice, pokušajte je povezati sa jedinicom. • Dodajte trosmerni ventil na ulazu u ventilatorsku spiralu kako biste obezbedili dovoljan protok vode.
Opterećenje grejanja prostora je malo.	Normalno, nema potrebe za grejanjem.
Funkcija dezinfekcije je omogućena, ali bez TBH-a.	<ul style="list-style-type: none"> • Isključite funkciju dezinfekcije • Dodajte TBH ili AHS za režim tople vode (DHW)
Ručno uključite funkciju BRZA VODA, nakon što topla voda ispuni zahteve, toplotna pumpa ne uspeva da se prebaci u režim klimatizacije na vreme kada je klima uređaj u funkciji	Ručno isključite funkciju BRZA VODA. Dodajte TBH ili AHS za režim pripreme tople sanitарне vode (DHW mode)
Kada je temperatura okoline niska, topla voda nije dovoljna i AHS nije u funkciji ili kasni	<ul style="list-style-type: none"> • Podesite "Tao_DHWMIN", preporučena vrednost je $\geq -5^{\circ}\text{C}$. • Podesite "Tao_TBH_ON", preporučena vrednost je $\geq 5^{\circ}\text{C}$.
Prioritet režima pripreme tople vode (DHW)	Ako je povezan AHS ili IBH sa uređajem, kada spoljni uređaj otkaže, unutrašnji uređaj mora raditi u režimu tople vode (DHW mode) dok temperatura vode ne dostigne podešenu vrednost pre nego što pređe u režim grejanja.

Simptom 9: Režim pripreme tople vode toplotne pumpe prestane raditi, ali postavljeni ciljni temperaturni nivo nije postignut. Grejanje prostora zahteva toplotu, ali uređaj ostaje u režimu pripreme tople vode

Mogući uzroci	Korektivne mere
Površina zavojnice u rezervoaru nije dovoljno velika.	Ista rešenja kao za Simptom 7.
TBH ili AHS nisu dostupni.	Toplotna pumpa će ostati u režimu pripreme tople vode dok se ne dostigne "t_DHWHP_MAX" ili postavljena tačka podešavanja. Dodajte TBH ili AHS za režim pripreme tople vode, TBH i AHS bi trebalo da budu kontrolisani od strane jedinice.

13.3 Kodovi grešaka

Kada se aktivira sigurnosni uredaj, na korisničkom interfejsu će se prikazati kod greške. Sva greške i koraci za ispravku mogu se pronaći u tabeli ispod. Resetujte sigurnosni uredaj isključivanjem jedinice i ponovnim uključivanjem.

Ukoliko ova procedura za resetovanje sigurnosnog uređaja nije uspešna, обратите се локалном продавцу.

KOD GREŠKE	NEDOSTATAK I LI ZAŠTITA	UZROK GREŠKE I KOREKTIVNE MERE
A7	Greška u protoku vode	<ol style="list-style-type: none"> Žični krug je kratko spojen ili otvoren. Ponovo povežite žicu ispravno. Protok vode je prenizak. Prekidač protoka vode ne funkcioniše, prekidač je otvoren ili stalno zatvoren, zamenite prekidač protoka vode.
AA	Greška u komunikaciji između kontrolera i unutrašnje jedinice.	<ol style="list-style-type: none"> Žica nije povezana između žičanog kontrolera i jedinice. Povežite žicu. Sekvenca komunikacione žice nije ispravna. Ponovo povežite grešku u komunikacionoj žici u pravilnom redosledu između kontrolera. Da li postoji visoko magnetno polje ili visoka snaga koja smeta unutrašnjoj jedinici, kao što su liftovi, veliki transformatori itd. Da biste zaštitali jedinicu, dodajte prepreku ili premestite jedinicu na drugo mesto.
93	Kvar senzora za krajnju temperaturu izlazne vode (TWO2).	<ol style="list-style-type: none"> Proverite otpor senzora. Priklučak senzora TWO2 je labav. Ponovo ga priključite. Priklučak senzora TWO2 je mokar ili ima vode. Uklonite vodu, osušite priključak. Dodajte vodootporni lepak. Kvar senzora TWO2, zamenite ga novim.
96	Senzor temperature vode u rezervoaru (TWT) neispravan.	<ol style="list-style-type: none"> Proverite otpor senzora. Priklučak senzora TWT je labav. Ponovo ga priključite. Priklučak senzora TWT je mokar ili ima vode. Uklonite vodu, osušite priključak. Dodajte vodootporni lepak. Kvar senzora TWT, zamenite ga novim.
94	Kvar senzora temperature ulazne vode (TWI)	<ol style="list-style-type: none"> Proverite otpor senzora. Priklučak senzora TWI je labav. Ponovo ga priključite. Senzor temperature vode na ulazu. Priklučak senzora TWI je mokar ili ima vode. (TWI) kvar, uklonite vodu, osušite priključak. Dodajte vodootporni lepak. Kvar senzora TWI, zamenite ga novim.
A9	Kvar u komunikaciji između unutrašnje i spoljne jedinice.	<ol style="list-style-type: none"> Žica nije povezana između spoljne jedinice i glavne kontrolne ploče unutrašnje jedinice. Povežite žicu. Sekvenca komunikacione žice nije ispravna. Ponovo povežite žicu u pravilnom redosledu. Da li postoji visoko magnetno polje ili visoka snaga koja smeta, kao što su liftovi, veliki transformatori itd. Da biste zaštitali jedinicu, dodajte prepreku ili premestite jedinicu na drugo mesto.
A3	Greška senzora temperature tečnosti rashladnog sredstva (TICL)	<ol style="list-style-type: none"> Proverite otpor senzora. Priklučak senzora TICL je labav. Ponovo ga priključite. Priklučak senzora TICL je mokar ili ima vode. Uklonite vodu, osušite priključak. Dodajte vodootporni lepak. Kvar senzora TICL, zamenite ga novim.
A4	Greška u senzoru temperature rashladivačkog gasa (TICO).	<ol style="list-style-type: none"> Proverite otpor senzora. Priklučak senzora TICO je labav. Ponovo ga priključite. Priklučak senzora TICO je mokar ili ima vode. Uklonite vodu, osušite priključak. Dodajte vodootporni lepak. Kvar senzora TICO, zamenite ga novim.
95	Senzor temperature izlazne vode (TWO1) je neispravan.	<ol style="list-style-type: none"> Priklučak senzora TWO1 je labav. Ponovo ga priključite. Priklučak senzora TWO1 je mokar ili ima vode. Uklonite vodu, osušite priključak. Dodajte vodootporni lepak. Kvar senzora TWO1, zamenite ga novim.
7F	Kvar solarnog temperaturnog senzora (Tsolar)	<ol style="list-style-type: none"> Proverite otpor senzora. Priklučak senzora Tsolar je labav. Ponovo ga priključite. Priklučak senzora Tsolar je mokar ili ima vode. Uklonite vodu, osušite priključak. Dodajte vodootporni lepak. Kvar senzora Tsolar, zamenite ga novim.
7E	Ulagana temp. vode za podno grejanje. senzor (TVI_FLH)	<ol style="list-style-type: none"> Proverite otpor senzora. Priklučak senzora TVI_FLH je labav, ponovo ga priključite. Priklučak senzora TVI_FLH je mokar ili ima vode, uklonite vodu, osušite priključak i dodajte vodootporni lepak. Kvar senzora TVI_FLH, zamenite ga novim.
A5	IOU kvar vodene pumpe	<ol style="list-style-type: none"> Proverite da li je otvoren ventil za vodu. Proverite da li je labava kontrolna linija pumpe za vodu. Proverite da li je filter prljav i blokirani. Proverite da li je napon pumpe niži od 170V ili viši od 270V. U slučaju kvara pumpe za vodu, zamenite je novom.
98	Greška ranog zatvaranja prekidača protoka vode	<ol style="list-style-type: none"> Proverite da li je žičanje prekidača protoka vode ispravno. Proverite da li je druga oprema povezana u seriji s glavnom opremom. Kvar prekidača protoka vode, zamenite novi prekidač protoka vode.

KOD GREŠKE	NEDOSTATAK ILI ZAŠTITA	UZROK GREŠKE I KOREKTIVNE MERE
97	Zaštita od niskog pritiska prekidača protiv zamrzavanja (AFLP)	1. Proverite da li je AFLP labav. 2. Proverite da li ima nedovoljno rashladnog sredstva. 3. Proverite da li je filter prljav i začepljen. 4. Kvar AFLP-a, zamenite novi AFLP.
AF	Zaštita od pregrevanja električnog grejanja	1. Proverite da li je filter prljav i začepljen. 2. Proverite da li je prekidač termičke zaštite ispac.
7D	Greška u komunikaciji s proširenjem	Proverite da li je veza normalna
A8	EE greška	1. Proverite da li su interni i eksterni povezani vodovi povezani normalno. 2. Kvar na kontrolnoj tabli, zamenite novu kontrolnu tablu.



U zimskim uslovima, ukoliko dođe do kvara na jedinici i kvar se ne popravi na vreme, vodena pumpa i cevovodni sistem mogu biti oštećeni smrzavanjem. Stoga, kvar mora biti popravljen na vreme.

14 TEHNIČKE SPECIFIKACIJE

14.1 Uopšteno

Model	jednofazna	jednofazna	trofazna	jednofazna	trofazna
	4/6 kW	8/10 kW	8/10 kW	12/14/16 kW	12/14/16 kW
Nominalno	Prema tehničkim podacima				
Dimenzije HxWxD	765x 1265x323mm	933x1385x520mm	933x1385x520mm	933x1385x520mm	933x1385x520mm
Dimenzije pakovanja HxWxD	930x 1330x428mm	1095x 1465x550mm	1095x 1465x550mm	1095x 1465*550mm	1095x 1465x550mm
Težina (rezervni grejač integriran u jedinici)					
Neto težina	90kg	124kg	128kg	137kg	140kg
Bruto težina	98kg	136kg	140kg	149kg	152kg
Težina (bez rezervnog grejača)					
Neto težina	87kg	121kg		134kg	137kg
Bruto težina	95kg	133kg		146kg	149kg
Povezivanja					
ulaz/izlaz vode	G1"BSP	G1"BSP	G1"BSP	G1"BSP	G1"BSP
Ovod vode	Kondenz crevo				
Ekspanzionia posuda					
Zapremina	8L				
Maksimalni radni pritisak (MWP)	3 bara				
Pumpa					
Tip	Hlađenje vodom	Hlađenje vodom	Hlađenje vodom	Hlađenje vodom	Hlađenje vodom
Broj brzina	Promenljiva brzina	Promenljiva brzina	Promenljiva brzina	Promenljiva brzina	Promenljiva brzina
Ventil za oslobođanje pritiska - vodenim krugom	3 bara				
Opseg rada - vodena strana					
Grejanje	+12-+65°C				
Hlađenje	+5-+25°C				
Opseg rada - vazdušna strana					
Grejanje	-25-35°C				
Hlađenje	-5-43°C				
Toplovod za domaću toplu vodu pomoću toplotne pumpe	-25-43°C				

14.2 Električne specifikacije

Model		Jednofazna 4/6/8/10/12/14/16kW	Trofazna 8/10/12/14/16kW
Standardna jedinica	Napajanje	220-240V~ 50Hz	380 - 415V 3N-50Hz
	Nominalna radna struja	Pogledajte "9.7.4 Zahtevi za sigurnosni uređaj"	
Rezervno grejno telo	Napajanje	Pogledajte "9.7.4 Zahtevi za sigurnosni uređaj"	
	Nominalna radna struja		

15 OBAVEŠTENJE O ODRŽAVANJU

Pažnja:

Za održavanje ili otpis, molimo kontaktirajte ovlašćene servisne centre. Održavanje od strane nekvalifikovane osobe može prouzrokovati opasnosti. Napunite klima uređaj sa R32 rashladnim sredstvom i održavajte klima uređaj strogo prema zahtevima proizvođača. Ovo poglavlje je uglavnom usmereno na posebne zahteve za održavanje uređaja sa R32 rashladnim sredstvom. Molimo servisera da pročita tehnički servisni priručnik posle prodaje za detaljne informacije.

Kvalifikacioni zahtevi za osoblje održavanja

1. Dodatna posebna obuka, pored uobičajenih postupaka popravki rashladne opreme, potrebna je kada je oprema s zapaljivim rashladnim sredstvima zahvaćena. U mnogim zemljama, ova obuka se sprovodi putem nacionalnih obrazovnih organizacija koje su ovlašćene da predaju relevantne nacionalne standarde kompetencija koji mogu biti postavljeni zakonodavstvom. Postignuta kompetencija treba biti dokumentovana sertifikatom.
2. Održavanje i popravka klima uređaja moraju se sprovoditi prema metodama preporučenim od strane proizvođača. Ako su potrebnii drugi stručnjaci da pomognu u održavanju i popravci opreme, to bi trebalo da se obavlja pod nadzorom osoba koje imaju kvalifikacije za popravku klima uređaja opremljenih zapaljivim rashladnim sredstvom.

Inspekcija lokacije

- Pred održavanje opreme sa rashladnim sredstvom R32, preduzmite bezbednosnu inspekciju kako biste se uverili da je rizik od požara sведен na minimum. Proverite da li je prostor dobro provetren, da li su antielektrostaticka i protivpožarna oprema u savršenom stanju.
- Tokom održavanja sistema za hlađenje, posmatrajte sledeće mere opreza pre nego što pokrenete sistem.

Postupci rada

1. Opšte radno područje:
Svom osobljju za održavanje i drugima koji rade na lokalnom području treba dati upute o prirodi radova koji se obavljaju. Rad u skućenim prostorima treba izbegavati. Područje oko radnog prostora treba biti ogradieno. Obezbediti da su uslovi unutar područja sigurni kontrolom zapaljivih materijala.
2. Provera prisustva rashladnog sredstva:
Područje treba biti provereno odgovarajućim detektorom rashladnog sredstva pre i tokom rada kako bi se osiguralo da je tehničar svestan potencijalno toksičnih ili zapaljivih atmosfera. Obezbediti da je oprema za detekciju curenja prikladna za upotrebu sa svim relevantnim rashladnim sredstvima, bez stvaranja iskri, dovoljno zaptivena ili intrinzički sigurna.
3. Prisustvo aparata za gašenje požara:
Ako se obavlja bilo koji vrući rad na rashladnoj opremi ili njenim delovima, odgovarajuća oprema za gašenje požara treba biti dostupna. Imati aparat za gašenje požara na bazi suvog praha ili CO₂ u blizini mesta punjenja.
4. Nema izvora paljenja:
Nijedna osoba koja obavlja rad u vezi sa sistemom za hlađenje koji uključuje izlaganje bilo koje cevi ne sme koristiti izvore paljenja na način koji može dovesti do rizika od požara ili eksplozije. Svi mogući izvori paljenja, uključujući pušenje cigareta, trebaju biti dovoljno udaljeni od mesta instalacije, popravke, uklanjanja i odlaganja, tokom kojih može doći do oslobađanja rashladnog sredstva u okolini prostora. Pre nego što rad počne, okolina oko opreme treba biti pregledana kako bi se osiguralo da nema zapaljivih opasnosti ili rizika od paljenja. Postavljeni su znakovi "Zabranjeno pušenje".
5. Provetravanje prostora (otvorite vrata i prozore):
Osigurati da je područje na otvorenom ili da je adekvatno provetreno pre nego što se pristupi sistemu ili obavi bilo koji vrući rad. Stepen ventilacije treba se nastaviti tokom perioda izvođenja radova. Ventilacija treba bezbedno raspršiti bilo koje oslobođeno rashladno sredstvo i po mogućству ga izbaciti van u atmosferu.
6. Provjere rashladne opreme:
Gde se menjaju električni komponenti, moraju biti namenjeni svrsi i moraju biti u skladu sa odgovarajućim specifikacijama. Uvek treba pratiti uputstva proizvođača za održavanje i servisiranje. U slučaju sumnje, konsultovati tehnički odeljak proizvođača za pomoć. Sledеće provjere treba primeniti na instalacije koje koriste zapaljiva rashladna sredstva:
 - Veličina punjenja u skladu je sa veličinom prostorije u kojoj su instalirani delovi koji sadrže rashladno sredstvo.
 - Ventilacioni uređaji i izlazi pravilno funkcionišu i nisu blokirani.
 - Ako se koristi neizravni rashladni krug, sekundarni krug treba proveriti na prisustvo rashladnog sredstva.
 - Cevi ili komponente rashladnog sistema postavljene su na mestima gde je malo verovatno da će biti izložene bilo kojoj supstanci koja može korodirati komponente koje sadrže rashladno sredstvo, osim ako komponente nisu izrađene od materijala koji su inherentno otporni na koroziju ili su odgovarajuće zaštićene od korozije.

7. Provere električnih uređaja:

Popravke i održavanje električnih komponenti trebaju uključivati početne sigurnosne provere i postupke inspekcije komponenti. Ako postoji kvar koji može ugroziti sigurnost, nijedno električno napajanje ne sme biti povezano sa krugom dok se kvar ne reši zadovoljavajuće. Ako kvar ne može odmah biti ispravljen, ali je potrebno nastaviti s radom, treba koristiti adekvatno privremeno rešenje. O tome treba obavestiti vlasnika opreme kako bi svi bili obavešteni.

Početne sigurnosne provere treba uključivati:

- Da su kondenzatori ispravnjeni: to treba učiniti na siguran način kako bi se izbegla mogućnost stvaranja iskri.
- Da nema izloženih živih električnih komponenti i žica tokom punjenja, vraćanja ili pročišćavanja sistema.
- Očuvanje kontinuiteta uzemljenja.

Provera kabla

Proverite da li je kabl pohaban, korozivan, pod prevelikim naponom, da li vibrira i proverite da li postoje oštri ivičnjaci i drugi štetni efekti u okolini. Tokom provere, trebalo bi uzeti u obzir uticaj starenja ili kontinuirane vibracije kompresora i ventilatora na njega.

Provera curenja rashladnog sredstva R32

Napomena: Provera curenja rashladnog sredstva treba se izvršiti u okruženju gde nema potencijalnog izvora paljenja. Ne sme se koristiti halogenska sonda (ili bilo koji drugi detektor koji koristi otvorenu vatru).

Metoda otkrivanja curenja:

Za sisteme sa rashladnim sredstvom R32, dostupan je elektronski uredaj za detekciju curenja koji treba koristiti, a detekcija curenja ne sme se vršiti u okruženju sa rashladnim sredstvom. Obezbedite da detektor curenja ne postane potencijalni izvor paljenja i da je primenjiv na mereno rashladno sredstvo. Detektor curenja treba biti podešen na minimalnu zapaljivu koncentraciju goriva (u procentima) rashladnog sredstva. Kalibrišite i podešite na odgovarajuću koncentraciju gasa (ne više od 25%) sa korišćenim rashladnim sredstvom.

Tečnost koja se koristi u detekciji curenja je pogodna za većinu rashladnih sredstava. Ali nemojte koristiti hloridne rastvarače kako biste sprečili reakciju između hlora i rashladnih sredstava i koroziju bakarnih cevi.

Ako sumnjate na curenje, uklonite sve izvore vatre sa mesta ili ugasite vatru. Ako je mesto curenja potreбно zavariti, tada sva rashladna sredstva treba oporaviti ili izolovati sva rashladna sredstva dalje od mesta curenja (korišćenjem odsečnog ventila). Pre i tokom zavarivanja, koristite OFN (kiseonik-freon-azot) za pročišćavanje celog sistema.

Uklanjanje i vakuumiranje

1. Proverite da nema upaljenog izvora vatre blizu izlaza vakuum pumpe i da je ventilacija dobra.
2. Dozvolite da se održavanje i ostale operacije rashladnog kruga izvode prema opštem postupku, ali ključne operacije koje već uzimaju u obzir zapaljivost su sledeće. Trebalo bi pratiti sledeće korake:
 - Uklonite rashladno sredstvo.
 - Dekontaminirajte cevovod inertnim gasovima.
 - Evakuacija.
 - Ponovno dekontaminirajte cevovod inertnim gasovima.
 - Secite ili zavarujte cevovod.
3. Rashladno sredstvo treba vratiti u odgovarajući rezervoar za skladištenje. Sistem treba napuniti azotom bez prisustva kiseonika kako bi se osigurala bezbednost. Ovaj postupak može biti potreбno ponoviti nekoliko puta. Ova operacija se ne sme izvoditi pomoću komprimiranog vazduha ili kiseonika.
4. Pomoću procesa duvanja, sistem se puni azotom bez prisustva kiseonika kako bi se postigao radni pritisak u vakuum stanju. Zatim se izbacuje azot bez prisustva kiseonika u atmosferu, i na kraju, vakuumira se sistem. Ponavljajte ovaj postupak dok se sva rashladna sredstva u sistemu ne uklone. Nakon poslednjeg punjenja azotom bez prisustva kiseonika, ispuštaјte gas u atmosferski pritisak, a zatim se može vršiti zavarivanje sistema. Ova operacija je neophodna za zavarivanje cevovoda.

Postupci punjenja rashladnih sredstava

Kao dopuna opštem postupku, potreбno je dodati sledeće zahteve:

- Proverite da ne postoji kontaminacija između različitih rashladnih sredstava prilikom upotrebe uredaja za punjenje rashladnog sredstva. Cevovod za punjenje rashladnih sredstava treba da bude što kraći kako bi se smanjila rezidualna količina rashladnih sredstava u njemu.
- Rezervoari za skladištenje trebalo bi da ostanu uspravno postavljeni.
- Proverite da su rešenja za uzemljenje već preduzeta pre punjenja sistema rashladnim sredstvom.
- Nakon završetka punjenja (ili kada još nije završeno), obeležite oznaku na sistemu.
- Pazite da ne preopteretite rashladna sredstva.

Otpad i oporavak

Otpad:

Pre ovog postupka, tehničko osoblje treba temeljno biti upoznato sa opremom i svim njenim karakteristikama, i sprovesti preporučenu praksu za bezbedno izdvajanje rashladnog sredstva. Za recikliranje rashladnog sredstva, treba analizirati uzorke rashladnog sredstva i ulja pre nego što počne operacija. Obezbediti potrebnu snagu pre testiranja.

1. Upoznajte se sa opremom i njenim radom.
2. Isključite napajanje.
3. Pre nego što započnete ovaj proces, morate se uveriti u sledeće:
 - Ako je potrebno, rad mehaničke opreme treba olakšati rad sa rashladnim rezervoarom.
 - Sva lična zaštita oprema mora biti efikasna i pravilno korišćena.
 - Ceo proces oporavka treba se izvoditi pod nadzorom kvalifikovanog osoblja.
 - Oporavak opreme i rezervoara treba se vršiti u skladu sa relevantnim nacionalnim standardima.
4. Ako je moguće, rashladni sistem treba vakuumirati.
5. Ako se ne može postići vakuum stanje, trebalo bi izvući rashladno sredstvo sa više mesta u sistemu.

6. Pre početka oporavka, trebalo bi osigurati da je kapacitet rezervoara dovoljan.
7. Pokrenite i operišite opremu za oporavak prema uputstvima proizvođača.
8. Ne punite rezervoar do njegovog punog kapaciteta (zapremina ubrizgavanja tečnosti ne sme premašiti 80% zapreme rezervoara).
9. Čak i ako trajanje bude kratko, ne sme preći maksimalni radni pritisak rezervoara.
10. Nakon završetka punjenja rezervoara i završetka procesa operacije, pobrinite se da se rezervoari i oprema brzo uklone i da su svi zatvarači na opremi zatvoreni.
11. Oporavljena rashladna sredstva ne smeju se ubrizgavati u drugi sistem pre nego što se ociste i testiraju.

Napomena: Identifikacija treba da se izvrši nakon što se uredaj odbaci i rashladna sredstva evakušu. Identifikacija treba sadržavati datum i ovlašćenje. Pobrinite se da identifikacija na aparatu može odražavati zapaljiva rashladna sredstva sadržana u tom aparatu.

Oporavak:

1. Pročišćavanje rashladnih sredstava u sistemu je potrebno prilikom popravki ili odlaganja uredaja. Preporučuje se potpuno uklanjanje rashladnog sredstva.
2. Za punjenje rashladnog sredstva u rezervoar za skladištenje može se koristiti samo poseban rezervoar za rashladno sredstvo. Obezbedite da je kapacitet rezervoara odgovarajući za količinu ubrizganog rashladnog sredstva u celom sistemu. Svi rezervoari namenjeni za oporavak rashladnih sredstava trebaju imati identifikaciju rashladnog sredstva (npr. rezervoar za oporavak rashladnog sredstva).
3. Rezervoari za skladištenje trebaju biti opremljeni ventilima za oslobođanje pritiska i kuglastim ventilima i trebaju biti u dobrom stanju. Ako je moguće, prazni rezervoari trebaju biti ispražnjeni i održavani na sobnoj temperaturi pre upotrebe. Oprema za oporavak treba se održavati u dobrom radnom stanju i opremljena uputstvima za upotrebu radi lakšeg pristupa. Oprema treba biti pogodna za oporavak rashladnih sredstava R32. Pored toga, treba postojati kvalifikovani uredaj za merenje koji se može normalno koristiti. Crevo treba biti povezano s odvojivim spojnim spojem nulte stope curenja i treba se održavati u dobrom stanju. Pre upotrebe opreme za oporavak, proverite da li je u dobrom stanju i da li je dobila savršeno održavanje. Proverite da li su električne komponente zatvorene kako bi se sprečilo curenje rashladnog sredstva i požar izazvan njime. Ako imate bilo kakvo pitanje, molimo konsultujte proizvođača.
4. Oporavljeno rashladno sredstvo treba se ubaciti u odgovarajuće rezervoare za skladištenje, uz priložene upute za transport, i vratiti proizvođaču rashladnog sredstva. Ne mešajte rashladno sredstvo u opremi za oporavak, posebno u rezervoaru za skladištenje.
5. Prostor u kojem se nalazi rashladno sredstvo R32 ne sme biti zatvoren tokom procesa transporta. Preduzmite antielektrostatičke mere ako je potrebno tokom transporta. U procesu transporta, utovara i istovara, moraju se preduzeti neophodne zaštitne mere kako bi se zaštitala klima uredaj i osiguralo da klima uredaj ne bude oštećen.
6. Prilikom uklanjanja kompresora ili čišćenja ulja kompresora, pobrinite se da je kompresor ispražnjen na odgovarajući nivo kako biste osigurali da nema preostalog rashladnog sredstva R32 u ulju za podmazivanje. Vakuumsko ispražnjavanje treba se izvršiti pre nego što se kompresor vrati dobavljaču. Dozvoljena je samo električna metoda grejanja kućišta kompresora kako bi se ubrzao proces. Obezbedite bezbednost prilikom pražnjenja ulja iz sistema.

DE-KOMISIONIRANJE, RASTAVLJANJE I ODLAGANJE

Ovaj proizvod sadrži rashladno sredstvo pod pritiskom, rotirajuće delove i električne veze koje mogu predstavljati opasnost i uzrokovati povrede. Sve radnje moraju izvoditi samo osobe sa odgovarajućim kvalifikacijama koristeći odgovarajući zaštitnu opremu i bezbednosne mere opreza.



Pročitajte uputstvo



Rizik od strujnog udara




RoHS



Jedinica se kontroliše na daljinu i može se pokrenuti bez upozorenja.



1. Izolujte sve izvore električnog napajanja za jedinicu, uključujući sve električne kontrolne sisteme koji su prekidačem povezani sa jedinicom. Obezbedite da su svi električni i gasni izolacioni ventilii u položaju ISKLJUČENO. Kabl za napajanje i gasovod mogu zatim biti isključeni i uklonjeni. Za tačke povezivanja, pogledajte uputstva za instalaciju jedinice.
2. Ispraznite sve rashladne tečnosti iz svakog sistema jedinice u odgovarajući kontejner pomoću uredaja za oporavak rashladnog sredstva. Ovo rashladno sredstvo se može ponovo koristiti, ako je to prikladno, ili se može vratiti proizvođaču radi odlaganja. NI POD KAKVIM okolnostima rashladno sredstvo ne sme biti pušteno u atmosferu. Gde je to prikladno, ispraznite rashladno ulje iz svakog sistema u odgovarajući kontejner i odbacite ga u skladu sa lokalnim zakonima i propisima koji regulišu odlaganje uljastih otpadaka.
3. Pakovane jedinice obično mogu biti uklonjene u jednom komadu nakon prethodnog isključenja. Svi vijci za pričvršćivanje trebaju biti uklonjeni, a zatim jedinica podignuta sa pozicije koristeći odgovarajuće tačke i opremu odgovarajućeg kapaciteta za podizanje. OBAVEZNO se pozivati na uputstva za instalaciju jedinice u vezi sa težinom jedinice i ispravnim metodama podizanja. Napomena da bi bilo kakvo preostalo ili prosuto rashladno ulje trebalo biti očišćeno i odbačeno kako je opisano gore.
4. Nakon uklanjanja sa pozicije, delovi jedinice se mogu odbaciti u skladu sa lokalnim zakonima i propisima.
5. Značenje prekrivenih kante za smeće na točkovima: Ne odbacujte električne aparate kao nesortiran komunalni otpad, koristite odvojene sisteme za prikupljanje. Kontaktirajte lokalnu vlast radi informacija o dostupnim sistemima za prikupljanje. Ako se električni aparati odbacuju na deponijama, opasne supstance mogu procuriti u podzemne vode i ući u lanac ishrane, oštećujući vaše zdravlje i dobrobit. Kada zamenujete stare aparate novim, trgovac je zakonski obavezan da preuzme vaš stari aparat za odlaganje, barem besplatno.



www.tesla.info