

TESLA

USER MANUAL
TABLET **L7.1 3G**

ENG

Congratulations on the purchase of your Tesla tablet!

1. To use your Tablet safely and correctly, please read the instructions in this manual carefully before use.
2. Our company owns all copyrights for this manual. Copying all or parts of this manual is forbidden.
3. The contents provided in this manual are based on the most recent information available at the time of printing. For more information about the product, visit our website (www.tesla.info).
4. Our company assumes no responsibility for personal data loss, damage and other indirect damage caused by misuse of software and hardware, or product repairs performed by unauthorized personnel.

Important safety and handling information

This manual contains important safety and operating information. To prevent accidents, please read this manual thoroughly and keep it for future reference.

- Keep the tablet away from rain and humidity.
- Do not expose the tablet to direct sunlight and heat.
- Do not use the tablet in strong magnetic fields as this can cause damage.
- Do not clean the tablet with detergent or any cleaning product containing chemicals or other liquids to avoid causing damage and corrosion.
- Carefully clean the screen. We suggest using a slightly damp, lint-free cloth that is used for cleaning camera lenses.
- Do not listen to music through headphones at high volumes for long periods of time as this can cause permanent damage to your hearing.

Control the volume and how long you listen to music in order to protect your hearing.

- Avoid charging the device at the voltage higher than suggested. Information regarding permitted volumes of circuit and voltage can be found on the charger.
- Certain movies, music and pictures are copyrighted. By downloading, using and distributing them without permission you are breaking the law.
- Wireless devices can affect the electronics of the airplane. When on an airplane, follow the rules regarding the use of electronic devices.
- Only use the original battery and any additional parts that came with your device. Inadequate replacement parts can cause permanent damages.


Package contents

- Tesla tablet
- Charger
- Technical documentation and warranty
- Micro USB cable

***Remarks

- If any part of the tablet is damaged or missing, please contact your vendor.
- The contents of the package can differ depending on a country or region.

Your Tesla tablet



1. Front Camera
2. The receiver
3. Headphone jack
4. USB port
5. Volume + key / Volume - key
6. Power key
7. Reset
8. Microphone
9. Back Camera
10. Speaker

How to charge your Tesla tablet

Use the power adapter and micro USB cable.

To charge your Tesla tablet:

1. Connect the USB cable with the power adapter.
2. Insert the micro USB connector into Tesla tablet.
3. Plug the power adapter into a jack.

Before using the tablet for the first time, you should charge the battery for approximately 4 to 5 hours.

Using the charger

To charge your Tesla tablet:

- Insert the micro USB connector into Tesla tablet.
- Plug the power adapter into a jack.

Charge your Tesla tablet until the battery indicator shows 100%. The battery doesn't need to be formatted.

IMPORTANT!

- When charging Tesla tablet use only the provided power adapter and micro USB cable. Using a different adapter can damage the device.
- Take care when inserting the power adapter into a suitable jack with a specific input voltage.
- Do not place objects on your Tesla tablet, even when you are not using it.

REMARKS

Tesla tablet can also be charged via a computer's USB port, but this is not recommended as it may take longer to power your device.

If possible, we advise you to charge your Tesla tablet by connecting a charger that came with your device to a wall socket.

TESLA

www.tesla.info