TESLA

VCR600W

ROBOT VACUUM CLEANER

WI-FI FUNCTION USER MANUAL

ENG

ENG

WI-FI MODULE SPECIFICATION AND OPERATION GUIDELINE

1. Minimum specifications on a smartphone:
   Android 5.0 version or higher
   IOS 9.0 version or higher
2. Basic parameters for Wi-Fi module

Parameters	Details
Network frequency	2.400 - 2.4835 GHz
Standards of WLAN	IEEE 802.11 b/g/n (channels 1-14, channels 1-13 for EU/AU, channels 1-11 for US/CA)
Protocol stack support	IPv4/TCP/UDP/HTTPS/TLS/DNS
Security support	WEP/WPA/WPA2/AES128
Network type support	STA/AP/STA+AP
Max. RF Power	18.5 dbm
Blue tooth frequency	2.402 - 2.480 GHz
Blue tooth RF Power	9 dbm

3. Operation guideline. Please use the simple guideline instructions below as reference.

Operation Steps	Operation Items	New Account	Re-install APP (registered before)
Step 1	Download and Install APP	YES	YES
Step 2	Activate APP	YES	YES
Step 3	Account Registration	YES	NO
Step 4	Login	YES	YES
Step 5	Add Device to control	YES	Registered Device will remain

Note: *If you registered the account and added device before, when you re-install the APP again and login, the added device will remain.*

DOWNLOAD AND INSTALL THE APP

For Android

For iOS

Tesla Smart

For Android smartphones

Method 1: Please scan the QR code with a browser scanner, download and install the APP.
Method 2: Open the Google "Play Store" on your smartphone and search "Tesla Smart", download and install the APP.

For IOS smartphones

Method 1: Please scan the QR code and follow the tips to get into "AppStore", download and install the APP.
Method 2: Open the Apple "AppStore" on your smartphone and search "Tesla Smart Things", download and install the APP.

⚠ ***Note:*** *Please enable the Storage/Location/Camera permissions for this APP during the installation. Otherwise it will have some problems when operating.*

REGISTRATION

1. If you don't have an account please tap the "Register" button.
2. Read the Privacy Policy and tap "Agree".



LOGIN

1. Tap “Sign in with an existing account”.
2. Enter your registered account username and password.
3. Tap the “Sign in” button.





REGISTRATION

1. Enter the verification code you received via e-mail.
2. Set the Password with 6-20 characters, including characters and numbers.
3. Tap “Done”.



ENG

LOGIN

1. Tap “Log in with existing account”.
2. Enter your registered account username and password.
3. Tap “Log in” button.





enter your account here

enter the password

Forgot the password

If you forgot the password or you want to reset the password, follow these steps:

1. Tap “Forgot password”.
2. Enter your account username (e-mail address) and tap the “Obtain verification code” button.
3. Enter the verification code received via e-mail.
4. Set the new password and tap the “Done” button.





ADDING DEVICES

AP mode

1. Power on the robot
2. Press both the HOME and the ON button for more than 3 seconds, until robot starts flashing and voice prompts “Wi Fi lost, please follow the APP instructions”
3. Ensure your phone is connected to same network you wish to connect the robot
4. Select “Small Home Appliance”
5. Tap the “Robot vacuum (Wi Fi)” logo
6. Input the password of the Wi-Fi to which your smartphone is connected, then tap “Next”
7. Tap + in the upper right corner and choose “AP Mode”, follow the comments on the screen to reset the Wi-Fi module modem is reset by pressing HOME and the ON button for more than 3 seconds, check “Confirm the device is reset” and tap “Next”
8. Read the instruction carefully and tap “Connect now”
9. Connect your mobile phone to the device’s hotspot
10. You can see the percent rate of the connection process, in real time.









www.tesla.info